PR series User Manual - Full Version



BrainChild

TABLE OF CONTENTS

1.	G	ENERAL DESCRIPTION	. 8				
1.1	ι	UNIQUE FEATURES OF RECORDER	8				
1.2	(COMPARISON OF PR SERIES RECORDERS12					
1.3	E	EXPANDABLE INPUT AND OUTPUT CARDS					
1.4	(COMMUNICATION					
1.5	E	EXTERNAL STORAGE MEDIA	15				
1.6	5	SMART MECHANISM	16				
1.7	(ORDERING CODES AND ACCESSORIES	17				
1	.7.1	PR10 Ordering code	17				
1	.7.2	PR20 Ordering code	19				
1	.7.3	PR30 Ordering code	22				
1	.7.4	PC201 Ordering code	24				
1	.7.5	Accessories:	25				
1.8	ę	SPECIFICATIONS	27				
2.	IN	STALLATION AND WIRING	32				
2.1		UNPACKING	22				
2.1							
2.2		PANEL MOUNTING STYLE	-				
2.3		SETUP INPUT AND OUTPUT					
2.4		WIRING OF THE CARDS					
2.5		RS-232, RS-422, AND RS-485 WIRING					
2.0							
3.	BA	ASIC FUNCTIONS OF RECORDERS	58				
3.1	(CONFIGURATION	58				
3.2	5	STANDARD AND PLUS VERSION OF FIRMWARE	58				
3.3	(COMMUNICATION WITH THIRD PARTY INTERFACES60					
3.4	I	INFORMATION ACCESSIBILITY THROUGH WEB60					
3.5	ł	HANDWRITING MESSAGES ON TREND SCREENS	61				
3.6	(CUSTOM EDITED DISPLAY SCREENS65					
3.7		ANALOG INPUT LOG SPEED FLEXIBILITY	66				
3.8	ł	HIGH SPEED INPUT	66				
3.9	ę	SYSTEM CLOCK SYNCHRONIZATION VIA INTERNET	66				
3.10)	INCREASED SECURITY IN PASSWORD CONFIGURATION	66				
3.1 [,]	1	AUTO OUTPUT TO PRINTER	66				
3.12	2	EXTERNAL CHANNELS	66				

3.13	Ватсн	66
3.14	FDA 21 CFR PART 11	66
4. CO	NFIGURATION	
-		-
	HANNEL	
4.1.1	Analog Input	
4.1.2	Digital Input	
4.1.3	Math Channel	78
4.1.4	Analog Output	
4.1.5	Digital Output	
4.1.6	External	
4.1.7	Jobs	93
4.2 D	ISPLAY	96
4.2.1	Status Bar	
4.3 T	IMER	99
4.4 C	LOCK	102
4.5 C	OMMUNICATION	103
4.5.1	Connections	105
4.5.2	Commands	106
4.5.3	Modbus RTU Master, Example1	107
4.5.4	Modbus RTU Master, Example2	109
4.5.5	Modbus RTU Slave, Example	111
4.6 IN	ISTRUMENT	113
4.7 S	ECURITY	114
4.7.1	Normal	114
4.7.2	CFR-21	115
4.8 D	ЕМО	116
4.9 A	ито-Оитрит	116
4.9.1	USB Printer	117
4.9.2	Network Printer (LPT1)	119
4.9.3	Print Historical data	120
4.9.4	Print Reports	122
4.9.5	Print Snapshot	123
4.10	SYSTEM INFO	124
4.11	BATCH CONTROL	127
4.12	CALIBRATE	134
4.13	PROCEDURE TO UPGRADE AND RESTORE FACTORY DEFAULT SETTINGS	152
e 50		4 - 4
5. PC	BASED SOFTWARE	
5.1 F	REE BASIC SOFTWARE	154
5.1.1	Requirements	154

	5.1.2	Operating system	. 154
	5.1.3	Software	. 154
	5.1.4	Ethernet Configuration	. 158
	5.1.5	Automatic export of data from historical viewer	. 163
5.	2 DAT	A ACQUISITION STUDIO SOFTWARE	164
	5.2.1	Requirements	. 164
	5.2.2	Software	. 165
	5.2.3	How to configure Communication Bank	. 165
	5.2.4	How to configure Recorder	. 169
	5.2.5	Touch Screen	. 169
	5.2.6	Ethernet	. 169
	5.2.7	Removable Media	. 173
	5.2.8	Configuration	. 177
	5.2.9	How to view Historical data	. 188
	5.2.10	How to view Real time data in PC	. 195
	5.2.11	Bank configuration	. 195
	5.2.12	Ethernet	. 198
	5.2.13	Serial (RS232/422/485)	. 201
	5.2.14	View Real time data from Multiple Recorders	. 201
5.	3 PAN	IEL STUDIO VERSION	202
	5.3.1	System Requirements	. 203
	•.•.	· ·	
	5.3.2	Software Installation	
			. 204
	5.3.2	Software Installation	. 204 . 205
	5.3.2 5.3.3	Software Installation Project status	. 204 . 205 . 206
	5.3.2 5.3.3 5.3.4	Software Installation Project status Create new project	. 204 . 205 . 206 . 207
	5.3.2 5.3.3 5.3.4 5.3.5	Software Installation Project status Create new project Menu bar	. 204 . 205 . 206 . 207 . 208
	5.3.2 5.3.3 5.3.4 5.3.5 5.3.6	Software Installation Project status Create new project Menu bar File	. 204 . 205 . 206 . 207 . 208 . 209
	5.3.2 5.3.3 5.3.4 5.3.5 5.3.6 5.3.7	Software Installation Project status Create new project Menu bar File Environment	. 204 . 205 . 206 . 207 . 208 . 209 . 211
	5.3.2 5.3.3 5.3.4 5.3.5 5.3.6 5.3.7 5.3.8	Software Installation Project status Create new project Menu bar File Environment Edit	. 204 . 205 . 206 . 207 . 208 . 209 . 211 . 212
	5.3.2 5.3.3 5.3.4 5.3.5 5.3.6 5.3.7 5.3.8 5.3.9	Software Installation Project status Create new project Menu bar File Environment Edit Format	. 204 . 205 . 206 . 207 . 208 . 209 . 211 . 212 . 215
	5.3.2 5.3.3 5.3.4 5.3.5 5.3.6 5.3.7 5.3.8 5.3.9 5.3.10	Software Installation Project status Create new project Menu bar File Environment Edit Format View	. 204 . 205 . 206 . 207 . 208 . 209 . 211 . 212 . 215 . 217
	5.3.2 5.3.3 5.3.4 5.3.5 5.3.6 5.3.7 5.3.8 5.3.9 5.3.10 5.3.11	Software Installation Project status Create new project Menu bar File Environment Edit Format View Objects	. 204 . 205 . 206 . 207 . 208 . 209 . 211 . 212 . 215 . 217 . 218
	5.3.2 5.3.3 5.3.4 5.3.5 5.3.6 5.3.7 5.3.8 5.3.9 5.3.10 5.3.11 5.3.12	Software Installation Project status Create new project Menu bar File Environment Edit Format View Objects Project	. 204 . 205 . 206 . 207 . 208 . 209 . 211 . 212 . 215 . 217 . 218 . 218
	5.3.2 5.3.3 5.3.4 5.3.5 5.3.6 5.3.7 5.3.8 5.3.9 5.3.10 5.3.11 5.3.12 5.3.12 5.3.13	Software Installation Project status Create new project Menu bar File Environment Edit Format View Objects Project Standard bar	. 204 . 205 . 206 . 207 . 208 . 209 . 211 . 212 . 215 . 217 . 218 . 218 . 219
	5.3.2 5.3.3 5.3.4 5.3.5 5.3.6 5.3.7 5.3.8 5.3.9 5.3.10 5.3.11 5.3.12 5.3.12 5.3.13 5.3.14	Software Installation Project status Create new project Menu bar File Environment Edit Format View Objects Project Standard bar Format bar	. 204 . 205 . 206 . 207 . 208 . 209 . 211 . 212 . 215 . 217 . 218 . 218 . 218 . 219 . 220
	5.3.2 5.3.3 5.3.4 5.3.5 5.3.6 5.3.7 5.3.8 5.3.9 5.3.10 5.3.11 5.3.12 5.3.13 5.3.14 5.3.15	Software Installation Project status Create new project Menu bar File Environment Edit Format View Objects Project Standard bar Format bar Project Explorer	. 204 . 205 . 206 . 207 . 208 . 209 . 211 . 212 . 215 . 217 . 218 . 218 . 218 . 218 . 219 . 220 . 221
	5.3.2 5.3.3 5.3.4 5.3.5 5.3.6 5.3.7 5.3.8 5.3.9 5.3.10 5.3.11 5.3.12 5.3.13 5.3.14 5.3.15 5.3.16	Software Installation	. 204 . 205 . 206 . 207 . 208 . 209 . 211 . 212 . 213 . 217 . 218 . 218 . 219 . 220 . 221 . 224
	5.3.2 5.3.3 5.3.4 5.3.5 5.3.6 5.3.7 5.3.8 5.3.9 5.3.10 5.3.11 5.3.12 5.3.13 5.3.14 5.3.15 5.3.16 5.3.17	Software Installation	. 204 . 205 . 206 . 207 . 208 . 209 . 211 . 212 . 215 . 217 . 218 . 218 . 218 . 219 . 220 . 221 . 224 . 282


5.3.21	Project Tools	329
5.3.22	Build	329
5.3.23	Build & Offline Simulation	329
5.3.24	Stop	330
5.3.25	Build & Download	331
5.3.26	Download	331
5.3.27	Project status	333
6. WE	BSERVER	334
6.1 R	EQUIREMENTS	334
6.1 R e 6.1.1	EQUIREMENTS Hardware	
		334
6.1.1	Hardware	334 334
6.1.1 6.1.2	Hardware Operating system	334 334 334
6.1.1 6.1.2 6.1.3 6.1.4	Hardware Operating system Browser Requirements	334 334 334 335
6.1.1 6.1.2 6.1.3 6.1.4	Hardware Operating system Browser Requirements IP Address Requirements	334 334 334 335 335
6.1.1 6.1.2 6.1.3 6.1.4 6.2 H o	Hardware Operating system Browser Requirements IP Address Requirements DW TO CONFIGURE WEB SERVER SETTINGS	

Safety

This recorder is compliant with the requirements of EN61010-1, UL 61010C-1 & CSA C22.2 No. 24-93. The protection provided by the recorder may be impaired if it is used in a manner inconsistent with its intended purpose, or in an environment that exceeds the specifications of the recorder. Brainchild Electronic Co., Ltd. is not liable if the customer fails to comply with these requirements.

Safety Symbols

The following symbols may be seen in the user manual or on recorder labeling.



Safety Notes and Precautions

- 1. Before any connection is made, the protective earth terminal should be connected first. To avoid making the recorder dangerous under fault conditions, any interruption of the protective Earth conductor inside or outside the recorder is prohibited. Even in the case of a portable unit, the protective earth terminal must remain connected if the recorder is connected to any hazardous voltage.
- 2. Keep signal and supply voltage wiring separated from one another. If this is impractical, use shielded cables for signal wiring. Double insulation should be used for signal wiring when the recorder is used with hazardous voltage.
- 3. Do not use the recorder where there is high vibration or a high magnetic field. This could cause damage or error of measurement.
- 4. All maintenance or repairs should be carried out with power disconnected to avoid personal injury or damage to the unit.
- 5. In areas with conductive pollution, adequate ventilation, filtering and sealing must be installed.

- 6. When cleaning the recorder, handle carefully and use soft dry cloth. Avoid the use of abrasives, or any sharp or hard objects which would damage the display.
- 7. Do not operate the recorder if any part has been removed or disassembled. Consult your nearest dealer at once.

Static Electricity

Appropriate precautions must be taken when handling the recorder. The circuit board components are susceptible to damage caused by electrostatic discharge. Take static electricity precautions while handling and inserting USB memory into the recorder.

NOTE: IF THE USER REQUIRES TO QUICKLY OR BRIEFLY KNOW DETAILS OF THE FUNCTIONS, PLEASE REFER THE QUICK USER MANUAL

1. General Description

1.1 Unique features of recorder

The PR series is a well-designed new generation paperless recorders with many outstanding features as follows:

Hardware


- Three sizes including 4.3", 5.6["] and 12.1"
- PR10, with a 4.3" display, with 3 or 6 universal analog inputs and 24 Optional External Channels
- PR20, with a 5.6" display, with 6, 12, 18 or 24 universal analog inputs and 48 Optional External Channels
- PR30, with a 12.1" display, with 6, 12, 18, 24, 30, 36, 42 or 48 universal analog inputs and 96 Optional External Channels
- TFT Color LCD, Touch screen & high resolution
- 100 millisecond sample rate and data logging
- Process Control card (PC201) to control the process.
- High accuracy 24-bit A-D Analog Input
- 16-bit D-A Analog Output
- Digital input, maximum 100 Hz.
- Plug & play I/O cards (AI, AO, DI, DO) for easy expansion
- On-board SD card slot for Internal memory
- USB slot for external storage
- 171 mm short depth
- Ethernet as standard with optional RS-232 or RS422/RS485 communication
- Two USB Host ports for downloading the data or connect to Printer
- IP65 / NEMA 4X water-resistant



Firmware and PC Software

- Free Basic software for configuration, Historical viewer
- Extensive Software- Data Acquisition Software for configuration, Historical viewer and Real time viewer
- View Circular Trends in PR30
- Additional Panel Studio Software for editing and customizing displays
- Display values in Digital, Real time trends, Historical trends, Bar graphs etc.
- Real time and Historical alarms
- Event management, Jobs linked with events
- Reports (Daily, Weekly and Monthly)
- Timers, Counters, Totalizers, Math channels and optional FDA 21 CFR part 11
- Customized messages for alarms
- Alarms by email directly from paperless recorder
- Batch control, log data in batches
- 100 msec. data logging and historical data archival tools
- Display screen rotation
- Dynamic Data Exchange via PC software
- Search data with reference to time and period, then Export to spread sheets
- Data logging by value change or time base
- Start/Stop data logging functions which can be linked with real time clock or events


Historical Viewer in Free and Extensive Software:




0		1 22	📐 📄 🚮 🛄 Sys	0 9	1 🛋		+ 🔹 🍬	n 📭 🛛 🤉	Close
				F	age	1		1.4	
2	2 3	4	5 6						
Mod	le Mix		 Directi 	on Hori	zonta	· •	Back	ground Black	•
Pen									
No.	Chanr	iel	Color		W	idth	Low	High	-
1	AI1	-	Blue	•	1	-	-120.0	1000_0	
2	AI2	•	Green	•	1	•	-200.0	1370.0	
3	AI3	•	Cyan	-	1	•	-250.0	400.0	
4	Al4	-	Red	•	1	-	-100.0	900.0	
5	AI5	-	Magenta	-	1	-	0_0	1820.0	
6	AI6	-	Yellow	-	1	•	0_0	1767.0	
Status B	lar								
	DI		DO			Totaliz	er	Counter	
Disable	l.	- 0	Disable	→ Di	sable	ù.	- D	isable	-


Configuration Editing in either Free or Extensive Software:


Extensive Software- Data Acquisition Studio with Real-time Viewer:





Panel Studio Software to Edit Custom Displays:





1.2 Comparison of PR series Recorders

Description	PR10	PR20	PR30
Display Size	4.3″	5.6″	12.1"
Analog Inputs (Maximum)	6	24	48
Math Channels (Maximum)	15	40	60
External Channels (Other devices)	24	48	96
Total Pages	8	20	21
Pens/Page (Maximum)	6	6	10
Batches (Maximum)	1	1	1

1.3 Expandable Input and Output cards

The recorder is equipped with rear expansion slots, which work flexibly with the following plug & play I/O cards.

Analog Input cards (part number AI206 & AI203): These two cards are used for 3 or 6channel analog inputs. Each input is isolated from each other to avoid noise and to ensure stable measurement.

> Al206 6 Al (6 analog inputs)



Relay Output card (RO206): Each card includes 6 alarm relays. Contacts are rated 5 Amp/240 VAC



Digital Input card (DI206): Each card includes 6 channels. Logic Low: -5V minimum, 0.8V maximum, Logic High: 3.5V minimum, 24V maximum

DI206 6 DI (6 digital inputs) **Combination Relay Output and Digital Input Card (RD233):** Each Card includes 3 digital Inputs and 3 Relay Outputs. For Digital Inputs, Logic Low: -5V minimum, 0.8V maximum, Logic High: -3.5V minimum, 24V maximum. For Relay Outputs, the Contacts are rated 5 Amp/240 VAC



Analog Output cards (AO206): Each card includes 6 channels. They are used for 4-20mA, 0-20mA current output, 0-5V, 1-5V, 0-10VDC voltage output.



Process Control card (PC201): Each card includes 2 Analog channels and 5 Digital Channels (1-Digital input, 2-Digital outputs, 2-Digital Outputs for Alarms)

PC201 single loop process control

•



1.4 Communication

The standard communication interface is Ethernet with protocol IEEE 802.3 – 10/100 Base T. Other options are RS-232 / RS-422 / RS-485. Details are explained in Chapter 2.6 - RS-232, RS-422, RS-485 wiring

1.5 External Storage media

There are two types of External storage for the recorder, SD card and USB. If the recorder is used with **6-channel inputs**, we've made an easy chart to show the maximum days based on available memory.

Log speed	SD card	16GB	32GB
1 second		15, 808 days	31,616 days
10 seconds		158,032 days	316,064 days
120 seconds		1,896,304 days	3,792,608 days

* The above is an approximation, each record of data uses 2 or 4 bytes of memory depending on the data type.

For ex: Selected data size = 2 bytes

If the Log Speed (the recording speed of measured data) is set to the fastest speed at 1 second per data, then for a six channels, a 16GB SD Card will last approximately 15, 808 days [16GB / (2 bytes x 24 hours x 60 minutes x 60 seconds x 6 Channels].


The following formula is to calculate how many days a USB disk can do saving before it is full.

of days = (The capacity of SD card memory x Log Speed) / (2 x # of hours per day x 60 x 60 x Number of channels)

If the User is using USB to store data, to avoid losing recorded data while transferring to PC, it is necessary to insert USB memory back again into the recorder soon after loading recorded data onto PC. Otherwise, data may not be recorded while the USB is absent.

1.6 Smart Mechanism


The recorded data is stored in the manufacturer's special binary format. It is not possible to manipulate or modify the recorded data. This feature fully guarantees the security of the data.



Front View:

1.7 Ordering codes and accessories

1.7.1 PR10 Ordering code



1 Additional Inputs and Outputs*

- 0: none
- 6: 3 relays + 3 DI

PR1006 (6 Analog Inputs)

1 Additional Inputs and Outputs

- 0: none
- 1: 6 relays
- 3: 6DI
- 6: 3 relays + 3 DI
- 7: 6 relays + 6 DI

2 Power

A: 90-250 VAC, 50/60 Hz D: 11-36 VDC

3 Communication

- 0: standard Ethernet interface
- 1: Ethernet + RS-232
- 2: Ethernet + RS-422/485

4 Firmware

- 0: Standard Version with Mathematic Fuctions
- 1: Plus Version 1 with external channels, batch & FDA 21 CFR part 11
- 2: Plus Version 2 with editable custom display and Panel Studio software
- 3: Plus Version 3- includes Plus Version 1+2 above

5 PC Software

- 1: Free Basic Software of Historical Viewer and Configuration
- 2: Extensive software Data Acquisition Studio
 - (Real Time Viewer + Historical Viewer + Configuration)

6 Mounting types, Power Cord & Switch

0: panel mount, no power cord, no power switch1: panel mount, no power cord, power switch

2: portable, UL & CSA power cord, power switch

3: portable, VDE power cord, power switch

4: portable, SAA power cord, power switch

5: portable, BS power cord, power switch

6: portable, no power cord, power switch

7: Panel mount, UL & CSA power cord, power switch

8: Panel mount, VDE power cord, power switch

9: Panel mount, SAA power cord, power switch

A: Panel mount, BS power cord, power switch

7 & 8 Special options

00: none

- S1: 16G SD card
- S2: 32G SD card
- 10: Process control card
- 11: Process control card + 16G SD card
- 10: Process control card + 32G SD card

*DI- Digital Input

1.7.2 PR20 Ordering code

PR2003 (3 Analog Inputs) -



1 Other Inputs and Outputs*

- 0: none
- 6: 3 relays + 3 DI
- C: 3 relays + 3 DI + 6 AO

PR2006 (6 Analog Inputs)

- **1** Other Inputs and Outputs*
 - 0: none
 - 1: 6 Relays
 - 3: 6 DI
 - 5: 6 AO
 - 6: 3 relays + 3 DI
 - 7: 6 relays + 6 DI
 - A: 6 relays + 6 AO
 - B: 6 DI + 6 AO
 - C: 3 relays + 3 DI + 6 AO
 - D: 6 relays + 6 DI + 6 AO

PR2012 (12 Analog Inputs)

1 Other Inputs and Outputs*

- 0: none
- 1: 6 Relays
- 2: 12 Relays
- 3: 6 DI
- 4: 12 DI
- 5: 6 AO
- 6: 3 relays + 3 DI
- 7: 6 relays + 6 DI
- 8: 9 relays + 3 DI
- 9: 3 relays + 9 DI
- A: 6 relays + 6 AO
- B: 6 DI + 6 AO
- C: 3 relays + 3 DI + 6 AO

PR2018 (18 Analog Inputs)

1 Other Inputs and Outputs*

- 0: none
- 1: 6 Relays
- 3: 6 DI
- 5: 6 AO
- 6: 3 relays + 3 DI

PR2024 (24 Analog Inputs)

1 Other Inputs and Outputs* 0: none

2 Power

A: 90-250 VAC, 50/60 Hz D: 11-36 VDC

3 Communication

- 0: standard Ethernet interface
- 1: Ethernet + RS-232
- 2: Ethernet + RS-422/485

4 Firmware

- 0: Standard Version with Mathematic Fuctions
- 1: Plus Version 1 with external channels, batch & FDA 21 CFR Part 11
- 2: Plus Version 2 with editable custom display and Panel Studio softwar
- 3: Plus Version 3- includes Plus Version 1 and 2

5 PC Software

- 1: Free Basic Software of Historical Viewer and Configuration
- 2: Extensive software Data Acquisition Studio (Real Time Viewer + Historical Viewer + Configuration)

6 Mounting types, Power Cord & Switch

- 0: panel mount, no power cord, no power switch
- 1: panel mount, no power cord, power switch
- 2: portable, UL & CSA power cord, power switch
- 3: portable, VDE power cord, power switch
- 4: portable, SAA power cord, power switch
- 5: portable, BS power cord, power switch
- 6: portable, no power cord, power switch
- 7: Panel mount, UL & CSA power cord, power switch
- 8: Panel mount, VDE power cord, power switch
- 9: Panel mount, SAA power cord, power switch
- A: Panel mount, BS power cord, power switch

7&8 Special options

00: none S1: 16G SD card S2: 32G SD card 10: Process control card 11: Process control card + 16G SD card 10: Process control card + 32G SD card

*DI- Digital Input AO-Analog Retransmission Output


Note:

Process control card can not be chosen together with 5: 6AO, A: 6 relays + 6AO B: 6DI +6AO C: 3 relays + 3DI + 6AO D: 6 relays + 6DI + 6AO nor with 24 analog inputs

1.7.3 PR30 Ordering code

PR3006 (6 Analog Inputs)

Analog inputs) –



PR3012 (12 Analog Inputs) PR3018 (18 Analog Inputs) PR3024 (24 Analog Inputs) PR3030 (30 Analog Inputs) PR3036 (36 Analog Inputs) PR3042 (42 Analog Inputs) PR3048 (48 Analog Inputs)

1 Relay Outputs

- 0: none
- 1: 6 Relays
- 2: 12 Relays
- 3: 18 Relays
- 4: 24 Relays

2 Digital Inputs

- 0: none
- 1: 6 Channels
- 2: 12 Channels
- 3: 18 Channels

3 Analog Outputs

- 0: none
- 1: 6 Channels
- 2: 12 Channels

4 Power

A: 90-250 VAC, 50/60 Hz D: 11-36 VDC

5 Communication

- 0: standard Ethernet interface
- 1: Ethernet + RS-232
- 2: Ethernet + RS-422/485

6 Firmware

- 0: Standard Version with Mathematic Fuctions
- 1: Plus Version 1 with external channels, batch & FDA21 CFR Part 11
- 2: Plus Version 2 with editable custom display and Panel Studio software
- 3: Plus Version 3- includes Plus Version 1 and 2

7 PC Software

- 1: Free Basic Software of Historical Viewer and Configuration
- 2: Extensive software Data Acquisition Studio
 - (Real Time Viewer + Historical Viewer + Configuration)

8 Mounting types, Power Cord & Switch

- 0: panel mount, no power cord, no power switch
- 1: panel mount, no power cord, power switch
- 2: portable, UL & CSA power cord, power switch
- 3: portable, VDE power cord, power switch
- 4: portable, SAA power cord, power switch
- 5: portable, BS power cord, power switch
- 6: portable, no power cord, power switch
- 7: Panel mount, UL & CSA power cord, power switch
- 8: Panel mount, VDE power cord, power switch
- 9: Panel mount, SAA power cord, power switch
- A: Panel mount, BS power cord, power switch


9&10 Special options

00: none

- S1: 16G SD card
- S2: 32G SD card
- 10: Process control card
- 11: Process control card + 16G SD card
- 10: Process control card + 32G SD card

Note: Process control card can not be chosen together with 5: 6AO, A: 6 relays + 6AO B: 6DI + 6AO C: 3 relays + 3DI + 6AO D: 6 relays + 6DI + 6AO nor with 24 analog inputs

1.7.4 PC201 Ordering code



A: Output 1

- 0: None
- 1: Relay 2A/240VAC
- 2: Pulse voltage to drive SSR, 5V/30mA
- 3: Isolated 4-20mA/0-20mA (OM95-3)
- 4: Isolated 1-5V/0-5V (OM95-4)
- 5: Isolated 0-10V (OM95-5)
- 6: Triac output 1A/240VAC, SSR
- C: Pulse voltage to drive SSR, 14V/40mA (OM94-7)

B: Output 2

- 0: None
- 1: Relay 2A/240VAC
- 2: Pulse voltage to drive SSR, 5V/30mA
- 3: Isolated 4-20mA/0-20mA (OM95-3)
- 4: Isolated 1-5V/0-5V (OM95-4)
- 5: Isolated 0-10V (OM95-5)
- 6: Triac output 1A/240VAC, SSR
- 7: Isolated 20VDC/25mA power supply (DC94-1)
- 8: Isolated 12VDC/40mA power supply (DC94-2)
- 9: Isolated 5VDC/80mA power supply (DC94-3)
- C: Pulse voltage to drive SSR, 14V/40mA (OM94-7)

C: Alarm 1

- 0: None
- 1: Form C relay 2A/240VAC

D: Alarm 2

- 0: None
- 1: Form A relay 2A/240VAC

1.7.5 Accessories:

Part no.	Descriptions
AI203	3-channel analog input card (TC, RTD, mA, V, mV)
AI206	6-channel analog input card (TC, RTD, mA, V, mV)
PC201	Process control card
RO206	6-channel relay output card
DI206	6-channel digital input card
RD233	3-channel Relay output and 3-channel digital input card
AO206	6-channel analog output card
IF232	RS-232 communication module for PR10 and PR20
IF485	RS-422/485 communication module for PR10 and PR20
IF232A	RS-232 communication module for PR30
IF485A	RS-422/485 communication module for PR30
PM201	90-250VAC 47-63Hz panel mount power supply board without power Switch for PR10 and PR20
PM202	90-250VAC 47-63Hz panel mount power supply board with power switch For PR10 and PR20
PM203	90-250VAC 47-63Hz portable power supply board with power switch for PR10 and PR20
PM211	11-36VDC panel mount power supply board without power switch for PR10 and PR20
PM212	11-36VDC panel mount power supply board with power switch for PR10 and PR20
PM213	11-36VDC portable power supply board with power switch for PR10 and PR20
PM301	90-250VAC 47-63Hz panel mount power supply board without power Switch for PR30
PM302	90-250VAC 47-63Hz panel mount power supply board with power switch For PR30
PM303	90-250VAC 47-63Hz portable power supply board with power switch for PR30
PM311	11-36VDC panel mount power supply board without power switch for PR30
PM312	11-36VDC panel mount power supply board with power switch for PR30
PM313	11-36VDC portable power supply board with power switch for PR30

Notes:

- The rear Slots of the recorder will only accept certain Input or output cards in any combination based on selected model.
- For example, PR10 has 4 empty slots. But only 3 slots can be used. In one slot, it needs 1 pc. of either a 3 or 6 channel analog input card. The other slot can be used as per the combination showed in the ordering code.
- The basic PC software is supplied free with the recorder. There is an additional charge for the extensive Data Acquisition Software supplied with communication of RS-232/422/485 or Ethernet.
- The Ordering Code for various standard model Recorders with an AC supply and without any additional options are as follows:

PR1003- 0A001000 PR2003- 0A001000 PR3006- 000A001000

1.8 Specifications

Power:

90-250VAC, 47-63Hz, 52VA, 26W maximum 11-36VDC, 26VA, 26W maximum

PR30:

90-250VAC, 47-63Hz, 110VA, 62W maximum 11-36VDC, 62VA, 62W maximum

Display:

PR10: LCD, 480 x 272 pixel resolution, 65K color PR20: LCD, 640 x 480 pixel resolution, 65K color PR30: LCD, 1024 x 768 pixel resolution, 65K color

Memory:

256MB storage memory on board

Process Control Card (PC201):

Please refer UMPRPID01 manual, Chapter 1.7, for the details

Analog Input Cards (AI20X):

Channels: AI203 ~ 3 channels, AI206 ~ 6 channels **Resolution:** 24 bits **Sampling Rate:** 10 times/ second

Maximum Rating: RTD input ±20V

T/C and Voltage input ± 65V

mA input ±10V

Temperature Effect: ±0.1uV ±15PPM of reading for all inputs except mA, ±30PPM of reading for mA input

Sensor Lead Resistance Effect: T/C: 0.32PPM of reading/ohm, 3-wire RTD: 2.6°C/ohm of resistance difference of two leads (Based on $^{\circ}C$ measurement temperature for PT100)

2-wire RTD: 2.6°C/ohm of resistance sum of two leads (Based on $^{\circ}C$ measurement temperature for PT100)

Burn-out Current: 10uA

Common Mode Rejection Ratio (CMRR): 120dB

Normal Mode Rejection Ratio (NMRR): 55dB

Isolation Breakdown Voltage between channels: 1500VAC min.

Sensor Break Detection:

Sensor opened for TC, RTD and mV inputs, below 1 mA for 4-20mA input, below 0.25V for 1-5V inputs, unavailable for other inputs

Sensor Break Responding Time: Within 1 seconds for TC, RTD and mV inputs, 0.1 second for 4-20 mA and 1-5V inputs

Characteristics:

Туре	Range	Accuracy at 25 °C	Input Impedance
J	-120 ~ 1000 °C (-184 ~ 1832 °F)	±1 °C	3.12MΩ
к	-200 ~ 1370 °C (-328 ~ 2498 °F)	±1 °C	3.12MΩ
Т	-250 ~ 400°C (-418 ~ 752°F)	±1 °C	3.12MΩ
E	-100 ~ 900 °C (-148 ~ 1652 °F)	±1 °C	3.12MΩ
В	0 ~ 1820 °C (32 ~ 3308 °F)	±2°C (200 ~ 1820 °C)	3.12MΩ
R	0 ~ 1768 °C (32 ~ 3214 °F)	±2 °C	3.12MΩ
S	0 ~ 1768 °C (32 ~ 3214 °F)	±2 °C	3.12MΩ
N	-250 ~ 1300 °C (-418 ~ 2372 °F)	±1 °C	3.12ΜΩ
L	-200 ~ 900 °C (-328 ~ 1652 °F)	±1 °C	3.12MΩ
U	-200 ~ 600°C (-328 ~ 1112 °F)	±1 °C	3.12MΩ
Р	0 ~ 1395 °C (32~2543 °F)	±1 °C	3.12MΩ
W5 or C	0 ~ 2315 °C (32 ~ 4199°F)	±1 °C	3.12MΩ
W3	0 ~ 2315°C (32 ~ 4199 °F)	±1 °C	3.12MΩ
LR	-200 ~ 800 °C (-328 ~ 1472 °F)	±1 °C	3.12MΩ
A1	0 ~ 2500 °C (-32 ~ 4532 °F)	±1 °C	3.12MΩ
A2	0 ~ 1800 °C (-32 ~ 3272 °F)	±1 °C	3.12MΩ
A3	0 ~ 1800 °C (-32 ~ 3272 °F)	±1 °C	3.12MΩ
М	-200 ~ 100 °C (-328 ~ 212 °F)	±1 °C	3.12MΩ
PT50 (α = 0.00385)	-200 ~ 850 °C (-328 ~ 1562 °F)	±0.4 °C	2.0ΚΩ
PT100 (α = 0.00385)	-200 ~ 850 °C (-328~ 1562 °F)	±0.4 °C	2.0ΚΩ
PT200 (α = 0.00385)	-200 ~ 850 °C (-328 ~ 1562 °F)	±0.4 °C	2.0ΚΩ
PT500 (α = 0.00385)	-200 ~ 850 °C (-328 ~ 1562 °F)	±0.4 °C	2.0ΚΩ
PT1000 (α = 0.00385)	-200 ~ 350 °C (-328 ~ 662 °F)	±0.4 °C	2.0ΚΩ

PT50 (α = 0.00391)	-200 ~ 850 °C (-328 ~ 1562 °F)	±0.4 °C	2.0ΚΩ
PT100 (α = 0.00391)	-200 ~ 850 °C (-328 ~ 1562 °F)	±0.4 °C	2.0ΚΩ
JPT50 (α = 0.003916)	-200 ~ 600 °C (-328 ~ 1112 °F)	±0.4 °C	2.0ΚΩ
JPT100 (α = 0.003916)	-200 ~ 600 °C (-328 ~ 1112 °F)	±0.4 °C	2.0ΚΩ
JPT200 (α = 0.003916)	-200 ~ 600 °C (-328 ~ 1112 °F)	±0.4 °C	2.0ΚΩ
JPT500 (α = 0.003916)	-200 ~ 600 °C (-328 ~ 1112 °F)	±0.4 °C	2.0ΚΩ
JPT1000 (α = 0.003916)	-200 ~350 °C (-328 ~ 662 °F)	±0.4 °C	2.0ΚΩ
Cu50 (α = 0.00426)	-50 ~ 200 °C (-58 ~392 °F)	±0.4 °C	2.0ΚΩ
Cu100 (α = 0.00426)	-50 ~ 200 °C (-58 ~392 °F)	±0.4 °C	2.0ΚΩ
Cu50 (α = 0.00428)	-180 ~ 200 °C (-292 ~392 °F)	±0.4 °C	2.0ΚΩ
Cu100 (α = 0.00428)	-180 ~ 200 °C (-292 ~392 °F)	±0.4 °C	2.0ΚΩ
Ni100 (α = 0.00617)	-60 ~ 180 °C (-76 ~356 °F)	±0.4 °C	2.0ΚΩ
Ni200 (α = 0.00617)	-60 ∼ 180 °C (-76 ~356 °F)	±0.4 °C	2.0ΚΩ
Ni500 (α = 0.00617)	-60 ∼ 180 °C (-76 ~356 °F)	±0.4 °C	2.0ΚΩ
Ni1000 (α = 0.00617)	-60 ∼ 180 °C (-76 ~356 °F)	±0.4 °C	2.0ΚΩ
Cu10 (α = 0.00427)	-200 ~ 260 °C (-328 ~500 °F)	±0.1 °C	2.0ΚΩ
±20mA	-26 ~ 26mA	±0.05%	75Ω
±60mV	-122 ~ 122mV	±0.05%	3.12MΩ
±200mV	-243 ~ 243mV	±0.05%	3.12MΩ
±1V	-1.58 ~ 1.58mV	±0.05%	3.12MΩ
±2V	-3.16 ~ 3.16mV	±0.05%	3.12MΩ
±6V	-6.32 ~ 6.32V	±0.05%	3.12MΩ
±20V	-25.3 ~ 25.3V	±0.05%	3.12MΩ
±50V	-50.6 ~ 50.6V	±0.05%	3.12MΩ
0.4 ~ 2V	-3.16 ~ 3.16V	±0.05%	3.12MΩ
1 ~ 5V	-6.32 ~ 6.32V	±0.05%	3.12MΩ

Digital Input Card (DI206):

Channels: 6 per card

Logic Low: -5V minimum, 0.8V maximum Logic High: 3.5V minimum, 24V maximum External pull-down Resistance: 1KΩ maximum External pull-up Resistance: 1.5MΩ minimum

Relay Output Card (RO206):

Channels: 6 per card Contact Form: N.O. & N.C. (form C) Relay Rating: 5A/240 VAC, life cycles 200,000 for resistive load

Analog Output Card (AO206):

Channels: 6 per card Output signal: 4-20mA, 0-20mA, 0-5V, 1-5V, 0-10V Resolution: 16 bits Accuracy: ±0.05% of Span ±0.0025% /°C Load Resistance: 0-500 ohms (current), 10K ohms minimum (voltage) Output Regulation: 0.01% for full load change Output Setting Time: 0.1 second (stable to 99.9%) Isolation Breakdown Voltage: 1500VAC at 50/60Hz for 1 minute Integral Linearity Error: ±0.005% of Span Temperature Effect: ±0.0025% of Span /°C

Note: there are DIP switches on the AO card and default is SET to Voltage output, For ma Output , SET 1 to 5 (ON), and 6 to 8 (OFF) . More details refer to Chapter 4.1.4

COMM Module (IF232 and IF485):

Interface: RS-232 (1 unit), RS-485 or RS-422 (up to 247 units) Protocol: Modbus Protocol RTU mode Address: 1-247 Baud Rate: 9.6 ~ 115.2 Kbits/sec. Measured data Bits: 7 or 8 bits Parity Bit: None, Even or Odd Stop Bit: 1 or 2 bits

Real-time Clock:

Item	Description
Make	Seiko Instruments
Model	MS621-FL11E
Rating	3V/4 mAH
Typical life time	10 yrs
Buffer period	6 months
Туре	Rechargeable
Accuracy	Maximum +/- 2 sec/day

Standard Ethernet Communication:

Protocol: Modbus TCP/IP, 10/100 Base T Ports: AUI (Attachment Unit Interface) and RJ-45, Auto- detect capability

Real time clock accuracy vs. temperature inside of housing

Temperature inside housing	typical error per month
10 ~ 40 °C	18 seconds
0 °C or 50 °C	52 seconds
-10°C or 60 °C	107 seconds

Environmental & Physical:

Operating Temperature: 0 ~ 50 °C Storage Temperature: -30 ~ 70 °C Humidity: 20 to 90% RH (non-condensing), maximum relative humidity 90% is for ambient temperature up to 38°C decreasing linearly to 50% relative humidity at 50°C Altitude: 2000 M maximum Insulation Resistance: 20 M ohms min. (at 500 VDC) Dielectric Strength: 2300VAC, 50/60 Hz for 1 minute between power terminal and earth Vibration Resistance: 10-55 Hz, 10m/ s² for 2 hours Shock Resistance: 30m/ s² (3g) for operation, 20g for transportation **Operation Position: no inclined restriction** Dimensions: Panel Mount style: 144(W) x 144(H) x 193mm (D) (for PR10/20) 288(W) x 288(H) x 194mm (D) (for PR30) Standard Panel Cutout: 137 x 137mm (for PR10/20) 281 x 281mm (for PR30)

Approval Standards:

Safety: UL61010C-1, CSA C22.2 No. 24-93 CE: EN61010-1 (IEC1010-1) over voltage category II, Pollution degree 2

Protective Class: IP 65 front panel for indoor use, IP 20 housing and terminals

EMC:

Emission: EN61326-1 (EN55022 class A, EN61000-3-2, EN61000-3-3)

Immunity: EN61326-1 (EN61000-4-2, EN61000-4-3, EN61000-4-4, EN61000-4-5, EN61000-4-6, EN61000-4-8, EN61000-4-11)

2. Installation and wiring

2.1 Unpacking

If any damage is found while unpacking, the user should contact the local representative at once. It is suggested that the special packaging is retained for possible future requirements.

2.2 Installation

Remove stains from this equipment using a soft, dry cloth. Do not use harsh chemicals, volatile solvents such as thinner or strong detergents to clean the equipment in order to avoid deformation.


The recorder is designed for indoor use and not in any hazardous area. It should be kept away from shock, vibration, and electromagnetic fields such as variable frequency drives, motors and transformers.

It is intended to operate under the following environmental conditions:


Pollution Degree Level II	IEC1010-1(EN61010-1)
Temperature	0~50 °C
Humidity	20 ~ 90 % RH (non-condensing)
Power	90 ~ 250 VAC, 50/60 Hz or 11-36VDC
Altitude	2000M maximum

2.3 Panel mounting style


PR10:








Panel Cut Out Dimensions




PR20:











Panel Cut Out Dimensions




PR30:


Front Side








Panel Cut Out Dimensions




Note:

- Do not over tighten mounting clamp screws that could result in distortion of the case.
- There is no mounting angle restriction.


Portable styles:




Bottom Side View of PR20 & PR10:




Front Side View of PR20 & PR10:




Bottom Side View of PR30




Front Side View of PR30:



Bottom Stand Clips:



Top Holding Handle :



2.4 Setup input and output

Analog input cards (part numbers AI206 and AI203)

Al206 and Al203 are analog input cards in 3 and 6 channels respectively. Each card includes universal inputs of TC (J, K, T, E, B, R, S, N, L, U, P, W5, W3, LR, A1, A2, A3, and M), RTD, mV, mA, V. The accepted input types and sensor range for each type are listed in clause 1.8 of chapter 1. Plug the card into the rear slot then power on. The recorder will automatically detect the card and display the specific input type, then show its location in a specific slot when the user is in Configuration Mode.

To select a specific input, please press menu and then the Config button to get into the configuration window. In the configuration window, press up/down and enter key to select AI to get into AI setting window. In the AI setting window, move the selected focus to the item "Type" under the node "Sensor", then press the enter key to select the desired sensor type. Press OK when finished. All other items are similar to set up. The item "Events" can be added to do further control.





Figure 2 - 15 (Al206)

Relay Output card (RO206) / 6 relay alarm card

The relay output card includes 6 relays rated 5 Amp/240 VAC each. Plug the card into a rear slot and power on the recorder. The recorder will automatically detect the card and display the output type and its location in a specific slot in **System Info** mode while doing the configuration.

To set up the relay output card, please press **menu** and then the **Config** button to get into the configuration window. In the configuration window, press up/down and enter key to select DO and to get into the DO setting window. In the DO setting window, the setup steps are similar to AI. The item "Reverse" is to reverse the output status.



Digital Input card (DI206)

This card includes 6 channels of event inputs. As above, plug the card into rear slot and power on the recorder. The recorder will automatically detect it, and then display the input type and its location in a specific slot in **System Info** mode while doing the configuration.

To set up the digital input card, please press **menu** and then the **Config** button to get into the configuration window. In the configuration window, press up/down and enter key to select DI and get into the DI setting window. In the DI setting window, the setup steps are similar to AI. The item "Type" is for the user to decide if this channel will have a logic level or Pulse Counter input. If you select Pulse Counter, the item "Frequency" will appear for you to select input frequency (100Hz,). The item "Events" can be added to do further control.



Combination Digital Input and Output card (RD233)

This card includes 3 relays rated 5 Amp/240VAC each and 3 Channels of Digital Inputs. As above, plug the card into rear slot and power on the recorder. The recorder will automatically detect it, and then display the input type and also a Relay. The first 3 combination are for relays (Terminal 1 to 9) and last 3 combination are for Digital inputs (Terminals 10 to 18). The setup is similar to relay output card and digital input card.



Analog output cards (AO206)


These cards are 6-channel current output cards. They are used to retransmit process values to other devices like meters, controllers, ect.

To set up the analog output card, please press the menu and then the Config button to get into the configuration window. In the configuration window, press the up/down and enter key to select AO. This will get you into the AO setting window. In the AO setting window, the setup steps are similar to AI. The item "Type" is to decide whether to output current or voltage. The item "Output" is to select the output range for current or voltage (0-10, 4-20mA, ect.). The item "Expression" is a math expression field where the user can input an expression to control the output value.



PID Control card (PC201)


Please refer manual UMPC201 for more information on the card.




- <u>Note 1:</u> The IO Cards should not be removed or Inserted to the PR when the Power is ON. This should be carried out in the Power OFF condition only.
- Note 2: In the PR30, the Analog Input card should be inserted in slots 1 to 8 only. It should not be inserted in slots 9 to 16.
- <u>Note 3:</u> The below pictures explain how to install a new AI card into a recorder slot:

Information regarding removing the IO Cards from PR. For removing the IO Card, First remove the metal screws then plastic screws, after that press the lock on the top and bottom of the Card and pull to remove it. Failing to do so will damage the IO Card. Please follow the below pictures for more information.

The Maximum Torque for the metal screw is 3Kg-cm (2.6in-lb) and the Maximum Torque for the plastic screw is 0.8Kgf-cm (.7in-lb).






- <u>Note 4:</u> For some industries who prefer/favour circular displays, PR30 can offer this unique feature and set the display speed for each page/circle in 30 minutes, 1, 2, 4, 8, 12 hours, 1, 2 days, or 1, 2, 4 weeks.
- <u>Note 5:</u> Calibrate: Sometimes the field calibration is required for high accuracy. In this case, a qualified engineer can do the necessary calibration.
- <u>Note 6:</u> For Thermocouple Inputs, a 1 hour warm up is necessary for initial set up.

Note 7: Circular Trends are only available for the PR30 mode.


2.5 Wiring of the cards

Miring Precautions


- 1. Care must be taken to ensure that the maximum voltage rating specified on the label is not exceeded.
- 2. For the panel-mount version, it is recommended that near an external fuse or an external switch rated at 2A/250 VAC should be used.
- 3. Beware not to over tighten the terminals screws. The torque should not exceed 0.4 N-m (3.6 Lb-in or 4.0 Kg F-cm).
- 4. With the exception of the thermocouple wires, all wires should be stranded copper conductor with maximum gauge of 18 AWG.
- 5. Connect a grounding conductor with 1.6mm diameter minimum to provide protective grounding prior to turning on the equipment.




Analog Input Card Al206




Analog Input Card Al203



Relay output card (RO206)



Digital input card (DI206)



Relay output and digital input card (RD233)

$$1 (A + mA, V)$$

$$2 (A + mA, V)$$

$$4 (A + mA, V)$$

$$5 (A + mA, V)$$

$$6 (A + mA, V)$$

$$8 (A + mA, V)$$

$$8 (A + mA, V)$$

$$9 (A + mA, V)$$

$$10 (A + mA, V)$$

$$11 (A - mA, V)$$

$$11 (A - mA, V)$$


$$12 (A + mA, V)$$

$$12 (A + mA, V)$$

$$13 (A + mA, V)$$


$$14 (A - mA,$$

Analog output card (AO206)




PID Control card (PC201)

2.6 RS-232, RS-422, and RS-485 wiring



TX1 TX2 Recorder RX1 RX2



2.7 External Memory Card:

There two types of external storage for the User. One is the SD card and other is USB memory. There are two slots for inserting USB memory, one in the front and other on the rear side of the recorder. If bigger capacity USB memory is required, the user may buy it locally. The SD card slot is in the front side. Please see the below figures for more information.



Note:

To read measured data and events on USB memory and SD card Memory, it is necessary to install either the free basic software or the Extensive Data Acquisition software on PC first.

3. BASIC FUNCTIONS OF RECORDERS

In this chapter we will be briefly explaining the functions that are available in the recorder.

3.1 Configuration

The configuration in the recorder follows a tree type layout. This makes it easy for users to go through the different sub menus easily and to not miss any setting.

Configurat	ion of mem 94%	SD 14:45:18 99% 11/07/14		
Configuration				
Save	⊂Channel AI DI Math			
Load	-DO -External -Display	▼		
Default	- Timer - Clock - Communication - Instrument	÷		
	-Password: ******* -Demo: Disable -Auto-Output - <mark>System Information</mark> -Calibrate	*		

3.2 Standard and Plus Version of Firmware

The standard version of firmware will have Input configuration and Math functions. It does not include External channels, Custom Edited Display, Batch, or FDA CFR part11 functions. However, the plus version includes all the above listed functions.

Math	I	Ма	th1	-	mem 27%	5D 78%	13:47:48 12/26/09
1 2 3 <mark>Sel</mark>	ect					×	
- Type: Mat - Log - DataTy	Math Disable Math Counter Totalizer				•		
Decima Range:		ок	Cance	⊇l			

Math: It includes Math, Counter & Totalizer.

Math Expression is keyed in an easy way.

AI7-AI1						
Source AI1	▲ Target	7	8	9	0	Clr
AI2 AI3 AI4 AI5	Source	4	5	6	· ·	BS
AI6 AI7 AI8		1	2	3	-	<
Operator SIN COS		,	*	/	+	>
EXP SQRT LN		()	~	o⁄o	End
LOG ABS POW			ок		Cance	el


3.3 Communication with Third Party Interfaces

The Recorder has the flexibility to communicate with Third party Interfaces via protocols such as Modbus TCP/IP or Serial connections as either a Modbus Master or Modbus Slave. The detailed settings related information can be found in Chapter 4, Configuration, and Section 4.5.

3.4 Information Accessibility through WEB

Web Server:

The Recorder Trend and Digital data can be viewed in any place in the world if we have Web Server connectivity. For this the Recorder should be connected to Internet with a fixed IP address provided by the Internet Service provider.



Email:


All Important Data events can be sent as an email. The detailed settings related information can be found in Chapter 4, Configuration, Section 4.5.

3.5 Handwriting Messages on Trend Screens


Handwriting Messages on Trend Screens is very handy for process associates to highlight important events.

The User can write handwritten messages using a stylus on Historical Trend screens. This is shown in the below picture.


When the User navigates through $(Menu) - \rightarrow History \rightarrow Page 1$, as shown in the below screen.




If the User wants to write a message, they can press the pen symbol as shown in the red square in the screen below




Then using the stylus, the User can write any message in Historical Trend Pages as shown below.




If the User wants to change the width of the written message, he/she can choose the width of pen as shown in the screen below. The menu to change the width is shown by the arrow pointing to the red box.




If the User wants to change color of the pen, he/she can change it by pressing the menu shown in the red box in the picture below.




If the User wants to erase part of a message, he/she can do this by pressing the menu (shown in the red box in the picture below), and erase part of the message.




If the User wants to undo part of a message, he/she can do this by pressing the undo symbol (shown in the red box in the picture below). This will undo the last part of the message.



If the User wants to delete the written message, he/she can this do by pressing the delete symbol (shown in the red box in the picture below), and this will delete the written message.




If the User wants to save the written message, he/she can do this by pressing the "save" symbol (shown in the red box in the picture below). This will save the written message.



3.6 Custom Edited Display Screens

(We call it a Custom Page on the device and Custom Page Editor on PC software)

In Plus versions, the PC software Panel Studio allows users to have custom edited displays linked with Analog and Digital Tags.



3.7 Analog Input Log Speed Flexibility

The Analog input can be logged at various speeds such as 100ms, 1, 2, 5, 10, 20, 50 Dot/sec and 1 or 2 dot/min. The User has a lot of flexibility in logging speeds.

3.8 High Speed Input

The Digital input can accessed as normal Logic or a High frequency pulse.

3.9 System Clock Synchronization via Internet

The Recorder System clock can be synchronized via internet and Summer Saving Time can be defined. The detailed settings related information can be found in Chapter 4, Configuration, Section 4.4.

3.10 Increased Security in Password configuration

The password can be configured as normal or CFR-21. For normal, there is only one password defined but for CFR-21 three 9 levels of password definition. The related settings information can be found in Chapter 4, Configuration, Section 4.7.

3.11 Auto Output to Printer

The daily or shift reports data can be printed automatically by a Printer. The related settings information can be found in Chapter 4, Configuration, Section 4.9.

3.12 External Channels

Besides AI and DI inputs, the Recorders can accept inputs through Modbus communication. The PR10, PR20, and PR30 can have a maximum of up to 24, 48 and 96 channels respectively. The related settings information can be found in Chapter 4, Configuration, Section 4.1.6.

3.13 Batch

Using this function, the recorded data can be stored in batches per shift. This makes it easy for the production personnel, and for quality and quantity management.

3.14 FDA 21 CFR PART 11

This feature is meant to comply with U.S. Food and Drug Administration with human health concern. When this feature is enabled, the recorded data cannot be manipulated.

4. CONFIGURATION

Press ("Menu"), then the "More" soft button to enter Configuration mode. A vertical list appears with a provision to configure Channel, Tools, Message, Display, Instrument, Security, Auto-Output, Demo, and system Information. In addition, the Save, Load, Default and Home soft buttons also appear.

Configurat	ion of the second se	SD 14:45:18 99% 11/07/14		
Configuration				
Save	⊂Channel -AI -DI -Math			
Load	-DO -External -Display	•		
Default	-Timer -Clock -Communication -Instrument	ب		
	-Password: ******* -Demo: Disable			
	- Auto-Output - <mark>System Information </mark> Calibrate	*		

Soft buttons



Various options are available to enter into configuration mode

Option-1: Select the mode by pressing up & down directional keys, then press "Enter" key

Option-2: Select the required mode directly with a touch, then press "Enter" key

Option-3: Select the required mode by pressing the mode two times quickly, it is same as a double click from a mouse

Save: Save configuration from the recorder to a USB Stick or an SD Card. To read the configuration from a USB Stick for the first time or any time the configuration has been changed, it is important to press the "Save" soft button to save configuration changes to the USB Stick or SD Card beforehand.

Load: Load configuration from a USB stick or SD Card to the recorder.

Default: If the configuration is set incorrectly, "Default" is a useful key to recall the default settings for the analog input card inserted into rear expansion slot.

Home: Returns the User to the home page.

4.1 Channel


Path: (Menu)-More-Config-Channel

- AI - DI - Math - AO - DO - External

This section is to configure different type of channels. Analog Input (AI), Digital Input (DI), Math, Analog Output (AO), Digital Output and External device channels.

4.1.1 Analog Input

After entering the Configuration mode, in "Channel", select "AI", then Press the "Enter" key to get into Analog Input Channel mode. It displays the Analog input AI1 as the first analog input channel configuration page. Press directional keys $\langle \rangle$ at the bottom to select other channels. Press directional keys $\uparrow \downarrow$ on the right hand side to select the column. After completing Configuration, press "Back" soft button, then press "Home" soft button to return to main display. All configurations will be saved automatically.



Copy: For example, to copy the channel configuration from channel 1 to channel 2, select the source channel, in this case AI1 (or whatever the channel is named), press on "Copy" button. Now, a "Paste" button will get enabled, go to target channel, say channel 2, and then press on "Paste" button.

Name: Enables the User to define the name for each channel with a maximum of 18 characters.

Select "Name", then Press "Enter", soft button, a keyboard with several keys appear. Press "Shift" to select special characters. Press "Caps" to select capital letters. Press soft key "OK" after entering a new channel name.

Desc: The description about a specific channel on the display.

Type: Option available to enable or disable the channel from selection

Filter: It is to reduce the noise of input signal before sampling. It is possible to select range from 1 to 16 sec. It is a soft filter available to reduce fast variation of analog inputs. It gives a moving average value. For example, if the filter value is set as 5 sec for AI1, it means all the samples collected in the last 5 sec shall be averaged, and the value is available to record as per Log method.

Moving Average: This takes Average of the values recorded in (entered) Buffer Time.

Difference: It is current value and last value difference. Allowance will define difference allowance. Holding time minimum is 100ms.

Example:

If current value 1000 and last value is 890, when you check the difference is 110. Since this difference is greater than 100 during holding time. This value will be recorded. If the current value is 900, since it less than 100 during the holding time , this value will not be recorded. So the holding time will define the duration.

Log:

Data Type: 2 byte

2 byte range: -32767 to +32767

Trigger: Two options are available

- a) Disable: Select disable while the recording of a specific channel is not required at this time
- b) Enable: Select Enable while the recording of a specific channel is required at this time

Method: This is the method of logging measured data. Select the column and press "enter". Then choose the Log method of Instant, Average, Minimum or Maximum data.

Instant: logging the last measured data at the sampling interval Average: logging the averaged measured data at the sampling interval Minimum: logging the minimum measured data at the sampling interval

Maximum: logging the maximum measured data at the sampling interval

Speed: It is the logging speed (recording speed) of measured data. Select Log Speed column, then choose one of the following

100ms/Dot
1 Sec/Dot
2 Sec/Dot
5 Sec/Dot
10 Sec/Dot
20 Sec/Dot
30 Sec/Dot
1 Min/Dot
2 Min/Dot
10 Sec/Dot 20 Sec/Dot 30 Sec/Dot 1 Min/Dot

(Auto)Set Jobs under Events

Set Job		×
No Action		
Job Items:	Target	
No Action Send Email Pause Start Sound Buzzer Dump Data DO Latch On DO Latch Off DO Process Enable Timer Disable Timer Preset Totalizer Reset Totalizer		СК
		Cancel

Sensor

- Type: Thermocouple K Type, °C
- -Unit: °C
- Range: -200.0~1370.0

Type: Select the sensor input type for the Channel.

Select
Thermocouple K Type
Thermocouple J Type Thermocouple K Type Thermocouple E Type Thermocouple B Type Thermocouple B Type Thermocouple S Type Thermocouple N Type Thermocouple L Type Thermocouple L Type Thermocouple TC1 Type
RTD PT100 Type
OK Cancel
RTD JPT100 Type RTD RTD1 Type Milli-Volts Volts

Milli Volts Current Unit: The engineering unit of input.


Range: Select based on Sensor type

Select	
-200.0~1370	0.0
-200~1370 -200.0~1370	
	Select
Sensor	0~1000
- <mark>Type: Milli-Volts</mark> Unit: mV Range: 0~1000	0~60 0~1000 -60~60

	Select
	0~5
Sensor	0~10 0~5
- <mark>Type: Volts</mark> Unit: V	1~5 -2~2
Range: 0~5	-20~20

	Select	
- Sensor - <mark>Type: Current</mark> - Unit: mA - Range: 4~20	4~20 0~20 4~20 -20~20	
™Range: 4~20	-20~20	

Scale: Appears only for linear inputs Ex: mV, Voltage, current etc..



Offset: It is offset value to correct the sensor error.

Gain: It is a multiplier to correct the sensor error. The correct value = (the process value x gain) + offset

Events

Events are frequently used for Alarm purposes. Events can also be used for digital outputs (DO), Timer, Totalizer, Counter or Report.

Maximum five events are possible to set for each Analog Input Press "Add" to add new event Press "Remove" to remove selected event

Events

--Add --Remove --1 --Type: H --SetPoint: 776.0 --Log: Log Alarm --Job1: No Action --Job2: No Action --Hysteresis: 0.0

Type: There are various types of H, L, HH, LL, Dev+, Dev-, and Error to be selected for a job

or Alarm purpose

H: High limit. When the process is over high limit, the alarm or job is actuated.

L: Low limit. Any the process is lower than low limit, the alarm or job is actuated

HH: High high limit, to set up another limit higher than high limit for double warning.

LL: Low low limit, to set up another limit lower than low limit for double warning.

Dev+: Trigger event on positive deviation of process value. The job or alarm is activated when process value is deviated by greater than the setpoint+the process value.

For example: Set point =10 At 10.00.01 Hrs, Tag1=40 At 10.00.02 Hrs, Tag1 = 51 Then, job or alarm is activated

Dev-: Trigger event on negative deviation of process value .The job or alarm is activated when the process value is deviated by less than the set point-the process value.

For ex: Set point =10 At 10.00.01 Hrs, Tag1=40 At 10.00.02 Hrs, Tag1 = 29 Then, job or alarm is activated.

Error: On channel error, an alarm or job is activated

Setpoint: To set up the process value for actuating Job1 and /or Job2

Alarm

Log Alarm: Record alarms

Log Alarm (Auto Ack): Record alarms and acknowledge automatically

Log Event: Record events

Job1, Job2: When an event occurs, the task to be performed is called the job. A typical example is to trigger **an alarm buzzer** in the event of a high temperature. Each pen can accept five different types of events (or alarms) and each event can create two jobs. Please note that a job under Event is different from a job created by pressing the **Operate** key. The former is actuated by an event, and the latter is actuated by manual control, no event necessary.

Note: Please refer to the section "Jobs" for full details about various jobs available


Hysteresis: To avoid it been activated too often, the Log Alarm or relay can set for no reaction. Hysteresis value can be defined for the event trigger set point.

Holding time: here refers to, suppose the set point is reached, but you want to wait for some time to activate that action. This time is holding time. In process sometimes SP is reached but it will go down immediately, that might due to process instability. To counter this, we have given an holding time, to see that PV stays at above that SP more than the holding time and then we activate action for that event

Example1

If the temperature is increased to more than 120 ^oC, log alarm and switch on digital output 1. When the temperature is decreased to less than 80 ^oC, log the alarm and switch off the digital output1.

Setting of events for the analog input in the channel configuration is as follows.



4.1.2 Digital Input

Path: (Menu)-Config-DI

After entering the Configuration mode, in the Channel, select DI then Press the "Enter" soft button to get into Digital Input Channel configuration page.

			DI					
1	2	3	4					
Na	Name: DI1							
De	Desc: Tank level high							
Тγ	Type: Logic Level							
Eve	Events							
Add								
F	۱em	ove						

Name: Define the name for the Digital Input Channel. A maximum of 18 characters is allowed for the name.

Description: Define detail description for the channel.

Type: Logic Level

Logic Level: This selection activates digital logic, which is either one or zero with low frequency which is less than 1Hz, such as an external relay.

Pulse Counter: With this selection, we can feed high speed inputs (high Frequency, up to 100Hz)

Select Logic Level and press "Enter" key

Logic Level	
Logic Level	
Pulse Counter	

Events: A maximum of 2 events are supported for every digital Input channel. A maximum of two jobs can be configured for each event.

*Note: Events will not appear if Logic Level selected as Pulse Counter

Add: Press "Add" to add events to the Digital Input

Remove: Press "Remove" to remove events from the Digital Input

Type: Select Low, L or High, H


Job1, Job2: To configure a Job, select Job1, the press the Enter button. It will show a list of all the available jobs. Select the required Job.

Note: Number of digital inputs shown one t DI screen depends on number of Digital input cards inserted in the paperless recorder.

Sample applications of Digital input ...

After pressing a "Start" switch, latch ON Digital Ouput1 After pressing a "Pause" switch, latch Off Digital Output1 Start Timer, Stop Timer Reset Totalizer, Reset Counter Reset MaxMinAve values of all the channels etc..

It is possible to display Digital input status via status bar on any page in the paperless recorder. If digital input is not enabled, it shows as "Low". Presence of an enabled digital input shall be shown as "High". See the picture below. To configure status bar, refer section "**Display**"



Digital Input status can also monitored from the (Menu). Press "Status" and then select "DI", it will show the Digital Input Status as follows.

M	lenu	Status				DI		mem 84%	12:49:57 02/17/13
DI	DO	A0	Counter	Totalize	er				
No	Name	е		Value		Desc			
1	DI1			Hi			switch high		
2	DI2			Low		Tank2 Level	Switch High		
				•					
						•			
]		

4.1.3 Math Channel

Maximum no. of Math channels in various PR series Recorders are as follows

PR Recorder	PR10	PR20	PR30
Maximum Math	15	40	60
Channels			

Path: (Menu)-More-Config-Math

After entering the Configuration mode, in Channel, select Math, then Press the "Enter" soft button to get into Math Channel configuration page.

			Math							
1	1 2 3 4 5 6 7 8 9									
Nar	ne: M	1ath1								
Des	sc: Ma	ath ch	nannel	<u>i</u>						
- Typ	be: Ma	ath								
Log	ļ									
C)ataT	ype:	4 Byte	9						
	Valu	ue Ra	nge: ·	-3.4E-	+38 ^	- 3.4E	+38			
۲ ۱	rigge	e <mark>r:</mark> En	able							
-N	/letho	d: In	stant							
_s	Speed	l: 100	ms/D	ot						
Exp	pressi	on: (/	AI1+A	AI2)/2	2					
Sca	Scale									
-Unit:										
- Transformation: Disable										
-Decimal: 1										
F	Range	e: -21	47483	864.8	~ 214	7483	64.7			

Name: Define the name of the Math channel

Desc: Define the detail description for the channel name

Type: Specify either Math, Totalizer or Counter

Note: Based on selection at "Type", configuration details will be changed. For ex: Type=Math has different configuration details compared with Type = Totalizer or Type = Counter

Log data type, Trigger, Method, Speed: Same as Analog Input

Press **Back** key and then press "**Home**" soft button go to Real time display and memorize the Math settings.


(AI1+AI2)/2						
Source:		7	8	9		
Ext53	Target	'	8	9	0	Clr
Ext54	Target					
Ext55	Source	4	5	6		BS
Ext56] 4	5	0	·	5
Ext57 Ext58		1				
Ext59		1	2	3		<
Ext60		1	Z	3	-	<
Operator:		1	*	,	+	>
SIN	▲	1		/	+	>
COS						
EXP			\		04	End
SQRT		- ()		%	End
LN						
LOG						
ABS			ОК		Cance	el
POW	•					

Enter Expression column, it appears Source, Operator and a keyboard.

The Source covers all available Analog inputs, Digital Inputs, Math inputs, external channels.

The Operators are mathematical expressions described below.

Use Source, Operator and keyboard to define the Math equation.



Transformation: Select disable, value or Math channel. This function mainly used to display process values obtained from Non-linearization table

Table: Select disable, value or Math channel

Maximum 64 rows can be entered in the Transformation table

Ex: A chemical tank has a non-linear shape. The level is 0 to 1400 cms. The Recorder should display 0 to 170 Tons as per following table

nsformation								
Add	No 1 2	Input 0 200		Output 0 10			Mode	
Delete	2 3 4 5	400 600 800		30 80 130				
	6 7 8	1000 1200 1400		150 160 170				
Сору	ļ							
							ب	
	J		ОК		Cancel]	

Add: Press "Add" soft button to add a new row into the Transformation table

Delete: Press "Delete" soft button to delete existing row from the Transformation table

Copy: Press to copy existing row in the Transformation table to create a duplicate entry

Mode: Press to toggle between Input and Output entries in the Transformation table

Up & Down: To navigate among rows in the Transformation table

4.1.3.1 Math Expression

Expressions	Mathematics Functions
+	Addition
-	Subtraction
*	Multiplication
/	Division
SIN(x)	sin(x)
COS(x)	cos(x)
EXP(x)	e ^x
SQRT(x)	Square root of x
LN(x)	log _e (x)
LOG(x)	log ₁₀ (x)
ABS(x)	Absolute of x
POW (x,y)	x ^y
ROUND(x)	The closest integral number to x
HI(x,y)	The bigger value between x and y
INV(x)	1/x
TG(x)	tan(x)
CTG(x)	1/tan(x)
ASIN(x)	Sin ⁻¹ (x)
ACOS(x)	Cos ⁻¹ (x)
ATG(x)	Tan⁻¹(x)
х%у	Remainder of x/y
х^у	x ^y

4.1.3.2 Math Eample-1

Relative Humidity – PR20 Math application

*How to Calculate Relative Humidity - Theory

Requirement: Two Analog Inputs, Type: RTD Al1: To measure dry bulb temperature Al2: To measure wet bulb temperature

First calculate the saturation vapor pressure (E) for both the dry-bulb (Td) and wetbulb (Tw) temperatures using the following equations:

Ew = 0.61078*EXP((17.269*Tw)/(Tw+237.3))*(Td-Tw) Ed = 0.61078*EXP((17.269*Td)/(Td+237.3))*(Td-Tw)

In the above equations the temperatures units are Celsius and the saturation vapor pressure units are millibars. The function "EXP" is the exponential and not raising something to an exponent.

Then calculate actual vapor pressure (Ea) using the following equation: Ea = Ew-0.63*(Td-Tw)

Relative Humidity is then calculated using the following equation: RH = (Ea/Ed)*100 The units of relative humidity are in percent.

Here is an example of the using the equations:

Assume that your dry-bulb temperature (Td) = 40 C and your wet-bulb temperature (Tw) = 30 C.

```
Ew = 0.61078*EXP ((17.269*Tw)/ (Tw+237.3))*(Td-Tw)
Ew = 0.61078*EXP ((17.269*30)/ (30+237.3))*(40-30)
Ew = 42.4262 millibars
```

```
Ed = 0.61078*EXP ((17.269*Td)/ (Td +237.3))*(Td-Tw)
Ed = 0.61078*EXP ((17.269 * 40)/ (40+237.3))*(40-30)
Ed = 73.7416 millibars
```

```
Ea = Ew-0.63*(Td-Tw)
Ea = 42.4262 - 0.63*(40-30)
Ea = 36.1262 millibars
```

```
RH = (Ea/Ed)*100
RH = (36.1262/73.7416)*100
RH = 48.99 %
```

* End of Theory

5 Math channels are required to calculate one RH. Td = AI1, analog input for dry bulb temperature (PT100) Tw =AI2, analog input for wet bulb temperature (PT100)

```
Math1 = EXP ((17.269*AI1)/ (AI1+237.3))
Math2 = Ed1 = 0.61078*Math1*(AI1-AI2)
```

```
Math3 = EXP ((17.269*AI2)/ (AI2+237.3))
Math4 = Ew1 = 0.61078*Math3*(AI1-AI2)
```

```
Ea = Ew - 0.63 * (Td - Tw)
Math5= RH1 = ((Math4-0.63*(AI1-AI2))/Math2)*100
```

```
Name: Math1

Desc: Math Channel 1

Type: Expression

Indext Constant of the second se
```

```
Name: Math1
Desc:
Type: Math
Log
DataType: 4 Byte
Value Range: -3.4E+38 ~ 3.4E+38
Trigger: by Time
Method: Instant
Speed: 1 Sec/Dot
Expression: EXP((17.269*AI1)/(AI1+273.3))
```

```
Name: Math2
Desc:
Type: Math
Log
DataType: 4 Byte
Value Range: -3.4E+38 ~ 3.4E+38
Trigger: by Time
Method: Instant
Speed: 1 Sec/Dot
```

Name: Math3
Desc:
Type: Math
Log
DataType: 4 Byte
Value Range: -3.4E+38 ~ 3.4E+38
Trigger: by Time
Method: Instant
Speed: 1 Sec/Dot

Name: Math4
Desc:
Type: Math
Log
-DataType: 4 Byte
Value Range: -3.4E+38 ~ 3.4E+38
Trigger: by Time
-Method: Instant
Speed: 1 Sec/Dot
Expression: 0.61078*Math3*(AI1-AI2)
-

Name: Math5
-Desc:
Type: Math
Log
-DataType: 4 Byte
Value Range: -3.4E+38 ~ 3.4E+38
-Trigger: by Time
-Method: Instant
-Speed: 1 Sec/Dot
Expression: ((Math4-0.63*(AI1-AI2))/Math2)*100

Now, in Math5, you will get Relative humidity in %

Five events are supported for every Math channel and two jobs are available in every event, the same as the Analog input channel.

Math channels are virtual channels. They contain measured values based on equations. These values can be recorded similar to physically connected Analog inputs and display digital values, trends, bar graphs etc.

4.1.3.3 Counter

Path: (Menu)-More-Config/Math

Select *Type* = *Counter*

			Math	1			
1	2	3	4	5	6	7	8
Na	me: C	:ount	:e r 6				
De	sc: Co	ounte	er 6				
- Typ	be: Co	ounte	er				
Loç	J						
C	DataT	ype:	4 Byt	e			
	Valu	ue Ra	ange:	-3.4E	+38 ~	~ 3.4E	-+38
٦	Frigge	er: Ei	hable				
N	4ethc	d: Ir	nstant				
<u> </u>	Speed	l: 100	Oms/E	ot			
-Cou	unter						
μ	-Unit:						
Preset: 0							
Eve	ents						
/	٩dd						
F	emo	ve					

Press directional keys $\langle \ \rangle$ at the bottom to select one of the Math channel for the Counter operation.

Name: Defines the name of counter, max. 18 characters allowed

Desc: Defines the description for a specific counter on the display

Type: Select Counter

Counter

Unit: Defines the unit of counter

Preset: Defines the preset value for the counter.

Event: Defines the type, Set point, Log, Job1 or Job2 & Hysteresis

Type: Select one of the options: H, L, HH, LL, Dev+, Dev-, Error

Set point: Defines the set point trigger of Counter value to initiate Jobs and/or Log alarms

Log: Select Log Alarm, Log Alarm (Auto Ack.), or Log Event

Job1, Job2: various jobs can be assigned, 2 jobs for each counter

Hysteresis: To avoid jobs have been activated too often, it can set for no reaction.

Hysteresis value can be defined for the event trigger set point

4.1.3.4 Counter Example-1

The operator wishes to know the number of occurrences of an event in a day. Let's say the pressure switch in DI1 goes logic high

Digital input1 is used for a Pressure switch. High signal indicates High pressure, Low signal indicates normal pressure

DI						
1 2						
Name: DI1						
Desc: Pressure Switch						
Events						
Add						
Remove						
·····1						
Type: H						
Log: No Action						
Job1: Inc Counter_Counter1						
Job2: No Action						
Timer						
1 2 3 4 5 6 7						
Type: Daily						
-Action: Enable						
Time						
-Hour: 23						
-Min: 59						
Sec: 1						
Job1: Log Report_Counter1						
Job2: Reset Counter_Counter1						

(Reset Counter1 historical data in order to log new data for the next day)

Archive historical data by pressing the following.

(Menu)-Event-Report, Select Daily in the Mode

If values meet the following conditions, recorder will change notation from traditional to scientific

- a. the value is more than 10^5 or less than $1/(10^5)$
- b. the value digit-length in display exceeds the allowed range

Ex: Up to 5 digits, counter displays value directly, let's say 0-99999. 100000 will be shown as 1E5, which means 5 zero's after 1 4294967295 will be shown as 4.29497E9 etc.

4.1.3.5 Totalizer

In our new generation Recorder, the Totalizer is a part of Math channels.

Configuration Path: (Menu)-More-Config-Math

Select *Type* = *Totalizer*

	Math							
1	2	3	4	5	6	7	8	
De	Name: Totalizer6 - Desc: Totalizer 6 - Type: Totalizer							
-Lo	-Log -DataType: 4 Byte -Value Range: -3.4E+38 ~ 3.4E+38 -Trigger: Enable -Method: Instant							
	Speed: 100ms/Dot Totalizer Input: AI Source: AI1 Action: Disable Decimal: 0 Period: Sec							

Press directional keys $\langle \rangle$ at the bottom to select from available Totalizers

Name: Defines the name of the Totalizer, Maximum 18 characters allowed

Desc: Defines the description for a specific Totalizer on the display

Type: Select "Totalizer"


Log: Same as Analog input configuration

Totalizer:

Input: Analog Input (AI) or Pulse Counter (DI)

Source: Select the source for the Totalizer from Analog input/Math/Counter/Totalizer

Action: Disables or enables the Totalizer



Decimal: Defines the decimal point for the Totalizer

Period: Selects if seconds, minutes or hours are used for the Totalizer

Unit: Defines the unit of totalizing

Preset: Defines the preset value for the Totalizer.

Low Cut: Defines the Low Cut for the Totalizer.

For ex: If 0.0 is set as Low cut, then, if source channel AI1 is less than 0.0, the Totalizer value will not go to negative.

- **Event:** Total 5 events are supported for each Math channel. Defines the type, Set point, Log, Job1 or Job2 & Hysteresis
- Type: Select one of options, H, L, HH, LL, Dev+, Dev-, Error
- Set point: Defines the set point trigger of Totalizer value to initiate Jobs and/or Log alarms
- Log: User can select one of Log Alarm, Log Alarm (Auto Ack.), or Log Event
- Job1, Job2: various jobs can be configured, 2 jobs for each Totalizer
- **Hysteresis**: To avoid jobs from being activated too often, the hysteresis can set to avoid nuisance tripping. Hysteresis values can be defined for the event trigger set point

4.1.3.6 Totalizer Example-1

Water flow rate is in M³/Sec. The operator wants to know about total water discharged and wants this information in daily, weekly and monthly reports

-Name: Totalizer1 -Desc: -Type: Totalizer -Log -DataType: 4 Byte -Value Range: -3.4E+38 ~ 3.4E+38 -Method: Instant -Speed: 1 Sec/Dot

Timer							
1	2	3	4	5	6	7	
Тγ	Type: Daily						
Act	tion: E	Enable	е				
- Tin	Time						
F	Hour:	23					
-Min: 59							
Sec: 1							
Job1: Log Report_Totalizer1							
Job)2: Re	eset T	otaliz	zer_To	otaliz	er1	


Reset Totalizer1 historical data in order to log new data for the next day

Archive historical data by pressing the following.

Path: (Menu)-Event-Report Select **Daily** in the **Mode** to see reports on daily basis. To navigate to another day, press on Left and right arrows below the **Mode** button. Select **Weekly** in the **Mode** to see weekly reports, or select **Monthly** on the **Mode** to see Monthly reports.

4.1.4 Analog Output

First check the AO card setting , there are DIP switches on the card and default is SET to Voltage output. For ma Output , SET 1 to 5 (ON), and 6 to 8 (OFF). Below picture explains ,



After entering the Configuration screen, in the Channel section, select AO, then Press the "Enter" soft button to get into Analog Output Channel configuration page.

		AO				A01	- ()	mem 🔰 81%
1	2	3	4	5	6			
- Ty - Ou	tput:	iurren 4-20i sion: 4	mΑ	-4)*(/	AI1-(-	120))/(1000-(-1	120))	

Desc: Define detail description for the channel name

Type: Current, Voltage

Output: Select either disable, 0 to 20mA , 4-20mA, 0-5V, 1-5V, 0-10VDC

Expression: This is similar to Math channel.

4-20ma output: For Retransmiting of AI1 using 4-20ma output,

Expression: 4+(20-4)*(AI1-(-120))/(1000-(-120))

Output Value =

Min ma + [(Max ma - Min ma) * (Al1- Min range of Al1)] / (Max range of Al1 - Min range of Al1)

4.1.5 Digital Output

DO		D01	mem 04:10:21 81% 02/17/13
1 2 Desc: Reverse: Disable			
	Сору		Back

Desc: Define detail description for the channel name

Reverse: Enable this if Reverse operation is required for the Digital Output.

For ex: If reverse is disabled, the relay output is Normally Open (NO). In case if you need to have a Normally Closed (NC) relay at Recorder Power ON, then enable "Reverse" for the selected Digital Output. The Relay output shall be normally closed.

4.1.6 External

This is to access data from the external devices.

Maximum no. of external channels in various PR series Recorders are as follows

PR Recorder	PR10	PR20	PR30
Maximum External	24	48	96
Channels			

All the properties are similar to Analog Input channel.

More details about external channels are available at section "Communication"

	External								Ext1					mem 37%	2:14:35 10/21/13	
1	2	3	4	5	6	7	8	9	10	11	12	13	14			
De Tyr Loç C 1 N N S Mo E	be: Er DataT Vali Vali Frigge Metho Speec dbus DataT	able ype: ue Ra er: En od: In l: 100 Regis	2 Byta ange: able stant Ims/D ster V 2 Byta	-3276 ot alue(f		onvei		+SI	•		•	•	•	<u> </u>		▲ ▼ ↓
-Formula: ((MV-RL)/(RH-RL))*(SH-SL)+SL -Range -Low(RL): 0.0 -High(RH): 65535.0																

Please refer section "Communication" for examples of external channels

4.1.7 Jobs

Various types of jobs can be selected as follows.

No Action: Do nothing

Send Email: Send Email directly from Recorder

Pause: Stop logging data.

Start: Start logging data.

Sound Buzzer: Sound the buzzer. It stops once any key is pressed.

Dump Data: To dump data from internal memory to external memory.

DO Latch On: Set digital output / relay on, and then select Target, let's say from one of DO 1 to DO 6. The relay is latched when it is activated.

DO Latch Off: Set digital output / relay off, and then select Target, let's say from one of DO 1 to DO 6. The relay is un-latched when it is activated.

DO Process: Set digital output / relay on for process high or low, and then select the target, let's say from 1 of DO 1 to DO 6. The relay is not going to be latched when it is activated.

Enable Timer: Start the timer, and then select Target timers

Disable Timer: Stop the timer, and then select Target from Timers

Preset Totalizer: set a preset value to the target Totalizer.

Reset Totalizer: Reset Totalizer to zero. Select a single Target Totalizer or All totalizers

Enable Totalizer: Starts the Totalizer. Select a single Target Totalizer or All totalizers

Disable Totalizer: Stops the Totalizer. Select a single Target Totalizer or All totalizers

Preset Counter: set a preset value to the target counter.

Reset Counter: Resets the counter to zero. Select a single Target counter or all counters

Inc Counter: Increases the counter by 1. Select a Target counter or all counters

Dec Counter: Decrease the counter by 1. Select a Target counter or all counters

- Log Report: Make a report for Counter, Totalizer, Analog inputs (Min/Max/Avg), Math (Min/Max/Avg), All Counters, All Totalizers, and All Channels (Min/Max/Avg). Choose this column, and the report will be presented as described in section "Reports".
- **Reset MinMaxAve**: In the Report function, after logging the Min/Max/Avg data of Al and Math channels for one day for example, this will reset historical data in order to log new data for the next day. It is also possible to reset the Min/Max/Avg for "All Channels" at one step.
- **Print**: If a printer is connected to the Paperless Recorder via the USB port or Ethernet, the following print jobs can be triggered from "events"

Print Historical data Print Event List Print Report List Print Snapshot

The time period of Print depends on the configuration available at (Menu)-More-Config-Auto-Output

Configurat	ion of mem 94%	SD 14:45:18 99% 11/07/14					
	Configuration						
Save	Channel -AI -DI -Math						
Load	-DO -External -Display	▼					
Default	- Timer - Clock - Communication - Instrument	4					
	-Password: ******** -Demo: Disable - Auto-Output - <mark>System Information</mark> - Calibrate	*					

Auto-Output						
Auto-Output						
Setup Printer						
-Historical Data						
-Period: Last Hours						
Hours: 1						
Interval: 1 Sec						
Report Data						
-Mode: List						

Note: Please refer section "Auto Output" for more details about options available

- **OutPut Historical Data:** This action will generate a historical data output in the form of excel sheets on external storage. Output is in the form of .CSV files. It will contain also contain event reports.
- **Copy Value and Paste Value:** This used for retransmission of Analog inputs using external (communication) Analog output channels. Since we have limitation of Analog outputs on the Recorder. This external channels can be utilized by using the copy value and paste value. You can do this by using event or timer when job 1 is copy value, job2 will be paste value.
- **Dump data:** This action will dump the historical data on to the SD. this data format can be only read by our Historical viewer software. it is not in excel format as we had in Output historical data.

Note:

In any mode, the sampling rate of the recorder is fixed at 100 milli seconds, i.e. 10 samples are collected per second. If the logging speed is set at 1 second in Instant mode, the recorder logs the last of ten measured data values. For the same speed in Average mode, the recorder logs using the average of the Ten measured data values. For the same speed in the Maximum or Minimum mode, then the recorder logs using the maximum or minimum of the Ten measured data values.

Sampling	Logging (historical trend)	Display (real time)
Instant	the last of 10 points of data	last of 10 points of data
Averaged	the average of 10 points of data	last of 10 points of data
Maximum	the maximum of 10 points of data	last of 10 points of data
Minimum	the minimum of 10 measured data	last of 10 points of data

Press "Home" key to return to real-time display, all configurations will be memorized

The Digital output DO card with relays can be set in Job1 and/or Job2. It can be viewed in "System Info" mode after it is installed into a Slot.

4.2 Display

Path: (Menu)-More-Config-Display

Select "**Display**", then press the "**Enter**" Soft button to get into the Display mode configuration page (shown on the following page).

	PR10	PR20	PR30
Display pages	8	20	21
Pens/Page	6	6	10

Display	Page1	mem 04:40:52 80% 02/17/13
1 2 3 4 5 6	7 8 9 10 11 12 13 14	
Name: Page1		_
-Mode: Trend		
-Speed: 1 Sec/Dot		
Direction: Horizontal		
Background: Black		
Pen		
Channel: AI1		
-Width: 1		
Range		
Low: -120.0		
High: 800.0		
-2		
-Channel: Math5		•
	Сору	Back
	50p)	Duck

Name: Defines the name of the display page

- Mode: Defines the default method of displaying data for the page. Options are: Trend, Bar, Digital, Mix, Circular (only for PR30) and Disable modes.
 - * Circular Trends are only available in the PR30 model.

For Circular Trends

Speed: This is the display speed. Available options are 100 msec/dot, 1 Sec/dot, 2 Sec/dot, 5 Sec/dot, 10 Sec/dot, 20 Sec/dot, 30 Sec/dot, 1 min/dot, 5 min/dot, 10 min/Page, 30 min/Page, 1 hour/Page, 2 hour/Page, 4 hour/Page, 8 hour/Page, 12 hour/Page and 1 Day/Page.

Direction: Sets the trend direction to be horizontal or vertical.

Background: Sets the background color of Trend mode to black or white

Pen: For a specific channel, this defines the drawing pen, its color, width, Range Low and Range High for the display.

Channel: Selects a specific analog input, Math, Counter, Totalizer, External channels. Select Disable if a specific channel is not required to be displayed.

Color: Selects the color for each pen.

Width: Selects the width of trend, 1-thin, 2-medium, 3-wide.

Low: Defines the low scale for a pen on the display. **High**: Defines the high scale for a pen on the display. Note:

► To illustrate the difference between Display Hi, Display Lo, Scale Hi, and Scale Low, here is a typical example, with input 0-10V, Scale Low=0.00, Scale Hi=100.00, to have better resolution and vision on Bar, set the Display Lo=0.00 and Display Hi=50.00 so that the Bar displays from value 0.00 to 50.00.

The decimal point is defined by Scale Hi and Scale Low, and not by Display Hi, or Display Lo.

4.2.1 Status Bar

Status Bar: To make it convenient when viewing the status of Digital Input, Digital Output, Math channel, Totalizer, Counter and AO, the user may enable these items in the status bar. The Status bar is displayed at Lower part of the page. A maximum of 10 tags can be displayed in each Status bar. One status bar can be configured for each page.

Note: Status bar configuration is not shared in all the pages. You may define a different setup for status bars in each page per your requirements.




Fig: Status bar display in Real time

4.3 Timer

Path:	(Menu)-More-Config-Timer
-------	--------------------------

			Timer							Timer	1			-		mem 80%	05:01:44 02/17/13
1	2	3	4	5	6	7	8	9	10	11	12	13	14		►		
- Ac	me Hour: Min: 1 Sec: 0 b 1: D 0	Enable 8	h 0n_	_DO1													▲ ▼ ↓
					•		Сор	y									Back

Press directional keys $\langle \rangle$ at the bottom to select from one of 20 available timers.

Type: Countdown, Repeat Countdown, Daily, Weekly or Monthly.

Countdown: Defines the interval of time, e.g. days, hours, minutes and seconds. (Not the Actual Time)

Repeat Countdown: Repeats the previous countdown (Not the Actual Time)

Daily, Weekly or Monthly: The timer works in selected interval of Real Time.

Action: Disables or enables the timer.

Job1, Job2: 2 jobs can be configured for each timer.

4.3.1.1 Timer Example-1

Switch on water pump every day at 8.00am and switch off at 10.00am

This application requires a "Daily" timer which works with Real Time Clock.

Configuration settings are as follows.

Timer1

Type: DailyAction: EnableTime – Hour: 8Min: 0Sec: 0Job1: DO Latch On, Target: DO1Job2: No Action

Timer2

Type: DailyAction: EnableTime – Hour: 10Min: 0Sec: 0Job1: DO Latch Off, Target: DO1Job2: No Action

4.3.1.2 Timer Example-2

Let's say, when a digital input high event is triggered by high pressure, you would like to switch on a relay after a 10 seconds delay.

Digital Input1

Event1 Type: H Job1: Enable Timer, Target: Timer1 Job2: No Action

Event2 Type: L Job1: DO Latch Off, Target: DO1 Job2: No Action

Timer1

Type: Countdown, Action: Disable Time – Hour: 0 Min: 0 Sec: 10 Job1: DO Latch On, Target: DO1 Job2: No Action

4.3.1.3 Timer Example-3

Timer & Report:


A manager plans to get a **daily** report from the recorder about the **minimum**, **maximum and average** values of the process every day. After production has finished, he can press **Menu**, then **Event**, then he selects **Report** and presses the **Mode** key to select the **Daily** mode. He then is able to view the report like in the figure shown below

Timer1

Type: DailyAction: EnableTime – Hour: 17Min: 01Job1: Log ReportTarget: ALL CH MinMaxAveJob2: Reset Min/Max/AveTarget: ALL CH(Reset historical data in order to logging new data for the next day.)

1	Menu	Rep	port	~	mem 05:02:21 86% 02/17/13
Ev	ent Repor	·t]
			02/17/13		
No	Туре	Name	Value	Time 🔺	
1	Channel	AI1	1000.0\-120.0\441.9 °C	5:01:01 PM	Mode
2	Channel	AI2	1271.9\-101.9\587.4 °C	5:01:01 PM	List
3	Channel	AI3	318.8\-168.8\75.8 °C	5:01:01 PM	LISU
4	Channel	AI4	712.5\87.5\401.1 °C	5:01:01 PM	
5	Channel	AI5	1365.0\455.0\911.6 °C	5:01:01 PM	
6	Channel	AI6	1215.4\552.4\885.0 °C	5:01:01 PM	
7	Channel	AI7	1104.9\662.9\884.7 °C	5:01:01 PM	
8	Channel	AI8	621.9\428.1\525.3 °C	5:01:01 PM	
9	Channel	AI9	1832.0\-184.0\855.6 °F	5:01:01 PM	
10	Channel	AI10	2321.4\-151.4\1123.8 °F	5:01:01 PM	
11	Channel	AI11	605.8\-271.8\180.8 °F	5:01:01 PM	
12	Channel	AI12	1314.5\189.5\769.7 °F	5:01:01 PM	
13	Channel	AI13	2489.0\851.0\1695.7 °F	5:01:01 PM	
14	Channel	AI14	2219.6\1026.4\1641.7 °F	5:01:01 PM	
15	Channel	AI15	2020.8\1225.3\1635.5 °F	5:01:01 PM	
16	Channel	AI16	1353.9\960.1\1163.2 °F	5:01:01 PM 📃 🔻	·
	◀				

4.4 Clock



	mem 05:07:10 86% 02/17/13
Clock	
Date Style: mm/dd/yy	
-Date/Time	
-Date (2/17/13)	
-Year: 13	
Month: 2	
Day: 17	
Time (17:06:54)	
-Hour: 17	
Min: 6	
Summer Time	-
Type: Disable	
-From (4/1 02:00)	
-Month: 4	
Day: 1	
Apply Time	Back

Fig: Clock configuration page in Paperless Recorder

Date Style: Selects either month/date/year or date/month/year

Date/Time: Set up the local time. Use directional keys Up/Down to select the column, press "**Enter**" soft button to change the clock data. Then press the "**Apply Time**" Soft button to apply it to the recorder.

Summer time: In some countries of North America and Europe, clocks are adjusted forward one hour near the start of spring and are adjusted backward in autumn. This is commonly referred to as Daylight Savings Time. We refer to this as "Summer Time". A Summer time set provision is available in the paperless recorder. In **Summer time**, Select **Type**: Enable and then set Start (Month, Day, Hour, Min) and End (Month, Day, Hour, Min) details.

4.5 Communication

Communication Q Pause	11:32:58 03/13/15
Communication	
Ethernet	
-IP: Static	
- IP Address: 192.168.10.100	
Subnet Mask: 255.255.255.0	
Default Gateway: 192.168.10.1	
-DNS Server: 192.168.0.1	
Modbus Server	
Modbus TCP Port: 502	
Web Server: Enable	
RS232/485/422	
-Protocol: Modbus Master	
Address: 1	
-Baud Rate: 38400	
Data Format: No,8,1	
Email	
Test	Back

Ethernet

IP: DHCP/STATIC

Select **DHCP** if the server on the network automatically allocates the IP address for the recorder.

Select **STATIC** to manually set a fixed address for the recorder.

IP Address: Defines the current address of the recorder on the network

Subnet Mask: Defines the current Subnet Mask address on the network

Default Gateway: Defines the current Gateway address.

DNS Server: This is required if the recorder is to be connected to Internet

Modbus Server: When configured as Slave Recorder is act as Server in Modbus Connectivity

Modbus TCP Port: Default: 502 for Modbus TCP

Serial:

Protocol: Modbus RTU Master/ Modbus RTU Slave

Address: Address of Master/Slave in the network

Baud rate: 9600/14400/19200/38400/57600/115200

Data format: None, 8, 1 or Odd, 8, 1 or Even, 8, 1

Modbus Client/Master:

Sample Rate:

Ethernet: 100 msec/dot, 1 sec/dot, 2 sec/Dot, 5 sec/dot, 10 sec/dot Timeout : The default timeout is 100ms Serial: 100 msec/dot, 1 sec/dot, 2 sec/Dot, 5 sec/dot, 10 sec/dot Timeout : The default timeout is 100ms Interval between 2 commands : The default timeout is 10ms

Email: Enable/Disable

Communication	STOP	20:55:38
Communication		
Email: Enable		
-SMTP Server		
-Host: http://www.company.com		
-Port: 25		
User: Mahidhar		
Address		_
-From: sales@company.com		
То		
-1: service@company.com		
-2:		
-3:		_
4:		
5:		
6:		
7:	-	
Email		Back
Test		Lucit

Press' "Email Test" and check mail function

If any problems with Email delivery, it will show error as shown attached

Communication		STOP	20:57:18 10/20/13
Communication			
Email: Enable			
-SMTP Server			•
-Host: http://www.company.com			
Port: 25			
User: Mahidhar			
Address			
-From: sales@compa			
SMTP server setting error or Ethernet setting error,			
-1: service@compa			
-2:			_
-3:			
-4:			
-5:			
-6:			
<u>⊢7:</u>	_		
Email			
Email Test			Back

4.5.1 Connections

There are a total of 16 connections available

Each connection can be configured as either Serial or Ethernet

Connections								
1	2	3	4	5	6	T		
Na	Name: Connect1							
Ту	Type: Serial							
Slave ID: 1								

Name: Connection name

Type: Serial/Ethernet

Slave ID: If Recorder is Modbus RTU Master, then, all the Slaves need to be configured in the connections.

Connections							
1	2	3	4	5			
	p <mark>e:</mark> E [P: 1 Port	Conn therr 92.16 : 502 e ID:	net 58.0.1				

IP: This is enabled only if Type = Ethernet selected at any connection

4.5.2 Commands

A total of 16 commands are available

Commands							
1	2	3	4	5	Ìέ		
-Chá -F -L	anne First: Last: vice Regis	Ext1 Ext1 ster		s: 1			
			: Inti Conn				

Action: Enable/Disable


To Channel: First: Enter first external channel details, Ex : Ext1 Last: Enter last external channel details, Ex: Ext24

From Device Register: Start: Address: Enter Start register address Data Type: Int16/Uint16/Int32_B/Int32_L, UInt32_B, UInt32_L, Float_B, Float_L Connection: Select the required connection

4.5.3 Modbus RTU Master, Example1

Master: Paperless Recorder

Slaves: External IO modules, 2 nos. each with 8 channel Analog inputs



Modbus Address	Register Name	Low Limit	High Limit	Access
30002	Analog Input 1	0	4095	R
30003	Analog Input 2	0	4095	R
30004	Analog Input 3	0	4095	R
30005	Analog Input 4	0	4095	R
30006	Analog Input 5	0	4095	R
30007	Analog Input 6	0	4095	R
30008	Analog Input 7	0	4095	R
30009	Analog Input 8	0	4095	R

Fig: External IO modules Register table

Master Configuration

Serial

RS232/485


Protocol: Modbus Master

- Address: 1

Baud Rate: 38400


-Data Format: No,8,1

Slave Configuration



4.5.4 Modbus RTU Master, Example2

Master: Paperless Recorder Slave: PID Controller



	Parameter Notation	Parameter Description	Range	Default Value	Data type
128	PV	Process value	Low: -32768 High: 32767	_	R
129	SV	Set point value for control	Low: SPLO High: SPHI	_	R

Fig: External PID Controller Register table


Master Configuration

-Serial -RS232/485 -Protocol: Modbus Master -Address: 1 -Baud Rate: 9600 Data Format: No₇8,1

Slave Configuration

Connections					
1	2	3	4	5	6
Тур	ne: C be: Se Slave	erial			


		С	omm	ands		
1	2	3	4	5	6	7
Ac	tion	: Enab	ole			
- To) Cha	nnel				
	First	:Ext1	L			
	Last	: Ext2	1			
Fr	om C	evice				
	Regi	ster				
	- T y	/pe: Ir	nput			
	St	art Ad	ddres	s: 129		
	Data	а Туре	: Int	16		
Co	nne	tion:	Conn	ect1		



4.5.5 Modbus RTU Slave, Example

Master: PC, Modbus RTU OPC Server

Slaves: Paperless Recorders, 2 nos. each with 6 channel Analog inputs



Address	Notation	Parameter	Scale Low	Scale High	Notes
0	AI1PV	AI1 process value	*1	*1	R
1	AI2PV	AI2 process value	*1	*1	R
2	AI3PV	AI3 process value	*1	*1	R
3	AI4PV	AI4 process value	*1	*1	R
4	AI5PV	AI5 process value	*1	*1	R
5	AI6PV	AI6 process value	*1	*1	R
6	AI7PV	AI7 process value	*1	*1	R

1. Input Register Parameter Table

*1: The scale high/low value are define in the following table for

Conditions	DP=0	DP=1	DP=2	DP=3	DP=4	DP=5
Scale low	-19999	-1999.9	-199.99	-19.999	-1.9999	-0.19999
Scale high	45536	4553.6	455.36	45.536	4.5536	0.45536

Fig: Paperless Recorder (Slave) Register table and scaling information

-Serial RS232/485 -<mark>Protocol: Modbus Slave</mark> -Address: 2 -Baud Rate: 38400 Data Format: No,8,1

4.6 Instrument

Instrument
Language: English
-Security Mode: Normal
-Batch Control: Enable
Volume: 1
-Tool Bar
AutoHide: Disable
-Scan Page
Idle Time: Disable
LCD
-Brightness: 4
Screen Saver: Disable
-Storage: Internal Flash
Custom Page
Allow download via ethernet: Enable

Language: A total of 20 languages are supported. They include English, Simplified Chinese, Traditional Chinese, Japanese, Korean, French, German, Italian, Polish, Spanish, Portuguese, Brazil Portuguese, Russian, Thai, Czech, Danish, Dutch, Swedish, Turkish & Greek.

Security: Select Normal or CFR-21 security. More details available at section "Security"

Batch Control: Disable and Enable options available for the selection. Refer section "Batch Control" for more details.

Volume: When the screen is touched, you can hear a "beep" sound. Select Disable to switch off the beeper. Select value 1 to 10 for volume control. 1 is minimum sound and 10 for maximum sound

Tool bar: On left side of the display page, the tool bar appears for configuration. Auto Hide: Select 10 Sec or 20 Sec or 30 Sec or 60 Sec to hide the tool bar if the user does not operate recorder via touch screen for the set time interval. Select "disable" if auto-hide is not required on specific set time

Scan Page: The User can set Automatic scanning of display pages for fixed time when enabled . The Fixed times are 1minute to 10 minutes.

Idle time: If touch screen is not used for the set idle time, then the display pages will start scrolling as per defined scan rate. Select 1 to 10 Min. for the idle time if display scroll feature is required, otherwise select "disable".

Scan Rate: This is the scroll time for the display pages. Select a time interval between 5 sec to 30 sec. This time interval is effective only if the "idle time" is enabled and the selected time is between 1 to 10 min

LCD:

Brightness: Select level between 0 and 6. 0 is the lowest brightness and 6 is for the highest possible brightness

Screensaver: To prolong the life of the LCD display, it is suggested to set the display turn-off time to 1, 10, 20, 30, 40, 50 or 60 minutes after the last time the user operates the recorder. *Screensaver default time is set to 10minutes from the factory.* The recorder continues to record data while it is in screen saving mode. The display turns on again by touching the LCD screen

Storage: Select internal flash memory or SD card

Custom page: User can use this setting to enable or disable custom pages downloaded via Ethernet.

Allow download via Ethernet: Enable/disable

4.7 Security

4.7.1 Normal

Path: (Menu)-More-Config-select Instrument, then press "Enter"

Select "Security" = Normal

If normal security is selected, users will need to key in a common password with a maximum of 18 characters. Once the password has been entered, the user needs to key in the password whenever **Config**, **Dump**, **Clear** or **Operate** soft keys are required. These keys enable the user to do configuration, dump data, clear data or manually operate the job. For easy access **Config**, **Dump**, **Clear** or **Operate** soft keys, the user may ignore the password by leaving the password field blank. If a password is not entered initially, there is no password required.

How to enter simple password

(Menu)-More-Config, select Password, press "Enter", then key-in the passwor

4.7.2 CFR-21

If the higher security CFR-21 is selected, it requires the recorder to operate with more restricted rules which comply with **FDA 21 CFR Part 11**

It has time limit during operation. If the user does not press ay keys in a predefined period of time (which can be selected between 1 to 20 minutes using LogOut function), the user needs to key in the password again. It also offers an audit trail function to record the user, the timing, and what type work the user was doing on the recorder. Incorrect password and unauthorized operation will be recorded into the event list as well. The maximum number of users available in FDA 21 CFR Part 11 Security Mode is 30.

In (Menu)-More-Config-Select Instrument, press "Enter" soft button.

Select Security = CFR-21.

Security Mode: CFR-21

Logout: Disable
Password validity: Unlimited
Security Level of Functions
Login From PC: 9
Dump: 9
Clear: 9
Operate: 9
Config: 9
Pause: 9
ShutDown: 9

LogOut: Time selection available from 1 min. to 20 min. This selection is visible only if CFR-21 is selected

If no user operates the Paperless Recorder for the above set duration, the current user will be logged out automatically

Password validity:

Password validity can be set for 30, 60 or 90 days. After the preset amount of days, it will require the user to key in a new password, or keep the old one for an additional 30, 60 or 90 days.

Security levels:


```
0 to 9 levels are supported
9 is the highest authority level, 0 is the lowest
```

4.8 Demo

The Demo mode is a simulation mode used as a sales tool for demonstration purposes. It is set to simulate AI analog inputs and Math functions.

To start the automatic demonstration, first enable **Demo mode**, then turn the power OFF and Power ON to make it effective. To stop the automatic demonstration and return to real mode with real inputs, first disable Demo mode, then turn the power off and Power ON.

4.9 Auto-Output



Setup Printer: It is to configure printer

Select Setup Printer and then press the "Enter" soft button

Print			? OK ×
Printer:	PCL Laser	Print Range	Crientation
P <u>o</u> rt:	Network	● Aļ	Portr <u>a</u> it
<u>N</u> et Path:		O Selection	O Lan <u>d</u> scape
Paper Si <u>z</u> e:	Letter	Margins (inches) –	
	od ✔ Dra <u>f</u> t Mode	L <u>e</u> ft: 1" <u> </u>	jop: 1"
Adyanc		Right: 1" E	ottom: 1"

Two kinds of printers are supported. One is USB printer for page printing and another is Serial printer for Line printing

Applications: Print Historical data, events, & Reports and snapshot directly from Paperless Recorder.

4.9.1 USB Printer

Generally, USB printer support PCL protocol. It means, it will support Page Print, but not line print. We support PCL language 4, 5 & 6

If USB printer supports ESCP protocol similar to EPSON LQ300+, then, it is possible to take line print.

Please refer Printer user manual for exact protocol details

Do not use USB printer supporting only PCL to print single line alarms, otherwise, pages will be wasted

Paperless Recorder Printer

Procedure

Connect Recorder to Printer via USB cable

Power ON Printer

Path: (Menu)-More-Config-Auto-Print, Enter

Select "Setup Printer", press "Enter" soft button

Auto-Output Setup Printer Historical Data Period: Last Hours
-Historical Data -Period: Last Hours
Period: Last Hours
Hours: 1
Interval: 1 Sec
Report Data
Mode: List

Print			? OK ×
Printer:	PCL Laser	Print Range	Crientation
P <u>o</u> rt:	Network	I A I	Portr <u>a</u> it
<u>N</u> et Path:		O <u>S</u> election	O Lan <u>d</u> scape
Paper Si <u>z</u> e:	Letter 💌	Margins (inches) -	<u>T</u> op: 1"
Ad <u>v</u> an	ced		Bottom: 1"

Print			? OK ×
Printer:	PCL Laser 🗨	_[Print Range]	Crientation
P <u>o</u> rt:	ESCP Printer PCL Inkjet	● A <u>I</u>	Portr <u>a</u> it
<u>N</u> et Path:	PCL Laser	<u>Selection</u>	O Lan <u>d</u> scape
Paper Si <u>z</u> e:	Letter	Margins (inches) – Left: 1"	<u>r</u> op: 1"
Ad <u>v</u> anc	ied <u>C</u> olor	Right: 1"	Bottom: 1"

Printer: PCL Laser, ESCP printer, PCL Inkjet available by default. Select one from the list as per printer model connected to the Paperless Recorder

Port: It shows "Network" by default. Once a printer is connected to the USB port, it will show "LPT1" for the USB printer. Select "LPT1"

Net Path: It is required to enter the correct network path here only if both Printer and Paperless Recorder are connected to a LAN network

Paper Size: A4, B5, Legal and Letter are supported

Draft mode: By default, it is selected. If more quality print is required, deselect Draft Mode

Color: Enabled for Inkjet printer


Orientation: Select Portrait/Landscape as per requirements

Note: Margins & Print Range are not working at this time.

Now, setup is ready at Paperless Recorder

4.9.2 Network Printer (LPT1)

Serial printer will print minimum one line and is generally used for printing Real time alarms. Also, it can be used for printing historical data and alarms from the Paperless Recorder. ESCP language id supported, so any printer supporting ESCP like LQ300+ can be used. The LPT1 port of a PC can be connected to a Serial printer directly. However, it needs to have a Printer driver installed in PC first, and share it for network use via Ethernet.



Procedure

Connect Paperless Recorder to PC via Ethernet

Install Printer driver in PC. Share Printer for network use

Connect Printer to PC via LPT1

Power ON Printer

In Paperless Recorder, at Path, select (Menu)-More-Config-Auto-Print, Enter

Select "Setup Printer", press "Enter" soft button

	Auto-Print
Auto-Print	
Setup Prin	iter
Period: La	st Hours
Hours: 1	l
Historical	Data
Interval	: 100ms
Report	
Mode: L	ist
1	

Print			? OK ×
<u>P</u> rinter:	PCL Laser	_[Print Range ——	Orientation
P <u>o</u> rt:	Network	I AII	O Portr <u>a</u> it
<u>N</u> et Path:		<u>Selection</u>	C Lan <u>d</u> scape
Paper Si <u>z</u> e:	Letter	Margins (inches)	Top: 1"
Advand	ed 🛛 🗹 Dra <u>f</u> t Mode		<u>T</u> op: 1" <u>B</u> ottom: 1"
	<u> </u>	Right: 1"	
Print			? OK ×
Print Printer:	PCL Laser	Print Range	? OK ×
	ESCP Printer	● Aļ	Orientation
<u>P</u> rinter:			Orientation
<u>P</u> rinter: P <u>o</u> rt:	ESCP Printer PCL Inkjet	 All Selection 	Orientation Portrait Landscape
<u>P</u> rinter: P <u>o</u> rt: <u>N</u> et Path:	ESCP Printer PCL Inkjet PCL Laser	 All Selection 	Orientation

Select ESCP printer.

Then, enter the proper Net Path. Ex: \\PC1\LQ300

PC1 is computer name and LQ300 is shared printer driver for network use

Now, the setup is ready at the Paperless Recorder

4.9.3 Print Historical data

Configure USB Printer or Network printer as explained in earlier section

In Paperless Recorder, at Path, select (Menu) -More-Config-Auto-Output, Enter

Auto-Output			
Auto-Output			
Setup Printer			
-Historical Data			
-Period: Last Hours			
Hours: 1			
Interval: 1 Sec			
Report Data			
- Mode: List			

Period: Select Last hours or Last days


Hours/Days: Select no. of hours or no. of days as per above selection

Interval: Select intervals of 100 msec/1 sec/2 sec/ 5sec/ 10 sec/ 20 sec/ 30 sec/ 1 min/ 5 min/ 10 min.

The Print function is available in the Job list and can be initiated in various ways.


Ex: Print historical data of last 1 hr. and do this every day at 8.00 hrs

		Timer				
1	2	3	4	5	6	
Тγ	be: Da	aily				
Act	ion: E	Enable	е			
- Tin	Time					
-Hour: 8						
-Min: 0						
Sec: 1						
-Job1: Print Historical Data						
Job2: No Action						



4.9.4 Print Reports

In Paperless Recorder, at Path, select (Menu)-More-Config-Auto-Output, Enter




In the **Mode**, select which kind of Reports are required. Available options include Daily Reports, Weekly Reports and Monthly Reports

		Timer				
1	2	3	4	5	Ìθ	
ŢΠŢ	pe: Da	aily				
Ac	tion: E	Enable	е			
Time						
-Hour: 8						
-Min: 0						
Sec: 1						
Job1: Print Report List						
Job2: No Action						
I						

4.9.5 Print Snapshot

≣∗	(Menu)-M	ore-Ope	erate-Pri	nt Snaps	shot	
Menu						
Realtime						
Mode	Dump					
Alarm	Clear					
Status	Operate					
History	Config					
Event	Stop					
More	ShutDown					
Operate						×
Print Sn	apshot					
Job Iten	ns:		Target			
Disable Preset C Reset C Inc Cour Dec Cou Log Rep Reset M	ounter nter Inter					
Print Ev Print Re Print Sn	ent List port List					ОК
						Cancel

4.10 System Info



Path: (Menu)-More-Config-System Information

The system information includes System version, Internal and External memory, Ethernet IP address and Slots status

Version: The firmware version of the recorder.

Memory (Free / Total):

Internal: Indicates the percentage of free memory compared to total memory available in internal flash card

External: Indicates the percentage of free memory compared to total memory available in external memory devices of SD and USB.

A small icon on the top right indicates the percentage of free memory e.g.: Mem 96 %

Address:

MAC: Displays the MAC address of Paperless Recorder IP address: Displays the IP address for the Paperless Recorder

Slot 1..5: Indicates the status of all Slots and the cards that have been inserted. The cards include Analog Input AI, Digital Input DI and Digital Output DO & AO.

4.10.1.1 Upgrade Firmware

Path: (Menu)-More-Config-System Information-Maintain

Maintain: The Maintain button is located at left lower side in System Info. page. It is the button to upgrade the firmware and calibrate the touch screen in the paperless recorder

Select	×
Update Core System	_
Update Core System	
Touch Calibrate	
ОК	Cancel

Upgrade Core System:

This is to upgrade firmware in the paperless recorder. Contact factory/supplier for the latest firmware files. Please download firmware file (.bin file, its compressed , it needs to be un zipped) to a USB stick or SD Card then, insert the USB stick into USB port or SD Card at SD card Slot in the Paperless Recorder. Select the External Storage to SD Card or USB flash on the External Storage Setting depends on the storage inserted. Select "Update Core System", then click the "OK" button. It may take a few seconds to finish the process. Please note that the power to the recordershould be not switched off during this upgrade process


4.10.1.2 Calibrate Touch Screen

Path: (Menu)-More-Config-System Information-Maintain

Maintain: The Maintain button is located at left lower side in System Info. page. It is the button to upgrade the firmware and Calibrate touch screen in paperless recorder

×
Cancel

This is used to calibrate the touch screen. A "+" symbol appears in the center of the LCD screen. Carefully press and briefly hold a stylus or finger on the center of the target. Repeat this procedure as the target moves around the screen. Just touch the screen to complete the screen calibration. This procedure helps to locate pointer via touch screen and properly select the objects during operation of the recorder



4.11 Batch Control


This feature is to store data in a different folder for every batch and archive data later with reference to a batch.

Path: (Menu) - More-Config-Instrument

Select Batch Control and press "Enter" key. Select "Enable". Press "Ok"

Instrument				
Language: English				
-Security Mode: Normal				
Batch Control: Enable				
-Volume: 1				
- Tool Bar				
AutoHide: Disable				
-Scan Page				
Idle Time: Disable				
-LCD				
-Brightness: 4				
Screen Saver: Disable				
-Storage: Internal Flash				
-Custom Page				
Allow download via ethernet: Enable				

Press "Back"





Press "OK", then, press "Home" Soft key to save these settings

Power the recorder OFF then ON, then in the (Menu), the Batch soft key will be shown as below

≣▪	Batch:		Paget		mem SD 35% 99%	10:12:41 12/04/14
Realtime	Dump	AI2	177.5	AI3 PC	-56.7	7 ∘c
Mode	Clear		1 380,000	\sum		
Alarm	Operate					
Status	Config		P			
History	Pause	\square				
Event	Batch	04/14 95:53	12/04/14 10:07:33	12/04/14 10:09:13	12/04/14 10:10:53	12/04/14 10:12:33
More	ShutDown	AI5	744.7	AI6	772.	8 _{°c}

Note: "Batch" soft key will appear only after Batch Control enabled as explained above

Press on Batch and it shows the following screen


Set Batch	*
Batch Name - No: Batch1	- 1
Comments:	
1:	
2:	
3:	
	OK Cancel

Operator can enter a maximum of three comments for any batch.

Configuration				
Save	Channel AI DI Math			
Load	-AO -External -Display	▼		
Default	- <mark>Batch</mark> -Timer -Clock -Communication	Ţ		
	– Instrument – Password: ******* – Demo: Enable – Auto-Output – System Information	*		

In the (Menu)-More-Config, select "Batch", press "Enter" key

It will show the Batch control settings as shown below



- Name: Enter Batch name. A maximum of 18 characters is allowed. By default, the name is Batch1.
- Lot Number: Enter the Lot number. If Auto increment is enabled, then Lot numbers will be incremented automatically by the recorder, Batch1-1, Batch1-2, Batch1-3 etc. during every start of a new batch

Jobs: Two events, Start, Stop are available


Start: Start means Jobs that should be done during start of a new batch **Stop**: Stop means Jobs that should be done during stop of a batch

Note: When batch control is enabled, the recorder will be in Pause mode by default initially and it requires Starting of the recorder from the Menu by pressing at (Menu) - More than "Start". When recorder is not logging any data, Pause status shall be shown in the Top right area of the recorder as shown below



How to do the batch control

Press on ("Menu"), "More", then "Start". Batch number will be shown in the recorder Top area.



To Stop this batch, press on "Menu", "More", then "Pause". It gives a message "Saving data" and updates batch data in the internal memory of the paperless recorder.

4.11.1.1 Batch Example-1

The operator wants to start a batch every day at 8.00am and stop the batch at 12.00am.

Configuration

Timer1


Type: DailyAction: EnableTime – Hour: 8Min: 0Job1: StartJob2: No Action

Timer2			
	Type: Daily	Action: E	Enable
	Time – Hour: 12	Min: 0	Sec: 1
	Job1: Pause		
	Job2: No Action		


How to view batch data in Recorder


Press on (Menu)-History-Page1

Press "Search", select required Batch and press "Ok"



Batch details including lot number can be archived by pressing soft key "Batch"





How to Dump Batch data to external USB memory Press on (Menu)-More then press on Dump

×
~
Cancel

Select "All" or required lots and press "OK" For ex: Batch1-1, Batch 1-2, Batch1-3 are available Initial 1 Lot means, Batch1-1 Initial 2 Lots means, Batch1-1 and Batch1-2 Initial 3 Lots means, Batch1-1, Batch1-2 and Batch1-3

Note: Provision not available to dump only specific lot.

Please refer Instrument->Data Transfer-> Transfer and Remain

Message			>	×
🚹 Do you want 🏷 dur	np historical (data and even	t list to storage media?	
	1			
	Yes	No		

Press on "Yes" to dump data from internal memory to external SD Card or USB memory.

If you have 3 batches, let's say Batch1-1, Batch1-2 and Batch1-3, then you can see three different folders in the external USB memory card after completing of dump



Please note that the data available in USB memory is in a proprietary format to avoid any kind of tampering. You will need PC software to view this data.

4.12 Calibrate

This function is used for calibrating Individual Analog channel.

Configuration		14:49:26 11/07/14
Configuration		
Channel AT Warning		
This function is only for engineering staff, any cha may affect the accuracy of I/O signals. The data sampling will be paused. Continue?(Y/N)	nge	
Yes No		
- Instrument - Password: ******** - Demo: Disable - Auto-Output - System Information - Calibrate		

Example 1:

Calibrate an AI with 0-5V

When you click Calibrate menu, the user can see the below screen. Please click calibrate as shown in the below screen

Ca	librate	AI1	-	Pause	14:50:19 11/07/14
Calibrate					
Unit	r e:Volts				▲ ▼ ↓
Calibra	ate				Back

Please note that , Inorder to calibrate the whole Module slot accurately , the 3rd channel of each slot nust be calibrated first. Click OK.

Ca	alibrate	AI1	Pause	13:12:25 07/13/15
Calibrate				
Channel				
Sensol	e: Volts			
_ I Init				
	In order to make t	he whole slot accurate, the sot must be calibrated first.	3rd	
				_

Now click Calibrate button as shown below.

C	alibrate	AI1	Pause	13:17:13 07/13/15
Calibrate				
Unit	r e: Volts			▲ ▼
Calibra	ate			Back

Click yes and proceed with the calibration process

Ca	alibrate		AI1	Pause	13:18:50 07/13/15
Calibrate					
Channel					
Senso	r e: Volts				
Libit	-				_
Ra	onfirm				
	Do you	want to calibra	te this channel?(\	(/N)	
	Do you				
		Yes	No		

Please follow the next instruction, input OV in to the input which can be seen in below screen

(Calibrate		AI1	Pause	13:20:55 07/13/15
Calibrate					
Channe	l: AI1			Г	
Sens					
	pe: Volts it: V				
	Lower AD Calibrati	on			
			and then press OK = 0 V Cancel	button.	

After you input OV and select ok, the user can see the below screen. Now follow the next instruction.

Ca	alibrate	AI1	Pause	13:22:01 07/13/15
Calibrate				
Channel				
Senso	e: Volts			
List				_
Ra	ower AD Calibration			
		Calibrating		

Now input 5V and click ok

С	alibrate	AI1		Pause	13:23:16 07/13/15
Calibrate					
Channel					
Senso	r e: Volts				
Lini	F• V				_
Ra	pper AD Calibration				
	Please adjust as fo	bllows and then press Input= 5 V	s OK b	utton.	
	Ok	K Cancel			
					_

After you input 5V and select ok, the user can see the below screen Now follow the next instruction.

Ca	alibrate	AI1	Pause	13:22:01 07/13/15
Calibrate				
Linit	- e: Volts			
		Calibrating		

When the calibration is done successfully, the user can see below screen.

Ca	alibrate	AI1	Pause	13:24:29 07/13/15
Calibrate				
Channel				
Sensol	e: Volts			
Unit Ra	•• W essage			
Ra				
		Calibration completed!		
		ОК		
				_

Example 2: Calibrate an AI with K-Type Thermocuple

Please note that , Inorder to calibrate the whole Module slot accurately , the 3rd channel of each slot nust be calibrated first. Click OK.

С	alibrate	AI1	Pause	13:29:29 07/13/15
Calibrate				
Channel	r			
- I Ini:	e: Thermocouple K Ty Hersage	pe		
	In order to make the	whole slot accurate, the nust be calibrated first.	3rd	
		ОК		

When you click Calibrate menu, the user can see the below screen. Please click calibrate as shown in the below screen

C	alibrate	AI1	Pause	15:21:42
Calibrate				
Channel Senso Typ Unit		Туре		▲ ▼ ↓
Calibra	ate			Back

Click yes and proceed with the calibration process

С	alibrate		AI1	Pause	13:31:19 07/13/15
Calibrate					
Channel					
Senso Typ Unit Ra ^C	e: Thermocoupl	е К Туре			
₩Ka		ant to calibra	te this channel?	(Y/N)	
		Yes	No		

Please follow the next instruction, input 0 mV in to the input which can be seen in below screen

С	alibrate		AI1	Pause	15:22:52
Calibrate					05/22/15
Channel	L: AI1				
Senso	r				
	e: Thermocouple K 1	Гуре			
Uni	t+ °C ower AD Calibration				
- Ko					
	Please adjust as f			button.	
		Input=	UMV		
	0	ĸ	Cancel		
					_

After you input 0V and select ok, the user can see the below screen. Now follow the next instruction.

Ca	alibrate	AI1	Pause	15:26:47 05/22/15
Calibrate				
Channel	AI1			
Senso				
	e: Thermocouple K T	ype		
Unii	ower AD Calibration			
- Ra				
		Calibrating		
		Senior dell'Igni		

Now input 60mV and click ok

Ca	alibrate	AI1		Pause	15:24:39 05/22/15
Calibrate					
Channel: Sensor	r				
Unit	e: Thermocouple K Typ oc oper AD Calibration)e			
⊢Ra	Please adjust as foll	ows and then p nput= 60 mV	ress OK	button.	
	ОК	Cano	el		

After you input 60 mV and select ok, the user can see the below screen Now follow the next instruction.

Calibrate	AI1	Pause	15:30:44 05/22/15
Calibrate			
Channel: AI1			
Sensor			
-Type: Thermocouple K Typ	pe		
Unite 9C Ra ^{Upper AD Calibration}			
	Calibrating		

Now input 0^{0} C from the simulator and press ok ,

C	alibrate	AI3		Pause	11:32:31 08/31/16
Calibrate					
Ser	nel: AI3				
-Calibra		s follows and the Thermocouple K , Ambient= 25 OK C	Type, 0°C	button.	

Calibrate	AI1	Pause	15:30:44 05/22/15
Calibrate			
Sensor			
- Type: Thermocouple K Typ	pe		
	Calibrating		

When the calibration is done successfully, the user can see below screen

Calibrate	AI1	Pause	15:31:35 05/22/15
Calibrate			
Sensor			
- Type: Thermocouple K	Туре		
Unit: °C Ra ^{Message}			
Ca	libration completed!		
	ОК		
			_

Calibrate an AO with 4-20mA

When you click Calibrate menu, the user can see the below screen. Please click calibrate as shown in the below screen

C	alibrate	AI1	Pause	13:29:29 07/13/15
Calibrate				
Channel			Г	
Senso				
	e: Thermocouple K Tyj t· •C	pe		
Ra	lessage			
	In order to make the v	whole slot accurate, the liust be calibrated first.	3rd	
		ОК		

Click ok and proceed and select the channnel of Analog Output to be calibrated.

Cal	librate	AI1	Pause	14:12:56 07/31/15
Calibrate	Select		×	
- Channel: . Sensor - Type - Unit: - Rang	AO1 AI2 AI3			
		OK Cancel		

C	alibrate	A01	Pause	14:50:02 07/31/15
Calibrate				
Channel			Г	
i ype;	Current			
				_
				-
Calibra	ate			Back

Confirm the channel to calibrate and click "Calibrate" and "yes" in the next screen

C	alibrate		AO1	Pause	14:14:06 07/31/15
Calibrate					
- Channel - Type:					
	onfirm Do you	want to calibra	ate this channel?(Y	′/N)	
		Yes	No		

Please connect current meter before calibrating and click ok

C	alibrate	A01	Pause	14:14:56 07/31/15
Calibrate				
Channel	: A01 Current			
M	lessage			
	Please connect a calibration.	current meter before starting	3	
		ОК		

Ca	alibrate	A01	Pause	14:15:35 07/31/15
Calibrate			_	
Channel: Type:	: A01 Current			
м	essage			
		Preparing Data		
013				

Calibrate	A01	Pause	14:16:04 07/31/15
Calibrate			
Channel: AO1			i
Type: Current			
Lower Calibration		1	
Please input the va	alue shown on the connec	ted meter.	
E	OK Cancel		

Then , input the value for Lower calibration , ie 2.7308 mA after clicking ok

Calibrate	ut Numeric — [4]				ie 14:24:20 07/31/15
- Channel: AC - Type: Cur	7	8	9	BS	
	4	5	6	<	
	1	2	3	>	
	0	•	-	Clr	
	0	к	Car	ncel	

Lower calibration is in progress

C	alibrate	A01	Pause	14:17:42 07/31/15
Calibrate				
Channel			1	î
i ype:	Current			
	ower Calibration			
		Calibration in progress		

After we finish Lower calibration now we need go for Upper calibration

С	alibrate		A01	Pause	14:18:43 07/31/15
Calibrate					
Channel Type:	: AO1 Current				
U	pper Calibration			ant.	
	Please inpu	t the value show	n on the connecte Cancel	ed meter.	
					_

After click ok on the above enter upper calibration value as 18.745 mA and click ok

CalibInpu Calibrate	it Numeric — 20				■ie 1 ⁴	4:23:3 7/31/1
Type: Cur	7	8	9	BS		
	4	5	6	<		
	1	2	3	>		
	0		-	Clr		
	0	к	Car	ncel		

Upper calibration is in progress

Calibrate	A01	Pause	14:17:42 07/31/15
Calibrate			
Channel: A01			
Type: Current			
Lower Calibration			
	Calibration in progress		
			1

After we finish Upper calibration now we need go for entering Offset

Calibrate	A01	Pause 14:19:54 07/31/15
Calibrate		
Channel: A01		· · · · · · · · · · · · · · · · · · ·
Type: Current		
Offset Calibration		
Diasso input the ur	alue shown on the connecte	nd motor
Please input the va	arue shown on the connecte	
	DK Cancel	
	Gancer	

we enter 3.7554 mA as offset

CalibInp				in the second se	× ;e	14:25:24 07/31/15
Calibrate	-Numeric — 1				7]]	
Channel: AC Type: Cur	7	8	9	BS		
	4	5	6	<		
	1	2	3	>		
	0	•	-	Clr		
	0	к	Car	ncel		

Offset calibration in progress

Ca	alibrate	A01	Pause	14:19:25 07/31/15
Calibrate				
Channel				
Type:	Current			
U	oper Calibration			
		Calibration in progress		
-0			1	
				î
-				

When the calibration is complete , we can see the below screen


Ca	alibrate	A01	Pause	14:48:32 07/31/15
Calibrate				
Channel: Type:				
м	essage			
		Calibration completed!		
		ОК		

Note:

Channell #3 should be calibrated first in all types of Analog Input cards. An analog temperature sensor is installed in channel # 3. When channel # 3 is calibrating, the cold junction voltage measured by this temperature sensor will be loaded into a register.

If channel # 3 is not calibrated, the default value of cold junction voltage will be used for all channels. It does not matter what order you perform calibration after calibrating input 3, there is no need to follow a sequence, and any one of T/C, RTD, mA or VDC can be done independently.

4.13 Procedure To Upgrade and Restore Factory Default Settings



Power ON the Recorder while Pressing the Reset Button

Now the Screen will appear like below

Please st	elect
Format	Upgrade
	Cance l
	the second second

Format:

Press the Format Button for at least 3 Seconds to return the Recorder to factory Settings.

After the Recorder is done formatting, it will ask for Screen Calibration. Do the Screen Calibration.

The recorder has now been returned to factory default settings.

Upgrade:

Download the Firmware from the FTP Link Given(.bin file, its compressed , it needs to be un zipped).

Copy the File to the SD Card. Be sure the SD card is formatted to FAT32.

Insert the SD Card to the SD Card Slot on the Recorder.

Press Upgrade Button for at least 3 Seconds to upgrade the image from SD Card. Follow the on-Screen instructions.

5. PC BASED SOFTWARE

By using this software you can configure the settings of the Recorder offline and online. Trends of configured channels can be viewed in PC by using this.

This has got 4 Options:

5.1 Free Basic Software

5.1.1 Requirements

Hardware

Recommended hardware PC with 2 GHz processor, 1GB RAM 50GB free space in the hard disk. Ethernet port, RJ 45 female/ USB port Minimum 20% free space in hard disk, Less than 10% space generates an error message

5.1.2 Operating system

Windows based Operating systems, Windows XP, Windows 7, Windows 8 etc.. 32 bit and 64 bit operating systems are supported

5.1.3 Software

Software installation

- 1. Install latest dotNet software from Microsoft website
- 2. Install the software
- 3. Historical viewer icon desktop shortcut will be created after installation of software
- 4. Historical viewer can be accessed from the following path as well Start-Programs-Historical viewer-Historical viewer.

The Software contains:



HIST_VIEWER is for monitoring historical trends and also for configuration of recorder parameters via the PC.

Uninstall the free Software

This is to remove previous versions of free software from PC.

HIST_VIEWER



How to set configuration of the Recorder from PC.

Start-Programs-Historical Viewer

Tool bar



To open new project

To open existing project file



When the User clicks the icon new (shown in the above picture in the red square), they can view the below menu where they can select the Recorder (PR) and click ok.

Cr	eate project type	ì
	Recorder(VR06)	
	Recorder (VR06) Recorder (VR18)	
1	Recorder (PR) HMI	

After that, the user must give a name to the project and select the location of project (as shown in the below figure). If the user already has the configuration stored in a SD card or USB, they can select the path accordingly.

If the User wants to configure the Recorder for the first time via Ethernet, they must select Ethernet, and enter the correct IP address of the Recorder.

New Project Enter the new	name Project1	
Select file path		
Storage Media	C:\	
© Ethernet	192.168.0.1	

If the User wants to open file in the software, already configured in the PC, then they can select *.prj file to open the project.

Open			? 🔀
Look in: 隘	Historical	• + 1	r 📰 🕈
Test1			
File name:	0		
Files of type:	Project files(*.prj)	•	Open Cancel



To save the project file settings in PC

• Receive configuration (Storage Media/Ethernet)

₽ Send configuration (Storage Media/Ethernet)

If the software is already configured in the PC, then you can select *.prj file to open the project.

Bank 🗟

This is used to select the physical connection between the Recorder and PC. Two options are available: Storage Media

Ethernet

Select file path	
Storage Media	C:\
Ethernet	192.168.0.1
	OK Cancel

Standard Ethernet port (RJ 45 female) shall be available at the Recorder. RS 232/ RS485 shall be supplied as additional options.

5.1.4 Ethernet Configuration

It is possible to use PC software for data logging of Recorders connected on standard Ethernet. A maximum of 1024 tags can be configured for data logging, archiving and analysis. The tags cover AI, Math, DI, DO, Counter & Totalizer.

- 1. Make sure that the network adapter in the PC is properly configured. IP address, Subnet mask and Gateway should be configured at the PC for using the Historical Viewer program. Please contact you System administrator to set a Unique IP address for the PC.
- 2. Install the Historical Viewer application software in your PC. The software may be installed from "setup" available in the CD supplied as per the order.
- 3. Ethernet configuration at the Recorder

Please refer to **4.5 Communication** for entering the IP address, subnet mask and gateway address manually at the Recorder.

Gateway refers to a device on a network that sends local area traffic to other networks.

Subnet mask numbers help to define the relationship between host and rest of the network.

For every LAN, the Network administrator shall define a Subnet mask and Gateway. Obtain the subnet mask and gateway address for the LAN at the place where the Recorder to be connected. Enter these details at the Recorder manually using front buttons.


By default, subnet mask address: 255.255.255.0


By default, Gate way: 0.0.0.0

Enter the Unique IP address to the Recorder and enter IP address at the Recorder manually. Contact your system administrator to obtain a free IP address available at user LAN. Naming duplicate IP addresses may disable the communication between the Recorder and PC/LAN HUB.

4. Local area network uses UTP cable for Ethernet connectivity. Maximum UTP cable distance between the Recorder and LAN/HUB/PC should be less than 100 Meters. If the distance is more than 100 Meters, additional LAN accessories/equipment may be required for increasing signal strength. Please contact your network administrator for more information on extending the LAN distance.

5. Two different types of cables shall be used for connecting the Recorder on Ethernet as follows. For connecting the Recorder to LAN HUB, then standard straight-through Ethernet cable should be used. For connecting the Recorder to a PC/Laptop directly, a crossover Ethernet cable should be used.





6. Connect a proper UTP Ethernet cable per the requirements and observe the communication status between the Recorder and PC/LAN HUB at the LED's located near the female RJ 45 connectors.

Recorder side

Link (Green LED)

Green lit: Cable connected between the Recorder and PC/LAN HUB Green Off: No Link between the Recorder and PC/LAN HUB

Tx/Rx

Orange Lit continuous: No cable connection Orange slow blink: Communication established between Recorder & PC/LAN HUB If the download is successful, the User can see the below screen.

	+ + 3	1	•													
hannel AI								1	AI1							
DI	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	
Math		Name	AI1				Desc	-			٦	Type E	nable	*		
A0 D0		Filter	Disable													
External	1		DISADIO	e	•											
splay	Log	24	ata Type	2 B)	/te	*		Value F	Range: -3	276.8	~ 3276	5.7				
ools Timer			111 C 8353	_	2			- arac -	12							
Clock			Trigger	Contraction	MAR (8).	•			Method	Inst	ant	•				
ommunication			Speed	100	ms/Dot	•										
strument			Offset	0.0		11			Gain	1.0		-				
emo	Ser	isor	Onset	0.0					Guil	1.0						
L. O.L.			Type	Therr	nocoupl	е Ј Туре	2		•		Uni	t: 👓	-			
		3	Range	-200	0 ~ 110	0.0										
		2	Range	-200.	0~110	0.0			•							
	Eve	ents	Range	-200.	0 ~ 110	0.0										
	(ents					1	Messa		Job1	10	b2	Hystere	esis		
uto-Output ystem Info	Eve No. 1	ents	pe S	-200. etpoin		Loç)	Messa	ige	Job1 Action		b2 Action	Hystere 0.0	esis		

If Upload is unsuccessful, the recorder shows the message "No response from Recorder, connection fails".




If this is the case, please check the Ethernet cable connections at both the Recorder and PC/LAN HUB side. Also make sure that green communication LED is lit which shows there is a proper firm connection at the RJ 45 connector.

If still communication is not established between the Recorder & PC, then once again check Subnet mask and gateway address at the Recorder & PC. Contact Network/ System administrator for proper Ethernet configuration of the Recorder & PC. Please note that Recorder should have a unique IP address in the network and PC that is using the software shall have a separate Unique IP address in the network.

nnel								AI1				
	1	2	3	4	5	6	7 8	9	10 11	12 1	13 14	15
lath		Name	AI1				De	SC			Type En	able 🔻
		Filter	Disat	ole	•							
xternal	Loc		Distr	ne								
play rt/Stop	1000		ata Typ	e 2 Byte	e	*		Value Rang	je: -3276.8 ~	3276.7		
ols			Trigge	er Enabl	le	•		Metho	d Instant	•		
imer Clock			Spee	d 100 r	ms/Dot	-	Mod	bus Scale:	-200.0 ~ 110	0.0		
nmunication				Offset	0.0		-		Gain 1.0	N N	_	
trument sword	Ser	isor		Unset	0.0				Gain 1.0)		
no co-Output	100000		Type	Therm	ocouple	e J Type		-	·	nit : C	•	
tem Info			Range	-200.0	·∼ 110	0.0		÷				
	Eve	ents										
	No.	. Ty	/pe	Setpoin	ıt	Log		Message	Job1	Job2	Hysteres	is Holding
	1	Н	•	840.0	Lo	og Alarm			No Action	No Action	0.0	Disable
	2	L	•	60.0	Lo	og Alarm	•		No Action	No Action	0.0	Disable
	3	НН	•	937.5	Lo	og Alarm	•		No Action	No Action	0.0	Disable
I	4	LL		-37.5		og Alarm	•		No Action	No Action	0.0	Disable

Now you see the configuration screen,

close the screen, its asks to save data , click yes



It will navigate to historical viewer screen, click yes for the import of data

Edit(E) View(V) Displa	v(D) Page(P) Se			controject2.004								0 4
<u>> ≥ ≣ m d</u> =	1 🔊 🖌 🕄 IF			= @ @ @	Zoom Size	• K 🖉 🔿	🛱 w 🖪					
a 🖉 🛛 1 Scale	-											
All				10				AIB				
1. Sec. 1												
			(inc									
)-												
)-												
				Information			×	1				
)-					100							
•				Now yo	u can import me	asured data !! Continue	(Y/N)					
10:14:17 10:16:08 03/18/16 03/18/16	10:17:48 03/18/16	10:19:28 03/18/16	10:21:08 03/18/16	-				10:29:28 03/18/16	10:31:08 03/18/16	10:32:48 03/18/16	10:34:28 03/18/16	10
03/18/16 03/18/16	03/18/16	03/18/16	03/18/16			Yes	No	03/18/16	03/18/16	03/18/16	03/18/16	03
714								Alb				
			°C					*C				
AI1 (Rearmost)												
A12 A13												
AI4												
AI5												
AI6 (Forefront)												


The import starts,

AII			A12				AI3				
		°C					°C				
			idate								
			Data linking P	Please wait a	moment	1					
			Data miking P			32%					
		L									
10:14:17 10:16:08 03/18/16 03/18/16	10:17:48 10:19:2 03/18/16 03/18/1	8 10:21:08 6 03/18/16	10:22:48 03/18/16	10:24:28 03/18/16	10:26:08 03/18/16	10:27:48 03/18/16	10:29:28 03/18/16	10:31:08 03/18/16	10:32:48 03/18/16	10:34:28 03/18/16	1
AI4							AI6				
		°C					°C				
AI1 (Rearmost)											
AI3											
AI4											

Once done, it will ask to your selection to delete storage media data, in this select No.

nedia data ?(Y/N)
No
_


Then you can view the data as below



5.1.5 Automatic export of data from historical viewer

In the Historical Viewer after opening the project . Please follow the steps for automatic import

1. Please select Automatically import and export option as shown in he picture.



2. Please do the settings as explained in the below picture for the period and also select the path for data dump

Automatically Import and Export Option	Select the period when want the automatic output
Option item	Period: File export attribute
C Manually	Speed S Sec/Dot
Automatically and Export to excel	Database Option
C Automatically and Export to database format	Export format : Microsoft Text (".csv)
File Select file path : C:\Program Files\Historical View	er\Historical\Project_pr1
🖌 ок	X Cancel
	Select the path of the file
	where you want the data

to be dumped

5.2 Data Acquisition Studio Software

5.2.1 Requirements

Hardware

Recommended hardware PC with 2 GHz processor, 1GB RAM 50GB free space in the hard disk. Ethernet port, RJ 45 female/ USB port Minimum 20% free space in hard disk, Less than 10% space generates error message

Operating system

Windows based Operating systems, Windows XP, Windows 7, Windows 8 etc.. 32 bit and 64 bit operating systems are supported.

5.2.2 Software

Software installation

1.Install latest dotNet software from Microsoft website

2.Install Data Acquisition Studio software

Historical viewer icon and Real time viewer icon will be created after installation of software

Historical viewer can be accessed from the following path as well Start-Programs-Historical viewer-Historical viewer

Real time viewer can be accessed from the following path as well Start-Programs-Data Acquisition Studio Realtime viewer

5.2.3 How to configure Communication Bank

It is to set path for the data transfer. It's important to setup "Bank" properly at the to proceed further

Open existing Project or create a new project from RealTime viewer using one of the following options

Start-Programs-Data Acquisition Studio-Realtime Viewer

File(F)	View(V)	Page(P)	Window(W)	Language(L)	Help(H)	
		涂回 田				∄ Ⅲ

Click on the new Project as shown in the red square in the above figure

Then the User must give a name to the project as shown in the below figure

🔁 Re	ealTin	ne C	onfigu	ure																	
			٩	2	8	1	#	1	J	8		J	#	oper,	uþ.	\$	ŵ,	× (0		
																					1
				89	Crea	ate a	new	pro	ject	44											×
							1	Ente	r the	new	nam	e:	Proj	ect1							
										-	~	ОК	1			×	Cance	el	1		
										-			_		-						
				-	_	_	-		-	-	-	-	-		-	-					_

H	😫 🔀 🖾 🕯		
[<mark>≓</mark> Add	🖄 Modif	y
No.	Node Name	Tag Name	Bank

Click the bank icon 😫 to open communication bank configuration, and select the bank accordingly.

Protoco	Disable	RS232 -	
RS232	Modbus		
Com Port :	COM2	-	
Baud Rate :	9600	•	
Parity :	No	•	
Data Bits :	8	•	
Stop Bits :	1	•	
		Default	

If the recorder is connected to Ethernet, then select Modbus_TCP as shown below

	Bank1	
Protocol:	Modbus_TCP	•
Ethernet		
Port :	502	
Format :	Standard	-
		Default

If the recorder is connected via Serial RS-232 or RS-485, then select Modbus_RS232 as shown below. Please select the same com port and baud rate that is in the instrument.

	Bank1	
Protocol:	Modbus_R	85232 -
RS232		
Com Port :	COM2	•
Baud Rate :	9600	•
Parity :	No	•
Data Bits :	8	•
Stop Bits :	1	•
		Default

Note : For connecting PR with Realtime Viewer, we suggest to use Ethernet . as Ethernet has better speed compared to RS485/RS232. The Volume of Configuration data in PR is Large comparing to VR. So If you want to connect PR with DAQ using RS485 then you need to follow the below steps :

1. Dump the Configuration file to USB/SD Card from PR

2. Create a new project in Real time Viewer and select the bank with RS485

3. Select the Folder of SD Card/USB where the configuration file was dumped from $\ensuremath{\mathsf{PR}}$

4. Now the Real time viewer read the configuration file from PR and start monitoring

the real time value.

5.2.4 How to configure Recorder

There are three ways to configure the recorder:

Touch screen, Software and Storage Media.

5.2.5 Touch Screen

It is possible to configure the recorder directly from the touch screen. Press Menu-Config

Configuration		mem	3:10:08 10/22/13
	Configuration		
Save	Channel AI DI Math		
Load	-AO -External -Display	▼	
Default	- Timer - Clock - Communication - Instrument	┙	
	-Password: ******* -Demo: Enable -Auto-Output - System Information		

Please refer chapter 4 for more details

5.2.6 Ethernet

The steps are given below

- 1. Connect Recorder to PC via cross over or straight Ethernet cable
- Check IP address of your Computer. Make sure to set IP address of Recorder in the same domain as your PC For ex: IP address of your computer: 192.168.0.200 You may set IP address of Recorder as 192.168.0.11
- Procedure to set IP address manually at Recorder Menu-More-Config-Communication, press "Enter" IP = Select User Define

Select, IP address: 192.168.0.11 (Default) and press "Enter" to change if required Subnet mask: 255.255.255.0 Default Gateway: 192.168.0.1

4. Use "Ping" from DOS prompt and check if communication is ok or not. If there is no response, check the cable or IP address at your computer or IP address at the recorder

🗪 Command Prompt
Microsoft Windows XP [Version 5.1.2600] (C) Copyright 1985-2001 Microsoft Corp.
E:\Documents and Settings\Mahi>ping 192.168.0.11
Pinging 192.168.0.11 with 32 bytes of data:
Reply from 192.168.0.11: bytes=32 time<1ms TTL=128 Reply from 192.168.0.11: bytes=32 time<1ms TTL=128 Reply from 192.168.0.11: bytes=32 time<1ms TTL=128 Reply from 192.168.0.11: bytes=32 time<1ms TTL=128
Ping statistics for 192.168.0.11: Packets: Sent = 4, Received = 4, Lost = 0 (0% loss), Approximate round trip times in milli-seconds: Minimum = Oms, Maximum = Oms, Average = Oms
E:\Documents and Settings\Mahi>_

5. Double click the Realtime viewer icon at desktop and follow on screen instructions to create a new project


Note: Create a new project only if it's first time. Next time, you can open a the saved project available in your computer

Device Type: Rei	corder(PR) 💌	Bank: 1
Protocol: Mod	lbus_TCP	I Auto-update the Tag content
LogSpeed: 1 S	ec/Dot 💌	LogMethod: Instant
IP address		
Example: 192,168,0,25		Please key in IP here and then press '+' button to add it to the IP list.
IP List:	192.168.0.119	+
		< Please select one IP form IP List and then press '-' button to remove it,
Use Converter		
Use Converter:Dev	ice N <mark>o</mark> de address	From: 1
📕 Set node range		To: 1
Select Display Tag		
С 1.РV		
C 2.PV and SV		

If the connection is working fine, the user can see the below figure. Upon clicking the icon shown in the red box, you are accepting the configuration

	📸 🖄 💭 😓	Modify	10 - 20	■ ‡ + + ‡] Delete =	*	
No.	Node Name	Tag Name	Bank	Use Converter	Node/IP	Device T
	All List	AI1 1	1	No	192.168.0.219	Recorde
1	Recorder(PR	AI2_1	1	No	192.168.0.219	Recorde
	2	AI3_1	1	No	192.168.0.219	Recorde
		AI4_1	1	No	192.168.0.219	Recorde
		AI5_1	1	No	192.168.0.219	Recorde
		AI6_1	1	No	192.168.0.219	Recorde
		AI7_1	1	No	192.168.0.219	Recorde
		AI8_1	1	No	192.168.0.219	Recorde
		AI9_1	1	No	192.168.0.219	Recorde
		AI10_1	1	No	192.168.0.219	Recorde
		AT11 1	1	No	192 168 0 219	Recorde

Click yes to apply the settings.



If you have set no password just click ok

-		
Password:		
	Change	
-	change ;	password
	🖌 ок	X Cancel

And after that you will see the below figure

P G		FR 🔲 🖾 🛄 🛙	Z 🔡 🖬 🖒 👌 🖪	R Recorder (VR 18)	P	()							4	13:40:58
													L BORS	
10058	ent/Alarm List			-		Bar-Page1								- 0 2
Ack	Туре	Source System	Active Time 11/20/14 13:39:47	Clear Time	Value/Content	1100.0	1370.0	400.0	800.0	18	20.0	1760.0	2012.0	2498.
	Login CT HIAlarm	All 1	11/20/14 13:39:4/		1088.1									
		A11_1	11/20/14 13:40:53			-200.0	-270.0	-270.0	-270.0	o 🛍 fo.c) <u>k</u>	-50.0	-328.0	A-454.
	📋 HiAlarm	A12_1	11/20/14 13:40:53					, 3308.0	3200.	0 18	0.0	20.00	20.00	2.00
	HiHiAlarm	A12_1	11/20/14 13:40:53		1220.8									
		AI3_1 AI13_1				-454.0	-454.0	32.0	-58.0	-64		0.00	-20.00	0.40
		A113 1				/ /0///0	15 110 1		5010			- 0100		
		A]14_1	11/20/14 13:40:53		83.33	5.00	6.00	2012.0	2498.	0 75	2.0	1472.0	3308.0	3200
	📋 LoAlarm	A116_1	11/20/14 13:40:53											
		A116_1 A117_1				10.00	-6.00	-328.0	-454.0		54.0	-454.0	32.0	-58.0
4														
						1 114								ATR 1
			m		,	AI1_1		A13_1	AI4_1					AI8_1
•		G		1	· · · · · · · · · · · · · · · · · · ·	A19_1	AT10_1	AI11_1	AI12_1					AI16_1
<	/ Adk 📕 🗸	(j All Alarn		Event/Cleared	,	2	AT10_1 AT18_1							
	/ Ack 🛛 🗸	(] All Alarn		Event/Cleared	, 0 8	A19_1 A117_1	AI 18_1	AI11_1	AI12_1					AI16_1 AI24_1
Dig	gital-Page1		Normal	A13-1		A19_1 A117_1 Trend-Page 1100.0	AI 18_1	AI11_1	AI12_1					AI16_1
Dig	gital-Page1 1095.	7 ***) Normal 1228.8	A13_1	286.9	A19_1 A117_1	AI 18_1	AI11_1	AI12_1	A113_				AI16_1 AI24_1
Dic	gital-Page1 1095.	7 *C) Normal 1228.8	A13_1 A16_1		A19_1 A117_1	AI 18_1	AI11_1	AI12_1	A113_				AI16_1 AI24_1
Dig 1_1 14_1	gital-Page1 1095. 530.7	7 •c	Normal	AI3_1 2 AI6_1 1 AI9_1	286.9 004.8	A19_1 A117_1	AI 18_1	AI11_1	AI12_1	A113_				AI16_1 AI24_1
Dig 11_1 14_1	gital-Pagel 1095.	7 •c	Normal	AI3_1 2 AI6_1 1 AI9_1	286.9	A19_1 A117_1 22 Trend-Page 1100.0 970.0 840.0 c 710.0 580.0	AI 18_1	AI11_1	AI12_1	A113_				AI16_1 AI24_1
Dig 111	gital-Page1 1095. 530.7 756.0	4 4 4 5 4 6 4 1 8 4 1 8 4 1 8 4 1 8 4 1 8 4 1 8 4 1 8 4 1 8 1 8	Normal 1220.0 1211.3 932.2	A13_1 A15_1 A15_1 1 A19_1 4112_1	286.9 004.8 119.6	A19_1 A117_1	AI 18_1	AI11_1	AI12_1	A113_				AI16_1 AI24_1
	gital-Page1 1095. 530.2 756.0	4 4 4 5 4 6 4 1 8 4 1 8 4 1 8 4 1 8 4 1 8 4 1 8 4 1 8 4 1 8 1 8	Normal	A13_1 A15_1 A15_1 1 A19_1 4112_1	286.9 004.8	A19_1 A117_1 22 Trend-Page 1100.0 970.0 840.0 c 710.0 580.0	AI 18_1	AI11_1	AI12_1	A113_				AI16_1 AI24_1
Dig 111	gital-Page1 1095. 530.7 756.0 473.1		 Normal 1220,0 1211,0 932,2 1630,1 	AB_1 AF6_1 AF6_1 AF6_1 1 AF6_1 AF6	286.9 004.8 119.6 551.1	A19_1 A117_1 100.01 970.01 840.0- < 710.0- 580.0- 450.0-	AI 18_1	AI11_1	AI12_1	A113_				AI16_1 AI24_1
Dig 191 14_1 17_1	gital-Page1 1095. 530.7 756.0 473.1 180.0		Image: Second	AIL1 AIL1 AIL1 AIL1 AIL1 AIL1 AIL1 AIL1	286.9 004.8 119.6	A19_1 A17_1	AI 18_1	AI11_1	AI12_1	A113_				AI16_1 AI24_1
Dig 121 4_1 7_1 1011	jital-Pagel 1095. 530.7 756.0 473.1 180.0		Itemal 1220,0 1220,0 1932,2 1630,1 83,33 71	AI2,1 AI5,1 AI5,1 AI2,1 AI2,1 AI2,1 AI15,1 AI15,1 AI16,1	286.9 004.8 119.6 551.1	A19_1 A19_1 110,0 900,0 840,0 550,0 550,0 10,0 10,0 10,0 10,0 10,0	A119_1	Af11_1 Af19_1	A112_1 0050_0	Atta (15) 1 Sec/Dot			A115_1 A123_1	A116_1 A124_3
Dig 1-1 4_1 7_1 110_1	gital-Pagel 1095. 530.7 756.0 473.1 180.0 0.00		Itemal 1229.9 1211.0 13932.2 14 932.2 15 1630.1 3 83.33 7J 16.67	AI2,1 AI2,1 AI5,1 AI5,1 1 AI5,1 1 AI12,1 1 AI13,1 6 AI13,1 6 AI13,1 1 1 AI13,1 1 AI5,1 1 1 AI5,1 1 1 AI5,1 1 1 1 1 1 1 1 1 1 1 1 1 1	286.9 004.8 119.6 551.1	A19_1 A19_1 A19_1 100.0 9700.0 9700.0 970.0 970.0 970.0 970	AT19_1 1 1 13:52:33 13:52:33 13:52:34	Alii_1 Alii_1 Alii_1 	A112_1 0000_0	4113_ 393] 1 Sec/Dot 13:35:53 11:35:53	1 AI AI		A115_1 A123_1	A116_1 A224_3
) Dig 131 141 17_1 10_1 10_1	gital-Pagel 1095. 530.7 756.0 473.1 180.0 0.00		Itemal 1220,0 1220,0 1932,2 1630,1 83,33 71	A12,1 2 A16,1 1 A13,1 1 A12,1 1 A12,1 1 A12,1 1 A12,1 1 A12,1 2 A12,1 1 A12,1	286.9 004.8 119.6 551.1	A19_1 A19_7 100.0 970.0	AT 19_1	Alii_1 Alii_1 Alii_1 	A112_1 0000_0	4113 	1 AI AI		A115_1 A123_1	A116_1 A129_3
Dig 121 421 721	gital-Pagel. 1095. 530.7 756.0 473.1 180.0 0,00 975.1		Itemal 1220,0 1220,0 1320,0 1320,0 1420,0 1320,0 1320,0 1420,0 1320,0 1320,0 1420,0 1420,0 1320,0 1630,1 1310,0 16,0 10,00,0	A13_1 A16_1 A16_1 A12_1 A12_1 A15_1	286.9 004.8 119.6 551.1 56.67 33.33	A19_1 A19_1 A19_1 100.0 9700.0 9700.0 970.0 970.0 970.0 970	AT19_1 1 1 13:52:33 13:52:33 13:52:34	A111_1 A119_1 13:54 13:54 13:54 13:54	A112_1 0000_0	4113_ 393] 1 Sec/Dot 13:35:53 11:35:53	1 AI AI		A115_1 A129_1	A116_1 A224_3

5.2.7 Removable Media

The steps are given below

- 1. In recorder, please insert an empty SD card or USB stick
- 2. In the recorder, press "Menu-More-Config". Press "Save"

Save	Configuration AI DI	
Load	-Math -AO -External -Display	▼
Default	 Timer Clock Communication Instrument Password: ******* Demo: Enable Auto-Output System Information 	*
onfirm Do you want to	save configuration to storage me	dia?



Press "Yes". It will save Recorder configuration files into USB stick.

Check contents of removable media. It should have the following files

ile Edit View F	avorites Tools Help	
🕃 Back 🔹 🔘	- 🏂 🔎 Search 🜔 Folders 🛄-	
idress 🗢 G:\		
File and Folder Ta	asks 🔕 FanelCfg BIN File	TagCfg BIN File

3. Remove the removable media from the recorder. Insert into PC

4. Double click the historical viewer icon at desktop and follow onscreen instructions to create a new project

Create a new project	
Create project type	
PR Recorder	
🗸 ок	X Cancel

Select PR Recorder. Click "OK"

Note: Above screen appears right away if no project files available in Computer

		1
Select file path		
Storage Media	C:\	
© Ethernet	192.168.0.1	

Select "Storage Media". Then enter the path to the Recorder files in USB stick or SD card. Click "OK"




Click "Yes". It will open Recorder configuration screen

	**:	\$ 🐴 [<u> </u>													
⊖ Channel – AI	AI1															
-DI	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	4
Math		Name	AI1				Desc			275	Τv	pe En	able •			-
- AO - DO				2									abre .			
External		Filter	Disab	le	•											
Display	- Lo	76	<u>ь т</u>			1				276.0	2276	,				
Tools		Da	ata Typ		10	*		Value Ra	5			/				
– Timer – Clock			Trigge	Enab	ole	•			Method	Insta	nt	•				
- Communication			Spee	d 100	ms/Dot	•										
- Instrument				a Terrar												
Password			Offs	et 0.0					Gain	1.0						
– Demo – Auto-Output	Se	nsor	Turne	-		Unit : C										
System Info			Туре	Inern	nocoupi	e J Type			•		Unit	. [-C	•			
			Range	-200.0) ~ 110	0.0			•							
	400	ents		enew na na		1.12		531		2.115	2.12	20				
	No	. Ty	pe	Setpoint		Log		Message		Job1	Job	2	Hysteresi	S		
	1	Н	•	840.0	Log A	larm	•		No	Action	No A	ction	0.0			
	2	L	•	60. <mark>0</mark>	Log A	larm	•		No	Action	No A	ction	0.0			
	3	НН	•	937.5	Log A	larm	•		No	Action	No A	ction	0.0			
	4	LL	•	-37.5	Log A	larm	•		No	Action	No A	ction	0.0			
	5	C.C.	•			-	•	-	Ne	Action	No A		0.0			

Note: The configuration screen is the same as the screen available directly in recorder. Please refer to Chapters 3 & 4 for more details about configuration

Do your required changes in the configuration. Click at Send configuration icon



6. Now, remove your removable media from the PC. Insert it into the Recorder. In the recorder, press "Menu-More-Config".

Press "Load"

Configuration		mem 4:50:13 41% 10/22/13
Save	Channel - AI - DI - Math	
Load	- AO External Display	•
Default	- Timer Clock Communication Instrument	
	-Password: ******* -Demo: Enable -Auto-Output -System Information	*

Select	×
Configuration	
Configuration	
Configuration	
Custom Page	
ОК	Cancel

Press "OK"

Confirm		
Do you want to load configur	ation from sto	rage media?
Yes	No	

Press "Yes"

5.2.8 Configuration

Please refer to Chapter 4 for full details related to configuration

5.2.8.1 Analog Input

- Channel								AI1					
	1	2 Name	3 AI1	4	5	6 7 De	8 SC	9	10	11 12	13 14 nable •	15	
Math AO		Filter	Disab	le	•								
-DO External	Lo	-	ta Typ	e 2 Byt	0		Valu	Range: -3	276.8	× 3276 7			
- Display ⊖ Tools			Trigge			•	Value		d Insta				
Timer Clock			Spee		ms/Dot	•			Contractor				
- Communication - Instrument			Offse	t 0.0				Gair	1.0				
-Password -Demo	Se	nsor	Type	Therm	ocouple	J Type		•		Unit : C			
- Auto-Output - System Info			Range		·~ 1100			•					I
	Ev	ents											
	No	. Ту	pe S	Getpoint		Log	Mes	sage 🛛	Job1	Job2	Hysteresis		
	1	H	•	840.0	Log Ala	irm	•	No	Action	No Action	0.0		
	2	L	•	5 <mark>0.0</mark>	Log Ala	irm	•	No	Action	No Action	0.0		
	3	HH	•	937.5	Log Ala	irm	•	No	Action	No Action	0.0		
	4	LL	•	- <mark>37.5</mark>	Log Ala	irm	•]	No	Action	No Action	0.0		
	5	Error	•]	0.0	Log Ala	irm	•	No	Action	No Action	0.0		-

5.2.8.2 Digital Input

Channel			DI1										
AI DI	1 2	2 3 4											
Math		News DH											
AO		Name DI1											
External													
-Display		Desc Tank level	high										
🖬 Tools													
Timer		Type Logic Leve	el 🚩										
Clock	- Events												
Communicati	No. Type	Log	Message	Job1	Job2								
Instrument		LOG	i™essuge	1 1001									
Password	1 Disab 🗸	No Action	→	No Action	No Action								
Demo													
-Auto-Output	2 Disab 🛩	No Action	*	No Action	No Action								
System Info													

5.2.8.3 Math channel

Ghannel AI						Math1							
-DI	1	2	3	4 5	6	7 8	9	10 11	12 🔹 🔹				
-Math -AQ		Nar	ne Math	1		Desc Totalizer 6							
External		TV	pe Math										
Display													
Tools	Log												
Timer		Data Type 4 Byte Value Range: -3.4E+38 ~ 3.4E+38 Trigger Enable Method Instant											
Clock													
Communicati Instrument			Speed	100 ms	s/Dot 🔽								
Password													
Demo		Expres	sion (AI	1+AI2)/2	2								
Auto-Output		Scale -							-				
System Info			Unit	-		Transfo	rmation Valu	ue 💉					
			Decimal	0	~		Table Poir	nt 1 to 2					
			Range;	0~10									
	Eve	ents											
	No	o. Type	Setpoint		Log	Message	Job1	Job2	Hysteresis				
	1	Н	0	No Acti	on 🖌		No Action	No Action	0				
	2	Disab 🗸	Ō	No Acti	on 💌		No Action	No Action	0				
	3	Disab 🛩	0	No Acti	on 💌		No Action	No Action	0				
	4	Disab 🛩	0	No Acti	on 💌		No Action	No Action	0				
	5	Disab 🛩	0	No Actio	on 🍾		No Action	No Action	0				

5.2.8.4 Analog Output

Channel AI	A01
-DI	1 2
Math	Desc
- <mark>AO</mark>	
External Display	Type: Current
Tools	
Timer	Output 4-20mA
Clock	Expression 4+(20-4)*(AI1-(-120))/(1000-(-120))
Communicati	
Instrument Password	
Demo	
-Auto-Output	
System Info	

5.2.8.5 External Channel

🖻 Channel	External1								
-AI -DI	1 2 3 4 5 6 7 8 9 10 11 12 🔹								
Math	Name Ext1 Desc								
AO									
External	Type Enable								
Display	Log								
	Data Type 2 Byte 🔹 Value Range: -32768 ~ 32767								
Timer Clock	Trigger Enable 🗸 Method Instant 🗸								
Communicati									
Instrument	Speed 100 ms/Dot								
Password	Modbus Register Value(MV) Conversion								
Demo	Data Type 2 Byte								
-Auto-Output	Formula: ((MV-RL)/(RH-RL))*(SH-SL)+SL								
System Info									
	Range Low(RL) 0.0 High(RH) 65535.0								
	Scale								
	Unit								
	Low(SL) 0.0 High(SH) 65535.0								
	Events								
	No. Type Setpoint Log Message Job1 Job2 Hysteresi:								
	1 Disab 🗸 O No Action 🗸 No Action No Action O								
	2 Disab 🖌 0 No Action 🗸 No Action No Action 0								
< III >									

5.2.8.6 Display

Channel				Dis	pla	ay1				
	2	3	4	5 6 7	7	1	8	9 10	11 12 🔨	
Math	Na	me Pag	je1	Mode	Mode Trend 👻 Direction Horizontal					
-A0 External	Spe	Speed 1 Sec/Dot V Background Black V								
Display	- Pen-	[12					
De Tools	N	o, (Channel	Color		Wie	đth	Display Low	Display High	
Timer Clock	1	AI1	~	Blue	-	1	~	-120.0	1000.0	
Communicati	2	AI2	~	Lime	-	1	*	-200.0	1370.0	
-Instrument Password	3	AI3	~	Cyan		1	*	-250.0	400.0	
-Demo	4	AI4	~	Red	-	1	~	-100.0	900.0	
Auto-Output System Info	5	AI5	~	Magenta		1	~	0.0	1820.0	
,	6	AI6	~	Yellow	-	1	*	0.0	1767.8	
	7	AI7	*	Gray	•	1	~	0.0	1767.8	
	8	AI8	~	Dark Blue	•	1	*	-250.0	1300.0	
	1.[is Bar Typ Disable Disable		e V 2. Disable 6. Disable			-		4. Disable 3. Disable	

5.2.8.7 Timer

Channel	Timer1							
-DI	1 2 3 4 5 6 7 8 9 10 11 12							
Math AO	Type Daily Action Enable							
External								
Display	Time							
🖶 Tools	Day Hour Min Sec							
Timer								
Clock								
Communication								
Instrument	Events							
Password								
Demo	Job1 Print Report List Job2 No Action							
Auto-Output								
System Info								

5.2.8.8 Clock

Channel	Clock
AI DI Math	Date Style MM/dd/yy
-AO -External -Display -Tools	Date/Time Synchronization Date : 10/18/13
Timer <mark>Clock</mark>	Time : 22:48:06
Communication Instrument Password Demo Auto-Output	Date/Time Synchronization is to adjust the clock of the recoder and then the system date/time of both PC and recoder will be the same. It only functions when you press 'Synchronize' button below.
System Info	Synchronize
	From 04 🖌 / 01 🖌 02 🖌 : 00 🖌
	To 10 🗸 / 31 🗸 03 🖌 : 00 🗸

5.2.8.9 Communication

File(F) Edit(E) Lange	uage(L) He	lp(H)				
🖹 🖻 🖶 🗙 😫 ᆃ	: + + ≠	1				
- Channel					Ethernet	
- AI - DI	Ethernet	Serial Mod	bus Client/Maste	er Email		
Math		Seria Tioa	ous energy lust			
AO		Web Server	Enable	-		
- DO			Lindbite			
External		IP	Automation	-	Modbus TCP Port 50	2
- Display			, latonation			
Tools		DNS Server	168.95.1.1			
- Timer - Clock						
Clock Communication						
Instrument						
Password						
- Demo						
-Auto-Output						
System Info						
4	1					

Channel	Serial	
-AI -DI	Ethernet Serial Modbus Client/Master Email	
Math AO DO External	RS232/485 Protocol Modbus Slave Address 1	
Display Fools Timer Clock	Baud Rate 115200 Data Format No.8,1	•
Communication Instrument Password Demo Auto-Output System Info		

📮 Channel	Modbus Client/Master							
AI								
DI	Ethernet Serial Modbus Client/Master Email							
Math	Connections							
-AO								
External	1 2 3 4 5 6 7 8 9 10 11							
Display								
Tools	Name Connect1 Type Serial Slave ID 1							
Timer								
Clock								
Communication								
Instrument	Commands							
-Password	1 2 3 4 5 6 7 8 9 10 11							
-Demo								
Auto-Output	Action Enable 👻 Connection Connect1 👻							
System Info								
	To Channel							
	First Ext1 🔹 Last Ext1 👻							
	From Device							
	Type Input 🛛 Start Address 1							
	Data Type Inti6							
	Comple Data							
	Sample Rate							
	Ethernet 1 Sec/Dot 👻 Serial 1 Sec/Dot 👻							

Channel				Email	
AI			L L / L L Franci		
	Ethernet Seria	I Modbus Cli	ient/Master Email		
Math			Email Enable	•	
AO	SMTP Serve	er			
-DO External		brainchild.co	m.tw	Authentication	Enable 🔹
Display	Port	25		User Name	vasudev
Tools					
Timer	User	vasu		Password	*****
Clock		Address			
Communication	,		service@brainchild.co	and the	
Instrument		FIUIII	service@brailiciliu.co	JIII.tw	
Password		To 1	sales@brainchild.con	n.tw	
Demo		2			
Auto-Output					
System Info		3			
		4			
		5			
		J			
		6			

5.2.8.10 Instrument

Channel						Bas	ic	
- AI - DI - Math	Basic	Security Tool	Bar	Scan Page	LCD		System Event	96 11
- AO DO		Langu	lage	English		•	Volume	Disable
External Display		External Stor	rage	SD card		•	Data Transfer	Transfer and Remai
Fools Timer Clock		Batch Cor	ntrol	Disable		Ŧ		
Communication								
Password Demo								
Auto-Output System Info								

🕞 Channel					se	curity			
AI	Basic	Security	Tool Bar	Scan Page LCE	\mathbf{r}	Custom Page			
DI									
Math		Secu	rity Mode	Normal	~	*	Logout	Disable	~
-AO			·						
External		Passwor	d validity	Unlimited 🔽					
Display									
🖻 Tools									
Timer									
Clock									
Communication									
Instrument									
Password									
Demo									
-Auto-Output									
System Info									

🖙 Channel	
AI	Basic Security Tool Bar Scan Page LCD Custom Page
DI	
Math	Auto Hide Disable
AO	
External	
Display	
📮 Tools	
Timer	
Clock	
Communication	
Instrument	
Password	
Demo	
-Auto-Output	
System Info	

🖙 Channel				
AI	Basic Security	Tool Bar Scan F	Page LCD	Custom Page
DI				
Math		Idle Time	Disable	~
-AO				
External				
Display		Scan rate	5 Sec	~
🖻 Tools				
Timer				
Clock				
Communication				
Instrument				
Password				
Demo				
-Auto-Output				
-System Info				

📮 Cl	nannel										
	AI	Basic S	Security	Tool E	3ar Sca	an Pa	ige l	_CD	Cust	om Pa	ge
	DI										
	Math				Brightn	iess	4			~	
	AO										
	External										
Di	splay			So	reen Sa	iver	Disa	ble		~	
⊨ To	ools										
	Timer										
	Clock										
C	ommunication										
In	strument										
Pa	assword										
De	emo										
A	uto-Output										
Sy	stem Info										

🖙 Channel		i ioniory evolve
AI	Basic Securi	ity Tool Bar Scan Page LCD Custom Page
-DI		
Math		
AO		
External		
Display		Allow download via ethernet 🛛 Enable 🛛 🗸 🗸
Tools		
Timer		
Clock		
Communication		
Instrument		
Password		
Demo		
Auto-Output		
System Info		

5.2.8.11 Password

🖻 Channel	Security Password
AI	
DI	
Math	
-AO	
External	Password
Display	
Tools	
Timer	
Clock	
Communication	
Instrument	
-Password	
Demo	
-Auto-Output	
System Info	

5.2.8.12 Demo

Channel	Demo	
AI DI		
Math		
AO		
External		
Display	Demo	Enable 🔽
Tools		
Timer		
Clock		
-Communication		
Instrument		
Password		
Demo		
Auto-Output		
System Info		

5.2.8.13 Auto-Output

Minutes
, mates

5.2.8.14 System Information

🖻 Channel	System Info		
-AI		· · · · · · · · · · · · · · · · · · ·	
DI	Version	0.80B9 Plus	
Math	00000	0.0000 1100	
AO	Slot1	AI1,AI2,AI3,AI4,AI5,AI6,AI7,AI8,AI9,AI10,AI11,AI12	
External			
Display	Slot2	AI13,AI14,AI15,AI16,AI17,AI18,AI19,AI20,DI1,DI2,DI3,DI4	
🖬 Tools		,A01,A02	
Timer			
Clock			
Communication			
Instrument			
Password			
Demo			
Auto-Output			
System Info			

5.2.9 How to view Historical data

There are three ways to view Historical Data

- 1. Touch screen
- 2. Ethernet
- 3. USB stick

5.2.9.1 Touch Screen

Please refer Chapter 3 for details how to view historical data in directly from the recorder using the touch screen


5.2.9.2 Ethernet

Note: Please read the following sections first

- 1. How to configure Communication bank
- 2. How to configure Recorder Ethernet

Make sure your Project has already been created and saved in your computer. Then set bank to Ethernet before proceeding with the following steps

Open Project from Historical viewer using one of the following options



Start-Programs-Historical viewer-Historical viewer

Open	
Look in:	🛅 Historical
My Recent Documents Desktop	Project1


Select Project and click "Open"

🗠 Display measured values from histor	rical data of E:\Program Files	\Historical Viewer\Historical\Pro	ject1.daq
File(F) Edit(E) View(V) Display(D) Page(P)	Search(S) Language(L) Help(H)		
📔 🚵 😓 🛛 📰 📾 📾 🖌	: 🔒 🍈 🗠 🔒 آف	🕇 🔶 🕂 🛨 🏛 🔍 🔍 🔍 Zoor	n Size 💽 🛃
🗐 🔁 🔎 🛛 1 Scale 💽			
Import measured data	AI2		AI3
	°C		°C
1300.0			ľ
1145.0-			
990.0-			
835.0-			

Click Import measured data icon 훰

Update	
Please wait a moment	
Data dumping \DataLog\20131021\P50.dat	
	23%
Cancel	

Note: Time taken based on amount of data available in internal memory



Press anywhere on the trend area, then click at Zoom icon and then see the historical trend clearly

Note: Please read "Historical viewer" help file from software itself for all the features available in Historical viewer software

5.2.9.3 Removable Media

Note: Please read the following sections first


- 1. How to configure Communication bank
- 2. How to configure Recorder viaSD card or USB

Make sure that if a project has already been created, and the settings and data are stored on an SD card or USB, set the bank to "Storage media" before proceeding with the below steps:


Insert Empty - SD card or USB in Recorder

Press "Menu-More-Dump"





Select "All" or one of the other available options, then press "OK"



Press "Yes"

Data Dumping4%	
Cancel	

Recorder	
Now alarm dummping	

Now, remove USB stick from Recorder


Check contents in the USB stick



Open Project from Historical viewer using one of the following options

Desktop: Historical viewer icon


Start-Programs-Historical viewer-Historical viewer



Select Project and click "Open"

Display measured values from histor	rical data of E:\Progr	am Files\Historical View	ver\Historical\Project1.do	aq
File(F) Edit(E) View(V) Display(D) Page(P)	Search(S) Language(L)	Help(H)		
DA& 🖩 🗗 🗗 🖌	🖄 🎼 🔂 🚳 🛛 🧿	≗ + + ≠	🍳 🍳 🍭 🛛 Zoom Size	
🛱 🚵 🔎 1 Scale 🛛 💌				
Import measured data		AI2		AI3
	٥	c .		°C
1300.0				Ĩ
1145.0-				
990.0-				
835.0-				

Click Import measured data icon 勉




Note: Time taken is based on the amount of data available in internal memory

Import	
Please wait a moment	
Data linking P78.dat	
	37%
Information	×
Do you want to delete storage media data ?(Y,	/N)

Select "Yes" if you wish to delete data from USB stick.

Select "No" only if you have plans to transfer data to another Computer or if you have plans to maintain data storage as back up in proprietary format in a Computer hard disk



Press on any area of the trend screen, then click at Zoom icon and then see the historical trend clearly

Note: Please read "Historical viewer" help file from software itself for all the features available in Historical viewer software

5.2.10 How to view Real time data in PC

It is possible to monitor Real time data from paperless recorder on your PC

For this, the recorder should be connected to a PC via Ethernet or Serial network (RS232/422/485). Set bank appropriately to proceed with required option.

5.2.11 Bank configuration

How to open Real time viewer

There are two ways to open Realtime Viewer



Click the desktop icon

Start-Programs-Data Acquisition Studio Studio-Real time viewer

💔 Creat	e a new project 🔀
	Enter the new name : Project1
Informat	ion 🛛
2	There are no tag data in the project $!!$ Do you want to configure it $?(\ensuremath{Y}\xspace/\ensuremath{N}\xspace)$
	Yes No

Click "No"

RealTime Configure					
🖶 😫 🗙 🕮 🔈	1 🔁 🔪 🖻 🖇	i 🖬 🚷 🥅	‡ + → ‡ 💱 🕻	D	
Add					
No. Node Name	Tag Name	Bank	Use Converter	Node/IP	

Click bank icon 😰

🕸 Re	ealTi	me	Confi	gure		
		×		ð	<u>a</u> \	<u>\</u>
1	2		3	4	1	Bank1
	15		1.0	,		Protocol: Modbus_TCP
						Ethernet
						Port : 502
						Format : Standard

A total of 4 communication banks are available

Each bank can be configured as Either Modbus Serial (232/422/485) or Modbus_TCP (Ethernet)

For example: If two Paperless Recorders are coming on two different RS485 networks, then each bank can be configured for each individual Recorder. This is provided that two COM ports are configured in PC to receive data from two different serial networks. You may use two USB to Serial converters for this application (See our UPort1150).

After completing the bank setup, click "Save" icon 🗟. To close, click the return to main program icon 🧕

Informat	tion 🛛 🛛
2	To let the new Bank setting take effect, system will save them then restart !! Continue ?(Y/N)
	Yes No

5.2.12 Ethernet

- 1. Install Data Acquisition Studio software
- 2. Set bank radial button to Ethernet
- 3. If the recorder is connected to the PC via Ethernet, make sure recorder is set with a User defined IP address and domain that is the same as the PC

Use Ping instruction from the Dos prompt, make sure the recorder is communicating with the PC via Ethernet

Command Prompt Microsoft Windows XP [Version 5.1.2600] (C) Copyright 1985-2001 Microsoft Corp. E:\Documents and Settings\Mahi>ping 192.168.0.11 Pinging 192.168.0.11 with 32 bytes of data: Reply from 192.168.0.11: bytes=32 time<1ms TTL=128 Ping statistics for 192.168.0.11: Packets: Sent = 4, Received = 4, Lost = 0 (0% loss), Approximate round trip times in milli-seconds: Minimum = Oms, Maximum = Oms, Average = Oms

4. Create a new project in Data Acquisition Studio software and monitor real time data from Recorder directly from PC


How to open Real Time Viewer

There are two ways to open Real Time Viewer



Start-Programs-Data Acquisition Studio Studio-Real time viewer

89 C	reate a new project	X
	Enter the new name : Project1	
	OK Kancel	



Click "Yes"


😵 Auto-configuration	
Device Type: PR Recorder	Bank: 1 💌
Protocol: Modbus_TCP	🔽 Auto-update the Tag contents
LogSpeed: Auto	LogMethod: Auto
IP address Input Format: IP address Example: 192.168.0.25 I92.168.0.11 IP List:	 Please key in IP here and then press '+' button to add it to the IP list. - Please select one IP form IP List and then press '-' button to remove it.
Use Converter Use Converter:Device Node address Set node range	From: 1
	✓ OK X Cancel

IP address		
Input Format:	IP address 💌	
Example: 192.168.0.25		Please key in IP here and then press '+' button to
IP List:	192.168.0.11	+ add it to the IP list.
		< Please select one IP form IP List and then press '-' button to remove it.

Click "OK"

🏶 Re	🕸 RealTime Configure 📃 🗖 🔀							
	★ Add Add Image: Second sec							
No.	Node Name	Tag Name	Bank	Use Converter	Node/IP	Device Type	Tag Type	
	All List	AI1_1	1	No	192.168.0.11	PR Recorder	Channel_1	
1	PR Recorder_1	AI2_1	1	No	192.168.0.11	PR Recorder	Channel_2	
		AI3_1	1	No	192.168.0.11	PR Recorder	Channel_3	
		AI4_1	1	No	192.168.0.11	PR Recorder	Channel_4	
		AI5_1	1	No	192.168.0.11	PR Recorder	Channel_5	
		AI6_1	1	No	192.168.0.11	PR Recorder	Channel_6	

Click "Save" icon 🖶. To close, click the return to main program icon 🧕



Note: When real time viewer is running in PC, data will be stored on the computer hard drive. This data can be archived later from Real time viewer itself using the "Measured data" icon. This data is same as the recorder's internal memory (Historical data).

In the case of a PC running round the clock (like a server), there may be no need to manually transfer historical data from Recorder to PC via Memory stick.

Note: Please read "Real time viewer" help file from software itself for all the features available in Real time viewer software

5.2.13 Serial (RS232/422/485)

The procedure is similar to Ethernet. But the bank must be set for Modbus Serial.

5.2.14 View Real time data from Multiple Recorders

Assume one Recorder database has already been added in Ethernet using IP address 192.168.0.11

Target: Connect a second Recorder, IP address 192.168.0.12 to the Real time viewer

Connect both the Recorders and PC to Ethernet switch

Use "Ping" instruction at DOS prompt and check communication between PC and two Recorders. If there is no response, then check IP address in all the devices. Also check Ethernet cables.

If there is good response from Recorders using the "Ping" instruction, Open Real time viewer

😻 Display real-time measured value							
File(F)	/iew(V)	Page(P)	Window(W)	La			
				25			

Click "Configuration data" icon 🤷

🕸 RealTime Configure								
	Add Modify							
No.	Node Name	Tag Name	Bank	Use Converter	Node/IP	Device Type	Tag Type	
	All List	AI1_1	1	No	192.168.0.11	PR Recorder	Channel_1	
1	PR Recorder_	AI2_1	1	No	192.168.0.11	PR Recorder	Channel_2	
		AI3_1	1	No	192.168.0.11	PR Recorder	Channel_3	
		AI4_1	1	No	192.168.0.11	PR Recorder	Channel_4	
		AI5_1	1	No	192.168.0.11	PR Recorder	Channel_5	
		AI6_1	1	No	192.168.0.11	PR Recorder	Channel_6	

Click "Add"

	🔽 Auto-uj	odate the Tag contents			
Device Type: Recorder(PR)	▼ Ban	k: 1 💌		Tag Name: Auto	
Protocol: Modbus_TCP	Use Converter:De	vice Node address	1	IP address:	
Log Trigger: by Time	v	LogSpeed: 1 Se	ec/Dot 👻	LogMethod: Instant	
Data Byte Type: 4Byte		Logopeed. [13		Logine diod. Instant	

Select Device Type = PR Recorder

Deselect checkbox next to "Auto-update the Tag contents"


Enter IP address of second Recorder. (Make sure to select user define IP address in Recorder. Do not select "automation")


Click "OK"

Now, second Recorder database will add to Real time viewer.

5.3 Panel Studio version

Using this software you can develop custom screens for your display same as SCADA. All the graphics developed on the screens can also be configured for animations.





Use this editing software to develop animation screens on the Recorder. It is mainly used for application development useful for operator interface in industrial applications. Using Screens, operators will be able to communicate with PLC's, inverters etc. via COM ports, the Ethernet port, on Modbus RTU or Modbus TCP/IP. Using this software, it is possible to develop operator interface applications like the following.

Sending start/stop command from Recorder to PLC to start motors, pumps etc. Display running stats of motors, pumps etc.

Display Real time value of process parameters like temperature, flow, pressure etc Visualize process data in meaningful ways such as bar graphs, dial, meter, level, digital LED etc.

Animation like visibility control, blinking, horizontal movement, vertical movement etc.

5.3.1 System Requirements

Recommended hardware: PC with 2 GHz processor, 1GB RAM 50GB free space in the hard disk. Ethernet port, RJ 45 female Minimum 20% free space in hard disk, Less than 10% space generates error message RS 232 serial port, RS485/RS232 converter to check online simulation if required

USB host to insert USB flash disk

Screen resolution better than 1024 X 768 (For Recorder 10" and 1550 projects)

Operating system: Windows XP, Windows Vista, Windows 7, Windows 2000 & Windows 2003 Server

5.3.2 Software Installation

Install Microsoft installer V3.1

Install Microsoft.Net frame work V3.5 SP1

Install Editing Software

Install OPC server

Install Demo projects

Install Historical viewer

Install Remote viewer



If any folders or files are deleted manually from C:\Program Files\Panel Studio, then delete a file by name "BCFile" manually from C:\WINDOWS before attempting to start new installation process. Otherwise, you may get error message "Access Violation".

5.3.3 Project status

During design time, it is possible to check current status of resources being used

File	Edit	Format	View	Objects	Pro	oject	Help	
🛅 - 👌		0 🕹 🐁	👌 🛍 🕽	< 🗚 🏢		Build		F6
(# 4)	ê E	후 릐 [0 <u>07 001</u> -0	• ☴ (i) 원		Build	And Offline Simulation	F7
Toolbox		д	×	creen1 Scree		Build	And Online Simulation	F8
						Onlin	e Simulation	
						Stop		
						Build	And Download	
						Dowr	nload	
						Proje	ect Status	


🔚 Project Status		
	Total	
Tag	40	
Objects	450	
Image	66	
Connection	0	
Alarm	5	
Recipe	0	
DataLog	4	
Scheduler	2	
UserScript	2	
Security	1	
Language	5	
Project designed time		
0 Days	17 Hours	55 Minutes

"Image" means symbols used from graphics and symbol factory. These symbols are also considered objects, so, if you add symbols, it also updates quantity in objects.

For example: If you add 2 symbols and one rectangle object. Then, Images = 2, Objects = 3

5.3.4 Create new project

Open Recorder Editing Software from desktop icon or from Start-Programs-Recorder **Editing Software**



New Project		×
Name	e Panel Location	
Resolution	n Language English	
Width	h 480 Height 272	
Author	v Version 1	
	Password	
Comment		
		*
	OK Cancel	

Click on "Create a new project"

Project Name: It is Name of the Project. For ex: Boiler
Location: It is path for project file storage.
Default Language: English
Width: It is pixels, resolution in dots available on X-axis
Height: It is pixels, resolution in dots available on Y-axis
Author: Write author name/system integrator name for future reference
Version number: It is for version management
Comments: It is for project management
After entering all the above details, click "OK"


File	Edit	Format	Vie	w Ob	jects I	Project	Help		
🗊 • 🖻	H 6	0 3	6		A III 1	🔠 🕨) 🛛 🛔	100%	•
1 5 51		홍 릐	allt allt	아 글	前題	1 000 P			
Toolbox	1	,	×	Screen1	Screen2	Screen	3 Screer	^{100%} 125%	
Basi	c Objec	ts						150%	
Enha	anced O	biects						175%	
19863764	and the second	ATT SOUTH						200%	

	Menu bar	Stand	ard bar / Format bar
File Edit Format V	iew Objects Project	Help	
	🚨 🗙 船 🟢 拱 🛗 📂) 🙆 🧕 100%	
(19 ● 10 ● 10 ● 10 ● 10 ● 10 ● 10 ● 10 ●	■ ● 印 田 昭 章 ● :	방 및 및 을 찾 랆 ㅎ	\$ 臣 • 〕
Toolbox 4 ×	Screen1 Screen2 Scree	n3 Screen4 Screen5	Screen6 Screen7
Basic Objects			
Enhanced Objects	Tool box		
SymbolFactory			
Graphics			

5.3.5 Menu bar

File Edit Format View Objects Project Help

5.3.6 File



New: To create a new project

Open Project: To open existing project

Close Project: To close present project

Save Project: To save Project in default path

Save Project As: Saves project in selected path other than default path specified while creating a new project settings.

Upload: To upload project from Recorder back to PC

Recently: It is to open recently opened projects

Exit: To exit from current project

Language: To update language files in Recorder. This is required only if a new language required at Control Center. Contact factory for further information

Clock Synchronization: To synchronize recorder clock with PC clock.

5.3.7 Environment

🔚 Environment		
General Download and Upload Snap and Grid Object default setting	Environment Language English TextFont Microsoft Sans Serif, 8.25pt	
	DateTimeFormat DateFormat TimeFormat	
	Path Project	
	Security Password Confirm	

General:

Language: Select Language for project environment. 20 languages are supported from Recorder editing software V1.1 onwards including English, Simplified Chinese, Traditional Chinese, Japanese, French, German, Italian, Polish, Spanish, Portuguese, Brazil Portuguese, Russian, Thai, Czech, Danish, Dutch, Korean, Swedish, Turkish & Greek.

Environment font: Select font required for design time environment. Example: Menu, Tool Box, Project explorer, function editor etc.

Project Path: Location to storage of project files Default project path: C:\Program Files\Recorder Editing Software\Recorder Editing Software\PanelProject

Graphic Path: Location of default basic Symbols Default graphic path: C:\Program Files\Recorder Editing Software\Recorder Editing Software\Basic Symbols

Security: This is to protect opening Recorder editing software in specific Personal computer (Not for project). Once password is entered, it is required to enter password correctly to open Recorder editing software for the current session. This is useful in factory environment to prevent un- authorized users to open Recorder editing software.

Note: If you need a password for a specific project, click "Settings" in the project explorer, select "General" tab, then enter the Password.

In general, it is preferred to back up project files regularly in other standard storage media like CD, DVD etc. It is recommended to store project files in separate folders on the D: drive instead of C: drive. Developers may make a hard disk partition and save all project files in drives other than location of operating system in the event that if there are problems with Operating system, it is still possible to retrieve project files.

Download and Upload: Please refer to section "Project tools" for more detailed information.

🔡 Environment		
General Download and Upload Snap and Grid Object default setting	⊂Type	
	Show Size X 2 Y 2	⊠ Snap


Snap and Grid: Used to define grid behavior in the design time environment.

- *Grid*: Select this option and select "Show grid" if grids are to be appeared in screen at design time.
- **Snap lines**: Select this option if grids are not required to appear in screen at design time.
- Snap: Select this option if component coordinates should within grids all the time.


🔚 Environment	
General Download and Upload Snap and Grid Object default setting	TextFont
	Name Tahoma 💌
	Size 12 Style Bold -
	FillColor
	Enable
	BackColor
	Enable
	ForeColor
	Enable

Object: Define default font size, Fill color, Back color and Fore color for the properties of most of the objects (label, Check box, Rectangle, Ellipse, Pie, Table, Dial, Level, Meter, Slider, Thermometer etc.).

5.3.8 Edit



5.3.9 Format




Align: Used to align selected components, objects etc. for adjusting their position precisely in the screen layout. Available options for selection are Center, Right, Left, Tops, middle & Bottom.

Example: Align two Labels to the left in Recorder screen.

Assume both labels are created in Screen1. Select both labels first using your mouse. Alternatively, select first label by left clicking the mouse, then press "Ctrl" on the keyboard and select the second label by left clicking the mouse. Now, in Menu, click "**Format**", then select "**Align**", then select "**Left**".

Before Align adjustment

After Left Align adjustment



Make Same Size: To adjust different objects to the same Width, Height, Both width and height, Size to grid etc.

Example: Adjust five buttons to same size i.e., height and width.

Create five buttons first. Then, select all these buttons via Mouse, then click "**Format**", then select "**Make same size**", then select "**Both**"

Before size adjustment



After Same Size adjustment



Horizontal spacing: It allows adjustment of horizontal spacing between any objects to make Equal/Increase/Decrease/Remove.

For example: There are 3 buttons located at bottom area of a page. Spaces between these buttons are not equal and screen does not looking good. Select all the 3 buttons via Mouse or using "Ctrl" on the keyboard along with mouse. Then in Menu bar, click "Format", then select "Horizontal spacing", then select "Make equal". Now, space between all these buttons with have an equal distance.

Before Spacing adjustment




After Horizontal spacing adjustment



Vertical spacing: It allows adjustment of vertical spacing between any objects to make Equal/Increase/Decrease/Remove

After vertical spacing adjustment

Before Spacing adjustment



Center in Page: It allows adjustmenting objects to the center of the page horizontally and vertically.

For ex: There are 3 buttons located at screen. You wish to locate them in the center of the page horizontally. Select these buttons and apply this feature to adjust buttons as per requirement.

	1	e				1	1		1	
	1								1	
										FirstPage
	1								1	
										NextPage
	1								1	· · · · · · ·
	1								1	· · · · · ·
										Previous
	1								1	· · · · · ·
	1								1	
										LastPage


	Tei	mp	lat	e									X
			1	1		1		1					
			•	1		1		1				• •	
·	÷	·	÷	÷	÷	÷	÷	÷	÷	÷			
											FirstPage		
											NextPage		
											Henti ugo		
			1	1		÷.		÷.		÷.,	Description		
											Previous Presenter Previous		
										1			
						1		1		1			
			•								LastPage	• •	

Order:

Bring to back: Moves objects to the back

Bring to Front: Moves objects to the front

For example: There is Rectangle box and a label with different colors. If you wish to keep label text in front of the Rectangle, select the Rectangle, choose the option, "Bring to Back" and for the label, choose the option "Bring to Front", such that both are visible at same time allowing overlapping of two objects for clear display.




Lock Controls: It is to lock control for further development. Apply this for a second time to unlock the control.

5.3.10 View



Select the required items to view in window layout. *Properties*

If "properties" is checked as shown above, in the right side bottom of screen layout, the properties box will appear showing all the properties for the component/object that is selected.



In above example, a rectangle is drawn, and once it is selected, the right side bottom corner will show all the properties for this specific rectangle if "properties" is checked

in the View dropdown menu. It is possible to modify properties of the rectangle from property grid. Alternatively, if you double click on the rectangle, you will see a pop-up window where you can edit properties.

Output

If output is selected in the view drop-down menu, this window appears just below the screen working area. This window will display any errors that appear during compilation of project.

In Menu, click "Tools", then "Build", or alternatively, on the "standard" bar, click the icon icon to prepare the build for the application. The project will then compile. A summary is shown in the output window as shown below.

Output
Screens preparing Check automatic of scan Screen1 images 0 / 0 objects 1 / 1 Conversion checking UserScripts checking Objects checking Alarms checking Scheduler checking
Datalogs checking Recipes checking
Build started Build succeeded.

Zoom

It is used to Zoom the current screen to various %, and it is useful during screen editing, particularly if screen size of PC screen is small. If 200% is used and if PC screen size is small, then horizontal and vertical slider will appear automatically in screen to navigate to other areas of screen easily.

Full screen

It is to display full screen. After selection, the screen layout will be as shown below. To go back, in menu, click at "View" and then "Full screen" again

Reset window layout

Used to display the default screen layout showing the screen working area, tool box, project explorer, output window etc.

Ex: If user deselects the "project explorer" in the View drop-down menu, then it will not show the Project explorer at the right side of the window layout. In this case, the user may select Project explorer again in the View drop-down menu. Alternatively, in Menu, click "View", then "Reset Window Layout", then it will reset all the view selections and show default window layout.

5.3.11 Objects

Objects		Project	Help		
	Basic Objects				
	Enhanced Objects				
	SymbolFactory +				
	Graphics				

More details about Basic objects, Enhanced objects, Symbol factory and Graphics are explained in section "Tool Box"

0	bjects Project	Help			
	Basic Objects	•			
Enhanced Objects		cts ▶			
	SymbolFactory	•			
	Graphics				
-	Basic Objects				
×	Pointer	\sim	Line		신 Polygon
	Rect	\circ	Ellipse		Arc
■	Table	1 0	NumericUpDown		DigitalLED
123	DigitalBox	abl	TextBox		${f A}$ Label
A	DateTimeLabel		AlamBanner		ab Button
.	BitLamp) <mark>@</mark> (WordLamp		CheckBox
t 🖃	Combo Box	= 0	ListBox		GroupPanel
	Enhanced Objects				
R.	Pointer	🚦 Le	vel	T	Meter
-	Slider	🗓 Th	ermometer		BarBox
Eł	Scale	🔏 Pie	ctureBox		

If you would like to increase font size in Menu bar, then, in menu, click File, then click "Environment" and then set font settings.

5.3.12 Project

Pr	oject	Help			
	Build	I	F6		
	Build	F7			
	Build And Online Simulation F8				
	Online Simulation				
	Stop				
	Build	And Download			
	Dow	nload			
	Proje	ect Status			


Above details are explained at section "Project Tools"


5.3.13 Standard bar

🤁 • 🕼	3日 30日 11日 11日 11日 11日 11日 11日 11日 11日 11日 1
	New Project
2	Open Project
	Save Project
0	Undo
0	Redo
*	Cut
þ	Сору
B	Paste

×	Delete
A	Search
#	Show Grid
4	Align to Grid
**	Build
	Offline Simulator
	Online Simulator
8	Stop simulation
	Download
	Full screen

5.3.14 Format bar





5.3.15 Project Explorer



5.3.16 Screen


This is to add new screen to the project.

- It is possible to set screen into the following types
- 1. Page

When a new project is created, screen1 (Page type) is created by default. It is not possible to change screen1 to either template or popup. Screen1 (start page) should be "Page" type only.

How to add a new page

In Project Explorer, select "Screen1", then right click your mouse. It will show the screen below. Click "Add", and Screen2 will be created and will appear as shown below.



Now, Select Screen1, then check its properties. For example: It is possible to change the background color of a screen from the page properties


roperties				
- 4 -			Screen Style	
			PageNo	1
BackColor	Silver		ScreenHeight	480
Text	Screen1		ScreenWidth	800
Events			Template	
Activated			TitleBar	True
Deactivated			Туре	Page
	Events Activated	Appearance BackColor Silver Text Screen1 Events Activated	2 Appearance BackColor Silver Text Screen1 Events Activated	2↓ Screen Style Appearance PageNo BackColor Silver Text Screen1 Events ScreenWidth Activated TitleBar

Right click your mouse keeping the pointer on any page, then, you can edit screen properties via the wizard.

	-	Pr	ope	rtie	s	
		Pa	iste			
	<u> </u>					

Screen1's Properties	
General Events	
Appearance	
BackColor	
Screen Style	
PageNo	Template
1	
ScreenHeight	ScreenWidth
480	800
	Туре
☑ TitleBar	Page 🔹
Loop Interval (ms)	
1000	

Screen1's Properties					
General	General Events				
Activated					
	Deactivated				
Loop					



It is possible either to open, delete or rename a screen. Select the appropriate screen in the project explorer, then "Right click" the mouse to show the above Screen dialog.



Note: These screen display names are the same as those available at project explorer. These are different from title bar (Text) defined for screen.

Properties:

Back Color: Defines the background color of a component.

Events:

Activated: Defines tasks to be executed before opening a Screen.

Deactivated: Defines tasks to be executed before closing a Screen.

Screen Style

Page No: Displays current page number.

Screen Height: Defines/Displays current screen height.

Screen Width: Define/Display current screen width.

Template: Select the Template page for this screen.

Title bar: Control visibility of Title bar and select it in design time.

If "Title Bar" is selected in Page properties, then, the number of grids vertically in screen multiplied by grid size will not match the screen height since the Title Bar occupies some space.

Type: Defines the type of screen. Available options include Template, Page and Popup.

5.3.17 Tool box

These can be accessed from menu bar also from objects.

Toolbox	ф	×
Basic objects	_	
Enhanced objects		
SymbolFactory		
Graphics		

5.3.17.1 Basic Objects

It is to draw simple shapes in the screen, data entry, data display, alarms view etc.

Basic Objects		
▶ Pointer	Line	신 Polygon
Rect	Ellipse	Arc
1 Table	1 NumericUpDown	
123 DigitalBox	abl TextBox	A Label
A DateTimeLabel	AamBanner	ab Button
📳 BitLamp	WordLamp	CheckBox
📷 Combo Box	≡: ListBox	EE GroupPanel

There are three ways to insert the above objects into the screen.

- i) Drag and drop.
- ii) Select the object, say a line, then use the mouse to draw a line on screen.
- iii) Select the object, then double click (mouse left click) quickly by keeping pointer on selected object. Then, the object will appear on screen. For example, select "line" and Double click it 3 times by keep mouse pointer on line, you can see 3 lines appear on the screen.

After inserting object to screen, it is possible to edit its properties either by Graphical User Interface (GUI) dialog or editing properties directly in property grid.

How to edit via GUI dialog

Insert any object in a screen. Select the object, right click the mouse, and then select properties.


Or

Insert any object in a screen. Double click on the Object. A GUI dialog will open automatically.

🔜 Rect1 Configuration						
General Animation Bands Common						
Арре	Appearance LineWidth 1					
TagBinding						

How to edit via Property grid

By default, the property grid will appear at the bottom-right area of the screen editor. If it is not available, click on the "View" drop-down menu, then click "Reset Window Layout". The property grid will appear at bottom right side of the screen editor just below the Project Explorer.



Property grid

Properties					
	Appearance				
	LineWidth	1			
Ð	Behavior	Behavior			
	Animation	False;0, 0;0,			
	Bands	(Collection)			
⊡	Data				
	TagBinding				
	n				

Before placing any objects in screens, check the section File- Environment and set default font size, fill color, fore color and back color for the objects as shown below.

🔚 Environment	
General Download and Upload Snap and Grid Object default setting	TextFont Name Tahoma 💌 Size 12 Style Bold 💌
	FillColor
	BackColor Enable ForeColor Enable

5.3.17.2 Common Properties

Appearance

Back Color: Sets the background color of the component.

Fore Color: Sets the Fore color of the component.

Bevel: Used to set the border including inner border, outer border and style of border.

Inner Border: True/False

Outer Border: True/False

Style: 9 styles are available

None, Flat, Single, Double, Raised, Lowered, Double Raised, Double Lowered, Frame Raised, and Frame Lowered

Rect1's Properties	2
General Animation Bands Common	Events
Location X 64 Y 48	Size Width 224 Height 64
Behavior Visible	💌 Enable
Others Name Rect1	SecurityLevel

Behavior

Visible: True/False, determines whether component/control is visible or hidden

Enable: This is for event control. If linked with a Digital tag, when the tag value =1 in run time, events configured for the object will be executed. If the tag value = 0, events will be not executed

Data

Tag Binding: Select the Tag of the desired process value

Write design time value: If selected, it writes the value available at "Text" in design time and in run time replacing the default value defined at Tag data base.

Design

Name: It is the name of the component.

Security level: Define the security level for the component.

Locked: True/False: It is to Move or Resize the component.

Layout

Dock: Defines which borders of the control are bound to the container.

Location: The coordinates of the upper-left corner of the component relative to upper-left corner of the container. Set X and Y position in screen in pixels.

Size: Size of the component in pixels. Set height and width of component in pixels.

• **Pointer**. It is to deselect the tool selection.

5.3.17.3 Line

Line: An object used to draw a line and do animation in Run time when linked with a Tag.

User can edit properties via GUI dialog or property grid. After drag/drop of object to a screen, double click the object to open the GUI dialog, or, select the object and directly enter properties via the property grid available at bottom right corner of screen editor.

Line1's Properties	×
General Animation Bands Common Events	
Appearance LineWidth 1 Direction Any	
Points Point2 X 5 5 209 Y 5 5 17	
TagBinding TagBinding TagBitNo	

General

Appearance

Line Width: Define Line width

Direction: Horizontal or Vertical

Points

Point1: Define X and Y coordinate for line starting point and they show current position.

Point1: Defines the X and Y coordinates for the line end point and shows the current position.

Tag Binding

Select a Tag to be linked with this line. This is useful if animation is required.

🔜 Line1 Configuration							
General Animation Bands Common							
Movement							
EnableMove							
C StartPosition							
X							
0 0							
Y Y							
0							
Size							
StartSize							
Width Width							
10 100 Usisht							
Height Height							
10 100							
Tag Value							
From To							
0 100							

Animation

This is to do animation on line in Run Time

Movement

Select "Enable Move" check box if movement animation is required during Run time.

Start Position: Defines X and Y coordinates for the start position when tag value is at its minimum during Run Time.

End Position: Define X and Y coordinate for end position when tag value is at its max. during run time.

The X position indicates movement from Left to Right, this is Horizontal movement. The Y position indicates movement from Top to Bottom, this is Vertical movement.

For example: Recorder 7" (High Performance) project, 800 X 480 pixels, Normal installation, Horizontal (Left to Right) = 800 pixels, Vertical (Top to Bottom) = 480 pixels

Enable move: Selected Start position X = 0, Y = 0End position X = 800, Y = 0Tag Value, From = 0, Tag Value To = 100

Now, in Run time, when the Tag value = 0, the line will be at the Top left. When the Tag value = 100, the position of the line will be at the Top Right

Size

Select "Enable Size" check box to enlarge/decrease size of component during Run time.

Start Size: Defines X and Y coordinates for the starting size when the tag value is at its minimum during Run time.

End size: Define X and Y coordinate for end size when tag value is max. Run time.

Tag Value

Select a Tag to be linked with this line. This is useful if animation is required to be done on the line.

Bands

This is to select various bands as part of an animation during Run Time

📰 Line1 Co	nfiguration				
General	Animation	Bands	Common		
	BandCoun 3	t	•		
Ban	d1				
	ForeCo	olor		Visible Visible	
Ban	d2 ForeCo	olor		Visible	Value 20
Ban	d3 ForeCo	olor		✓ Visible	Value 80

Band Count

A maximum of 32 bands are available.

For example: In the above sample, If the Tag value is 0 to 20, the line will be Yellow If the Tag value is 21 to 80, then, line color = Green If the Tag value is above 80, line color = Red

5.3.17.4 Polygon

Polygon: Used to draw a polygon. After finishing drawing, double left-click the polygon using the mouse to complete the Polygon. It is also possible to link a polygon to a tag and define some user friendly animation to appear during Run time.

Polygon1's Properties				
General Points Animation Bands Common Events				
Appearance ForeColor LineWidth	FillColor			
TagBinding TagBinding				
TagBitNo	T			

Polygon1 Configuration							
Gen	eral	Points	Animation	Bands	Common		
	Point	t 1 ———					
		×					Y
		5					49
	Point	2					
		×					Y
		93					5
	Point	3					
		×					Y
		130					64

🔜 Polygon1 Configuration		
General Points Animation	Bands Common	
⊂ Fill		
EnableFill		
StartFill		EndFill
0		100
Movement		
EnableMove		
StartPosition X		EndPosition X
0		0
Y		Ý
0		0
Size		
EnableSize		
StartSize		EndSize
Width 10		Width 100
Height		Height
10		100
Tag Value		
From		To
0		100

Animation

This is to do animation with a Polygon in Run Time

Fill

Select "Enable Fill" if filling animation is required on a Polygon object during Run time. When a tag value changes during Run time, it shows the polygon filling with a defined color inside the Polygon object. It's like a bar graph where the filling is within the polygon shape. Start Fill: Defines a Start value for Fill

End Fill: Defines an End value for Fill

Movement

Used to define a movement position. This is the same as previously explained for the Line object earlier.

Size

Used to define the amount of size increase/decrease. This is the same as previously explained for the Line object earlier.

Tag Value

Select a Tag to be linked with the Polygon object. This is useful if animation is required to be done with the Polygon.

E Polygon1 Configuration	×
General Points Animation Bands Common	
BandCount 3	
Band1Blink	
ForeColor FillColor	Blink BlinkColor
Visible Band2	
Appearance Blink	🔲 Blink
Visible 2	alue
Band3	
Appearance Blink	🔲 Blink 📕 BlinkColor
Visible 8	alue

Band editor: A maximum of 32 bands are available.

For example: In the above sample, If the Tag value is 0 to 20, Polygon fill color = Yellow If the Tag value is 21 to 80, then, Polygon fill color = Green If Tag value is above 80, Polygon fill color = RED

If required, it is also possible to configure the blink property and set blink color for any band.

5.3.17.5 Rectangle

Rectangle: Used to draw a Rectangle and do animation during Run time when linked with a Tag.

Rect1's Properties					
General Animation Bands Common Events					
Appearance ForeColor	FillColor LineWidth				
TagBinding TagBinding					
TagBitNo	•				

🖶 Rect1 Configuration	×
General Animation Bands Commor	ו
CFill	
🗌 EnableFill	
StartFill	EndFill
	100
Movement EnableMove	
	-EndPosition
X	x
	0 Y
0	0
EnableSize	
StartSize	EndSize
Width 10	Width 100
Height	Height
10	100
Tag Value	
From	To 100
	OK Cancel

Animation Supported: Fill, Movement and Size

The above features are same as explained for Line and Polygon objects

🔜 Rect1 Configuration	×
General Animation Bands Commo BandCount 3	n
Band1 Appearance ForeColor FillColor Visible	Blink Blink Blink BlinkColor
Band2 Appearance ForeColor FillColor	Blink Blink BlinkColor Value 20
Band3 Appearance ForeColor FillColor Visible	Blink Blink BlinkColor Value 80
	OK Cancel

Band editor: A maximum of 32 bands are available.

For example: In the above sample, If the Tag value is 0 to 20, Rectangle fill color = Yellow If the Tag value is 21 to 80, then, Rectangle fill color = Green If the Tag value is above 80, Rectangle fill color = Red

If required, it is also possible to configure blink property and set blink color for any band.

5.3.17.6 Ellipse

Ellipse: Used to draw an Ellipse or a circle and do animation during Run time when linked with a Tag.

General Animation Bands Common Events	
Appearance ForeColor Circle	
TagBinding TagBinding	
TagBitNo	

Ellipse1's Properties	
General Animation Bands Comr	non Events
Fill	
EnableFill	
StartFill	EndFill
,	100
Movement	
EnableMove	
StartPosition	EndPosition
Size	
🗖 EnableSize	
StartSize	EndSize
Width	Width
10	100
Height	Height
10	100
Tag Value Range	
From	<u></u>
0	100

Animation Supported: Fill, Movement and Size

The above features are the same as explained for Line and Polygon objects.

🔜 Ellipse1 Configuration	×
General Animation Bands Common BandCount 3	
Band1 Appearance ForeColor FillColor	Blink Blink BlinkColor
Band2 Appearance ForeColor FillColor	Blink Blink BlinkColor Value 20
Band3 Appearance ForeColor FillColor Visible	Blink Blink BlinkColor Value 80
	OK Cancel

Band editor: A maximum of 32 bands are available.

For example: In above the sample,

If the Tag value is 0 to 20, Ellipse fill color = Yellow If the Tag value is 21 to 80, then, Ellipse fill color = Green If the Tag value is above 80, Ellipse fill color = Red

If required, it is also possible to configure blink property and set blink color for any band.

5.3.17.7 Arc

Arc: Used to draw an Arc and do animation during Run time when linked with a Tag.

Arc1's Properties	
General Animation Bands Common Events	
Appearance ForeColor	LineWidth
Shape StartAngle	SweepAngle
TagBinding TagBinding TagBitNo	

Start Angle: Defines the start angle.

Sweep angle: Defines the end angle

Arc1's P	roperties	
General	Animation Bands	Common Events
	vement EnableMove	
St	artPosition X 0 Y 0	EndPosition X 100 Y 0
Size	9	
🗖 🗖 E	EnableSize	
St	artSize Width 10 Height 10	EndSize Width 100 Height 100
Tag	y Value Range From	То
	0	100

Supported Animation: Movement and Size

🖶 Arc1 Configuration		
General Animation Bands	Common	
BandCount 2	•	
Band1 ForeColor	✓ Visible	
Band2	✓ Visible	Value 10

Band editor: A maximum of 32 bands are available. Band editor for "Arc" is the same as explained for the "Line" object earlier.

5.3.17.8 Table

It is used to draw a table during design time by specifying number of rows & columns. All rows/columns will have an equal width and height. It is possible to place labels on rows (Linked with Tags) for displaying process values to appear like a tabular column. User can edit properties via the GUI dialog or Property grid as per convenience. After dragging/dropping the object to the screen, double click on the object to open GUI dialog.

While working with a Table, in page properties, select Snap to Grid = False so that it will be easy to place labels/textboxes in required positions easily.

			_	 	_	

Drag/Drop Table from Basic objects to the screen, then double click on Table. The following screen will open.

Table1's Properties	
General Common Events	
Appearance BackColor LineWidth	ForeColor
Columns SameWidth	ColumnCount 10
Rows SameHeight	RowCount 5

Note: Deselect "Same Width" to adjust column width in the Table

Note: Deselect "Same Height" to adjust Row height in the Table

Property grid

Properties		ф	×
₽ 2 ↓ □			
Appearance			
BackColor	Control		
ForeColor	ControlText		
LineWidth	2		
🗆 Behavior 👘			
Visible	True		

Ξ	Design	
	(Name)	Table1
	Columns	5
	Locked	False
	Rows	5
⊡	Layout	
	Dock	None
Ŧ	Location	80, 192
Ŧ	Size	480, 176

Properties

Back Color: It is the back color of the table

Fore Color: It is the color for the lines of the table

Line Width: It is the width of the lines of the table

Columns: Defines the number of columns in the table

Rows: Defines number of rows in the table

Name: The unique name for the table in a specific page

Locked: Used to determine if table is locked for further moving and resize in design time and you can set this in property grid.

5.3.17.9 Numeric Up/Down

Numeric Up/Down is a Graphical User Interface widget that allows the user to increase or decrease the value of a tag by pressing up or down arrows during Run time, or to enter a numeric value directly via a keypad. Users can edit properties via GUI dialog or Property grid for convenience. After drag/drop of a numeric up/down object to the screen, double click on the object to open GUI dialog.

Every Numeric Up/Down button should be linked with an *Analog* Tag.



Except the Up/Down arrow, if a user presses another area of the Numeric Up/Down component in the recorder during Run time, a numeric keypad will open. The user can then enter a numeric value directly. The numeric keypad will not appear in the PC during Online/Offline simulation, you can use the keyboard directly to enter a numeric value.

NumericUpDown1's Properties	
General Common Events	
Appearance	
BackColor	ForeColor Decimal
WriteDesignTimeValue	2
Rounding	
TextFont Name	Size
Tahoma	12
Style	1
Bold	
Tabindex	
0	
Values	Minimum
Increment	Maximum
1	100
Soft Keyboard	
🔽 Enable	Alignment MiddleCenter
TagBinding TagBinding	

Increment: Select the value to be incremented/ decremented each time when the up/down arrow is pressed during Run time.

Properties

Write design time value: If selected, it writes value available at "Text" during design time and also during run time replacing the default value defined in the Tag data base.

Rounding: Rounds to nearest value

Decimal: Enter the number of decimal points

Value: Current Tag value. It is used to enter a value during design time and to check how a value is displayed during Run time.


Increment: Value to be incremented during Run time after pressing Up/Down button.

Minimum: Defines the minimum value *Maximum:* Defines the maximum value




Soft keyboard: If enabled, it is possible to control the keypad appearance during run time. For example, if alignment is selected as Middle center, then, when keypad appears in run time, it will be located to Middle center in screen

Events: Defines events to be executed when the operator presses the Up/Down arrow and changes the value during Run time.



5.3.17.10 Digital LED

This object is used to view a process value in a digital format. Generally, it is linked with an analog type tag (example: an analog input tag at a PLC, which is received as 4-20 mA signals from field transmitters to define things like Temperature, Pressure, Flow, Level, Position etc...)



For common properties like Back Color, Bevel, ect., please refer section "Common Properties

DigitalLED1's Properties	
General Common Events	
Appearance BackColor	Value
Bevel InnerBorder Style DoubleRaised	OutterBorder
Digits ActiveColor DigitHeight 80 DigitSpace 3 SegmentThickness 4	InactiveColor DigitWidth 40 SegmentSpace 1
Decimal 0 TagBinding	Rounding
TagBinding	

Property grid

Ξ	Digits	Red,80,3,40,Color [Silver].
	ActiveColor	Red Red
	DigitHeight	80
	DigitSpace	3
	DigitWidth	40
	InactiveColor	Silver
	SegmentSpace	1
	SegmentThickness	10

Properties

Back Color: Defines background color for the component

Inner border: Select if inner border is required for the component

Outer border: Select if outer border is required for the component

Style: Defines border style. Available options are Single, Double, Raised, Lowered, Double Raised, Double Lowered, Frame Raised and Frame Lowered

Active Color: Defines Active Color of Segment for Digits

Inactive Color: Defines color of inactive segments. In the seven-segment LED display, some segments may be active and some other segments may be inactive depending on numeric values.

Digit Height: Defines height of digits

Digit Width: Define width of digits

Digit Space: Defines the space between digits

Segment Space: Defines the space between segment to segment for digits

Segment Thickness: Defines thickness of segments for digits

Decimals: Defines the number of decimal points

Tag Binding: Selects the Analog Tag of process value

5.3.17.11 Digital Box

Digital Box is a Graphical User Interface widget that displays a digital tag value along with four predefined labels as attributes for the process value in Run time.



Digital Boxes are normally used with *Analog* tags to display process values like Temperature, Pressure, Flow etc. They also allow 4 different labels as attributes for displaying tag related information.

italBox1's Properties	
Appearance	
BackColor	ForeColor
Attribute Attribute1	Attribute2
T10	
Attribute3	Attribute4
Mill1	Outlet
AttributeFont	Outlet
Name	Size
Tahoma 🚽	20
Style	
Regular	
Value	
Decimal	Rounding
2	
Value	
0 ValueFont	
Name	Size
Tahoma 🔻	20
Style	
Regular	
TagBinding TagBinding	
regenang	

⊡	Appearance	
	Attribute1	T10
	Attribute2	*C
	Attribute3	Mill 1
	Attribute4	Outlet
ŧ	AttributeFont	Microsoft Sans Serif
	BackColor	📃 Khaki
	Decimal	2
	ForeColor	Blue Blue
Ŧ	ValueFont	Arial,20,Bold

Ξ	Behavior	
	Value	0
	Visible	True
Ξ	Data	
	TagBinding	Tag3 🛛 🗸 🗸
Ξ	Design	
	(Name)	DigitalBox1
	Locked	False
Ξ	Layout	
	Dock	None
ŧ	Location	176, 224
Ð	Size	256, 112

Properties

Attribute1: attribute to be displayed at Top left side of Digital Box

Attribute2: attribute to be displayed at Top Right side of Digital Box

Attribute3: attribute to be displayed at Bottom Left side of Digital Box

Attribute4: attribute to be displayed at Bottom Right side of Digital Box

Attribute font: Define font for attribute, select type font, and size of font and style of font. Styles include Regular, Bold, Italic, Underline, and Strike out.

Back color: Defines background color

Fore Color: Define fore-color for the font

Decimal: Defines number of decimal places for the value to be displayed

Value font: Used to adjust the size of the display process value font, select type of font, size of font and style of font. Styles include Regular, Bold, Italic, Underline and Strike out.

5.3.17.12 Text box

Used to Read/Write Alpha numeric text in Run time. It can be linked with any type of tag.

TextBox1	
TONDONT	

If the object is linked with String type tag, an alpha-numeric keypad opens during Run time if a user touches the object. If the object is linked with an Analog or Digital tag, a numeric keypad opens during Run time if a user attempts to touch the object. If a digital tag is used, make sure "decimal" is set to 0.

Inp												×
	USER 1											
	1	2	3	4	5	6	7	8	9	0	-	=
	Q	w	E	R	т	Y	U	I	ο	Р	Γ]
	A	S	D	F	G	Н	J	К	L	;	ı	•
	Z	x	С	v	В	N	м	,	•	/	١	2
	Shift	Caps	Alt						Backs	space	<	>
	Сору		Pa	ste					0	к	Car	ncel

Alpha numeric keypad

🔜 Input		Je J	×
0.00			
7	8	9	BS
4	5	6	<
1	2	3	>
0		-	Clr
0	к	Car	ncel
			//

Numeric keypad

TextBox1's Properties	
General Common Events	
Appearance BackColor Text TextBox1 WriteDesignTimeValue	ForeColor Decimal 2 Rounding
Name Tahoma Style Bold TabIndex 0	Size 12
Values Minimum 0	Maximum 100
Soft Keyboard	Alignment MiddleCenter
TagBinding TagBinding	
Tahoma Style Bold TabIndex 0 Values Minimum 0 Soft Keyboard ImagBinding	12 Maximum 100 Alignment

Note: For common properties of all components, please check the beginning of this section.

Write design time value: If selected, it writes the value available at "Text" during design time and also during run time replacing the default value defined in the Tag database.

Soft Keyboard	
Enable	Alignment MiddleCenter

Soft keyboard: If enabled, it is possible to control the keypad appearance during run time. For example, if "alignment" is selected as Middle center, then, when the keypad appears during run time, it will be located in the middle-center of the screen

	🗉 Design
-	(Name) TextBox1
Appearance BackColor White	Locked False
Decimal 2	SecurityL 0
ForeColor ControlText	□ Events
Password	Changed
Text TextBox1	□ Layout
■ TextFont Tahoma,12,Bold	Dock None
Behavior	■ Location 96, 96
Visible True	
🗉 Data	□ Misc
TagBindin Tag1	WriteDesi False

5.3.17.13 Label

The "Label" object is used to write a simple line of text for user information in the screen. Example: Tag name, Pump number display etc. It is also used to display process values (read only) to operators if linked with a Tag.

P102

Label1's Properties	X
General Common Events	
Appearance BackColor Text P102 TextFont Name Tahoma Size Tahoma Style Bold	
Decimal Rounding	
TagBinding TagBinding	
Tag3	
TagBitNo	

Properties 4				
Appearance				
	BackColor	Yellow		
	Decimal	2		
	ForeColor	Blue		
	Rounding	False		
	Text	P102		
	TextAlign	TopLeft		
Ŧ	TextFont	Tahoma,12,Bold		
	Behavior			
Ŧ	Enable			
Ŧ	Visible			

Ξ	Data	
ŧ	TagBinding	Tag3
Ξ	Design	
	Name	Label1
	Events	
	Clicked	
Ξ	Layout	
ŧ	Location	224;126
Ŧ	Size	112;38

Note: For common properties of all the components, please check beginning of this section.

Properties

Text: Defines text associated with this component and it should be entered at design time only.

Text Align: It is for Alignment of text. Available options include Top Left, Top Center, Top Right, Middle Left, Middle Center, Middle Right, Bottom Left, Bottom Center and Bottom Right

Text Font: Defines font for text including type of font, size of font and style of font. Styles include Regular, Bold, Italic, Underline and Strikeout.

Tag Binding: Select the Analog Tag of a process value

Decimal: Defines the number of decimal points

5.3.17.14 Date and time Label

1/20/2010 PM 4:43:03

Used to display Date and Time in screen.

🔜 DateTimeLabel1 Configuration				
General Common				
Appearance BackColor TextAlign TopLeft	ForeColor			
Name Tahoma Style Bold	Size 12			
DateTimeFormat DateFormat M/d/yyyy DateTimeFormat DateTime	TimeFormat H:mm:ss			

0

If date and time is required in more than one screen, it is better to create a screen and select the screen type as "Template", and then link this template to all other required screens to display Date and Time automatically. This is more efficient than keeping Date and Time label in more than one screen, since it uses less memory.

5.3.17.15 Button

Button1

A Button is commonly used to perform an action after operator presses it with their finger, or by clicking using a mouse during Run time.

Generally, "Button" is used to turn ON a bit, Turn OFF a bit etc. when used with Digital type tags. Example: Start Pump, Stop pump etc.

Three kinds of "Events" are supported for a button. Clicked, Pressed and Released. Several functions are supported which can be configured from "Events" and all the functions are covered in next section "Function editor".

Button1's Properties	
General Bands Common Events	
Appearance BackColor Text Button1 ShowSelect	ForeColor BorderStyle Fixed3D TextAlign MiddleCenter
Image BitmapFile arrow2-b.wmf Transparent Transparent Flip	ImageLayout None TransparentColor Rotate
None TextFont Tahoma Style Bold	0 Size 12

Properties

Back Color: Selects Back color for the object. Also, it is possible to select transparent mode if required. *Firmware V1.20 onwards.*

🔜 Selec	t Color	×
Color		
	O Transparent	
	• Select Color	
	ОК	Cancel

Text: Defines required text to be displayed on the object. *It is also possible to enter multiline text from firmware V1.20 onwards*

Appearance BackColor Text	
Button1hello	
🔜 Text	
Button1 hello	

Show select: True/False. If it is selected, then, when the operator presses this button, it will show a dotted line just inside the button. When the operator presses another button, it automatically shows selected "show" status to latest button and deselect "select" status for previous button pressed by the operator.

Border Style: Defines border style. Available options include none, fixed single and fixed 3D

Image: Selects the Image to be displayed on the object. Image can be selected from either Basic symbols or Symbol factory, or a custom image can be used if they are formatted as bmp, wmf, jpg, gif or png.

Screen1	Button1's Properties
	General Bands Common Events
	Appearance BackColor Text
	C ShowSelect
	Image BitmapFile Valves-1-r.wmf

Text font: Define the font includin	g name of font, size	e of font and style of font
-------------------------------------	----------------------	-----------------------------

Pressed
🗖 AutoRepeat
Interval (ms)
50
_

Timing: This is an advanced feature and used to make sure operator action is properly received by PLC when the PLC has a large scan time.

Hold time: This is generally applicable for a "Clicked" event. This keeps executing the action defined at the "Clicked" event for the time defined at hold time. We suggest using holding time greater than the PLC scan time. Example: 300 msec.

Example:


Push button Function

🖶 Button1	Configuration	
General	Bands Common Events	
	Clicked	
	TurnBitOn(Tag1);	
	Pressed	
	Released	
	TurnBitOff(Tag1);	




Example: Operator presses button for only 200 msec. When operator clicks the button, Tag1 = 1. When operator releases the button, Tag1 = 0, holding time = 1000 msec.

Since holding time is set for a clicked action, the released action "TurnBitOff" will be executed only after completing 1000 msec, not immediately after the operator releases the button. In this case, if the PLC scan time is 800 msec, the operator click action will be detected properly because the button will remain active for 1000 msec.



Auto Repeat & Interval time: This is generally applicable for a "Pressed" event. It is to repeat the action defined at the "Pressed" event as per the set interval time.

Example: When operator keeps the button pressed, the set point should be incremented by 1 for every 1 second.



Auto repeat with time interval and holding time cannot be used together.

Tag binding: Select the tag that should be linked to the button to show a different display during run time based on configuration available at Band editor. Any of the configured Analog or Digital tags can be selected.

TagBinding TagBinding		
Tag1		-
TagBitNo		
Disable		

If Tag1 is an Analog Type (32 bit), it is also possible to show a different display based on individual bits. By default, it is disabled. You can select the bit from the combo box and then configure the band editor per project requirements.

🔡 Button1	Configur	ation			
General	Bands	Common	Events		
Band					
	 	 BackCo			Text
	L	Dacket	101		START
		ForeCo	olor		Visible
Bli	nk				
		🔲 Blink	c .		BlinkColor
Ime	nge				
	Bitmap	File		Ir	nageLayout
					lone 🕑
	ranspare			Г	
		Transpa	arent	I	TransparentColor
	Flip			R	lotate
	None	!		• 0	×
	Valu	e			
	0				

Bands: Defines bands for the button.

Back color: Defines the back color for the selected band

Fore color: Defines the fore color to appear for selected band in run time

Text: Define the text to be displayed for selected band in run time

Visible: Controls if the button is visible

Blink: Select if blink is required when the tag value reaches a selected band during run time. If yes is selected, it allows the user to enter a blink color.

Bitmap file: Select the image to be displayed on button when tag value reaches this band in run time.

For example: When Tag1=0, show Red colored motor symbol on the button.

When Tag1=1, show Green colored motor symbol on the button.

Note: Two different symbols are required for the above example

Bmp, wmf, jpg, gif and png types are supported. If the selected file is different than wmf, then, it is also possible to select Image layout and transparent options.

🔡 Select	Image	×
Image		
	• From file browser	
	© From Basic Symbol	
	© From Symbol Factory	/
-	ок	Cancel

From File browser: To select image from a specified location

From Basic Symbol: To select images from the free basic symbols (*.wmf format) available in Recorder editing software.

From symbol factory: It allows the user to select symbols from the symbol factory (in wmf format).

Image layout: None, center and Stretch options are available. Stretch means the selected bitmap will be stretched to the size of the button.

Note: If a bitmap has poor resolution, when stretch is used, it may show a low quality image in screen.

Flip: Used to flip a button. This needs to be configured during design time. Available options include None, Horizontal, Vertical and Both.

Rotation: Used to rotate the button at predefined angles. This needs to be configured during design time. Available options include 0° , 90° , 180° and 270° .

Value: Defines the maximum range of the selected band. Low range will be the value defined at the previous band. There is no need to enter any value for band 1 as its value is 0 which is low range.

0

If the button is linked with a Digital Tag, then, in the band editor, it will show only two bands for value 0 and 1. When a button is linked with an Analog tag, it is possible to configure up to 32 bands for showing different states of button based on value of tag. It shows statuses similar to word lamp.

Button1	's Properti	es				×
General	Bands Com	mon Events				
Locatio	on × 76 Y 62			Size Width 160 Height 76		
Vis	avior sible TagBinding					
	TagBitNo	Y				
En	able TagBinding TagBitNo		_		•	
Othe	Name	_		SecurityLevel		
				SecurityLevel 0	T	

Security control: Defines security level for the button. It allows the user to operate the button only when operator security level is equal to or more than security level defined here.

Please refer section "Security" at Project explorer for more information about security features.

Events

Clicked: Define the action that happens when user presses button during Run time. If required, it is possible to configure a holding time for this action.

Holding time is a very useful function. If the PLC has a large scan time, sometimes the operator "clicked" action will be not detected by the PLC. In this case, it is possible to have a hold time for a "clicked" event so that operator action will be continuously present for the time defined at "holding", such that the PLC will receive the operator action properly.

If the operator touches a button and releases his/her finger instantly, it is called a "Clicked" action. During this time, a total of three actions will be executed. Click, Pressed and Released

📰 Button1 Configuration						
General	Bands Common Events					
	Clicked					
	AddValuetoTag(Tag1,1);					
	Pressed					
AddValuetoTag(Tag1,1);						
	Released					
	AddValuetoTag(Tag1,1);					

Case-1

Holding time = 0

In above example, Tag1 value becomes 3

Case-2

Holding time = 5000m sec

In the above example, if the scan time for Tag1 is 1000m sec, the Tag1 value becomes approximately 8.

When the button is clicked, the "Clicked" and "Pressed" event action occurs, and the Tag1 value becomes 2. Since the holding time is 5 sec, for the next 5 seconds, the Tag1 value is incremented by 1 each second. So, Tag1 value becomes 7. When the button is released, Tag1 value is incremented by 1 again, so it becomes 8.

The above example is for illustration only to understand about events for the button object.

Pressed: Define the action that happens when a user continuously presses on a button. If required, it is possible to configure Auto repeat and interval time for this action.



Once an operator touches a button, the "clicked" event will be executed first. If the operator keeps holding the button continuously, the "pressed" action

will continuously be executed. When the operator releases their finger, the "released" action will be executed.

Auto repeat: On, Time interval=1000 m sec. In this example, the Tag1 value will first increment by 1, then it will keep incrementing by 1 once every 1000 m sec. as long as the operator presses the button. The Tag1 value will also be incremented by 1 when the operator releases the button.

Released: Defines the action when the user releases the button

Switch Function

With this function, two buttons are required. One button to turn a tag ON, and a second button to turn a tag OFF.

📰 Button1 Configuration	🔜 Button2 Configuration
General Bands Common Events	General Bands Common Events
Clicked	Clicked
TurnBitOn(Tag1);	TurnBitOff(Tag1);
Pressed	Pressed
Released	Released

When the operator clicks Button1, Tag1 will = 1. Now, Tag1 will = 1 even after the operator releases the button, and it will continue to maintain its earlier state. When the operator clicks Button2, Tag1 will = 0.

5.3.17.16 Function editor

This is very useful to select different functions to execute based on operator actions. During Run time, this provides an easy way for an application developer to use a ready-made macro instead of writing scripts. Insert a Button into any screen and configure events. The following functions are supported.

S	elect a fur	nction to a	d
+	+ Page		-
	⊕ Tag		
	• Object	t	
	÷ Sound	ł	

Page Control functions

📮 F	age
	- GotoFirstPage
	- GotoPreviousPage
	- GotoNextPage
	- GotoLastPage
	GotoPage
	- GotoPageByNumber
	GotoPopup
	ClosePopup

Every screen has a screen number. The pointer will be the screen number for navigation.

GotoFirstPage: It is used to navigate from current screen to first screen

GotoPreviousPage: Used to navigate from current screen to previous screen

GotoNextPage: Used to navigate from current screen to next screen

GotoLastPage: Used to navigate from current screen to Last screen

GotoPage: Used to navigate from current screen to specific screen by name

GotoPageByNumber: Used to navigate from current screen to specific page by number

GotoPopUp: Used to open specific pop up screens by name

ClosePopUp: Used to close pop up screens by name

Tag functions

🚊 Tag
SetValuetoTag
AddValuetoTag
 SubtractValuefromTag
CopyTagBtoTagA
AddTagBtoTagA
SubtractTagBfromTagA
SwapTagAforTagB
CopyStringTagBToTagA
SetStringtoTag
CopyBlockfromTagBtoTagA
EditValuetoTag
TurnBitOn
TurnBitOff
ToggleBit

SetValuetoTag: Writes a value to a tag

Example: Set 90 to TagA when operator presses on a button during run time.

Parameter Setting		
Tag	Tag1 💌	
Value	90	
	ОК	

AddValuetoTag: Used to add value to Tag

SubtractValuefromTag: Used to subtract value from Tag

CopyTagBtoTagA: Used to copy TagB value to TagA

Parameter Setting		
TagA	Tag1	
TagB	Tag2	

AddTagBtoTagA: Used to add TagB to TagA and store result in TagA

SubtractTagBfromTagA: Used to subtract TagB from TagA and store the result in TagA.

SwapTagAforTagB: Used to swap TagB data with TagA

CopyStringTagBtoTagA: Used to copy the string type of TagB to TagA

SetStringtoTag: Used to write a string to a String type Tag

Parameter Setting		
Tag	Tag7	v
String	Hello	

CopyBlockfromTagBtoTagA: Used to copy a block of tags from TagB to Tag1

For example: Copy 4 continuous tags from Tag5 to a target location starting with Tag1. Tag5 is copied to Tag1, Tag6 is copied to Tag2, and so on.

Note: Maximum block size is limited to 80 tags

Parameter	
TagA	Tag1
TagB	Tag5
Block Size	4 1~80
	OK

EditValuetoTag: Used to edit tag value during run time from a keypad. For example, if this function is called from button "clicked" event, then, a keypad will open during run time and the user can enter a set point.

TurnBitOn: Used to turn on a bit.

If a momentary Turn on is required, then in "Clicked" action, select Turn On, then, in "Released" action, select "Turn OFF".

TurnBitOFF: Used to turn off a bit

Togglebit: Used to toggle the bit






Fig: Ladder logic in PLC

Button10's Properties			
General	Bands Common	Events	
	Clicked		
	TurnBitOn(Bit0,0);		
	Pressed		
	Released		
	TurnBitOff(Bit0,0);		

Button10's Properties		
General Bands Common Events		
Clicked	Pressed	
Hold	AutoRepeat	
HoldTime (ms)	Interval (ms)	
50	50	

Fig: On button configuration

0 If a button is not switching properly at the PLC, then, in the "General" Tab, select the "Hold" check box and enter the hold time. Default value is 50 msec. If required, adjust this to 100 msec. and check again if the button is switching properly.

Button1's Properties		
General Bands Common Events		
Clicked		
TurnBitOn(Bit1,0);		
Pressed		
Released		
TumBitOff(Bit1,0);		
Button1's Properties		
General Bands Common Events		
Timing Clicked Pressed		

🗹 Hold

50


HoldTime (ms)

AutoRepeat

Interval (ms)

Fig: Off Button configuration

If button is not switching properly at PLC, then, in General Tab, select "Hold" check box and enter the hold time. Default value is 50 msec. If required, adjust this to 100 msec. and check again.



BitLamp1's Properties	
General Bands Common Events	
Band1 BackColor	Text
ForeColor	OFF Visible
Blink Blink	BlinkColor
Image BitmapFile	ImageLayout
Transparent Transparent	TransparentColor
Flip None	Rotate 0
Value 0	

Band2 BackColor ForeColor Blink	Text ON Visible
🔲 Blink	FinkColor
BitmapFile	ImageLayout
Flip None	Rotate
Value 1	

Fig: Bit lamp status

5.3.17.17 Bit lamp

A bit lamp is used to show the digital input status for the operator. It is linked with either a digital input tag or an Analog input tag. By using the band editor, it is possible to display a different foreground color, different background color, different text, different symbols, different Blink color, and control visibility when the Tag value is 0 or 1.

When a Bit lamp is linked with a digital tag, it has only two bands by default. The Band1 value is 0 and Band 2 value is 1.

For example: If Tag1 = 0, show Red colored background with an Orchid color blink. If Tag9=1, show green colored background.



GUI Wizard

SitLamp1's Properties General Bands Common Events	2
Appearance BackColor	ForeColor
Text BitLamp1	BorderStyle FixedSingle
Circle	TextAlign MiddleCenter
Image BitmapFile	ImageLayout
Transparent Transparent	TransparentColor
Flip None	Rotate 0
TextFont Name Tahoma Style	Size 12
Bold	
TagBinding TagBinding	
	

💀 BitLamp1 Configuration			
General Bands Common			
Band1 Text			
BackColor BitLan	np1		
	✓ Visible		
Blink			
🗹 Blink	BlinkColor		
Image			
BitmapFile			
CTransparent None	<u> </u>		
	nsparentColor		
Flip Rotate			
None V	~		
Value			
0			
Band2			
BackColor Text			
ForeColor	✓ Visible		

Bitmap file: Select the image to be displayed when tag value reaches this band in run time.

For example: When Tag1=0, show Red colored motor symbol When Tag1=1, show Green colored motor symbol

Note: Two different symbols are required for the above

Bmp, wmf, jpg, gif and png types are supported. If the selected file is other than wmf, then it is also possible to select Image layout and transparent options.

🔡 Select	: Image	×
Image		
	• From file browser	
	• From Basic Symbol	
	© From Symbol Factory	,
	ок	Cancel
		11.

From File browser: Allows user to select images in formats of bmp, wmf, jpg, gif and png

From Basic Symbol: Allows user to select wmf format images from basic symbols

From symbol factory: Allows for selecting symbols from symbol factory in .wmf format

Image layout: None, center and Stretch options are available. Stretch means the selected bitmap will be fixed to the size of the bit lamp

Note: If a bitmap has poor resolution, when stretch is used, it may show a low quality image in screen.

Flip: Used to flip bit lamp and needs to be configured during design time. Available options include None, Horizontal, Vertical and Both.

Rotation: Used to rotate a bit lamp in predefined angles and needs to be configured at design time. Available options include 0 $^{\circ}$, 90 $^{\circ}$, 180 $^{\circ}$ and 270 $^{\circ}$

Circle: By default, a bit lamp object shape is in Rectangle. Select this if you wish to change the bitlamp shape to a circle. It is more useful to show status of digital inputs for the operator during Run time.

How to show status of an individual bit in Analog type tag

Sometimes, you will get a 16 bit/32 bit tag from a PLC with different diagnostic information, and you would like to show 16 bit/32 bit lamps in the Recorder screen.

When a Bit lamp is linked with an Analog tag, for example: Int16/Int32, it has two bands. By default, Band1 value is 0 and Band 2 value is 1. In this case, using each bit lamp, it is possible to show the status of each individual bit status within 32 bits as per configuration available at band editor.

TagBinding ———		
TagBinding		
Tag2		•
TagBitNo		
0	-	

In the above figure, Tag2 is an analog type (4 byte), so, a TagBitNo combo box will appear for the selection of the required bit within 32 bits (0 to 31).

If Tag2 is Digital type tag, then, TagBitNo. Combo box is not visible.

5.3.17.18 Word lamp



Word lamps are similar to Bit lamps but linked with an Analog type tag only. It can have many bands. By using the band editor, it is possible to display a different foreground color, different background color, different text, different symbols, different Blink color, and control visibility when Tag values change values during Run Time.

For example: Tank Level indicator

When Tag1 value is 0 to 10, Text = Low Low Level, Color = Yellow Blinking 11 to 20, Text = Low Level, Color = Yellow Background 21 to 80, Text = Normal, Color = Green back ground 81 to 90, Text = High level, Color = Red back ground 91 to 100, Text = High High Level, Color = Red blinking

Create 5 bands as shown

GUI Wizard/Dialog

ieneral Bands Common Events	
Appearance BackColor	ForeColor
Text	BorderStyle
WordLamp1	FixedSingle 💽
	TextAlign
Circle	MiddleCenter 🗾
Image	In a set as suit
BitmapFile	ImageLayout
Transparent	INONE
Transparent	TransparentColor
Flip	Rotate
None	0
TextFont	
Name	Size
Tahoma	12
Style Bold	
TagBinding	
TagBinding	

🔜 WordLamp1 Configuration	
General Bands Common	
BandCount 5	
Band1 BackColor	Text Low Low Level
ForeColor	Visible
Blink Blink	BlinkColor
Image BitmapFile	ImageLayout None
Transparent	TransparentColor
Flip None	Rotate 0

Band1 range = 0 to value defined at band2-1. i.e., 0 to 10

Band2	
BackColor	Text Low Level
ForeColor	Visible
Blink 🗌 Blink	BlinkColor
Image	
BitmapFile	ImageLayout
	None 👻
Transparent	
Transparent	TransparentColor
Flip	Rotate
None	0
Value	
11	

Band2 range: Band 2 value to Band3 value-1 i.e., 11 to 20

Band3		
BackColor	Text	
BackColor	Normal	
ForeColor	Visible	
Blink	BlinkColor	
Image		
BitmapFile	ImageLayout	
	None	
Transparent		
Transparent	TransparentColor	
Flip	Rotate	
None	0	
Value		
21		

Band3 range: Band 3 value to Band4 value-1 i.e., 21 to 80

Band4	
BackColor ForeColor	Text High Level ✓ Visible
Blink	BlinkColor
Image	
BitmapFile	ImageLayout
	None
Transparent	TransparentColor
Flip	Rotate
None	0
Value	
81	

Band4 range: Band 4 value to Band5 value-1 i.e., 81 to 90

Band5	
BackColor	Text High High Level
ForeColor	✓ Visible
✓ Blink	BlinkColor
Image	
BitmapFile	ImageLayout
	None
Transparent	
Transparent	TransparentColor
Flip	Rotate
None	0 💌
Value	
91	

Band5 range: More than or equal to value defined at band 5 (In this case number of bands=5) i.e., greater than 91


5.3.17.19 Check Box

The Check box (or tick box) is a graphical user interface widget that permits the user to make multiple selections from a number of options during run time. Generally it is linked with a Digital type tag Flag/Bit memory in a PLC for use in ladder programming to receive an action from an operator.



Every check box is linked with a single *Digital* tag from Tag Database In the above white box, normally, white space means Not selected, False, Tag Value = 0 Tick mark means, True, Tag value = 1

A caption describing the meaning of the check box is normally shown adjacent to the check box. Inverting the state of a check box is done by touching with a finger or clicking the mouse on the box, or on the caption.



CheckBox1 Configuration			
General	Common Events		
∩Арре	earance BackColor ForeColor VriteDesignTimeValue	Text P101 Checked	
Tex	dFont		
	Name	Size	
	Tahoma 🔽	12	
	Style		
	Bold 💌		
	TagBinding		
	Tag1		

Properties

Write design time value: If selected, it overwrites the default value defined in the tag database.

Checked: Default setting, available options True/False

For example: Tag1 is linked with Checkbox 1. If Checked, the tag = False, that means Tag1=0. If Checked, the tag = True, then Tag1 = 1.

Text: It is Text that appears near Check box as a caption. Example: Text = P101

Events

Changed: Define action using function editor. When operator presses on check box during Run time, the actions defined here will be executed.


Example: There are three pumps named P101, P102 and P103, and the operator would like to select pump P101 for startup. Using the check box, write a meaningful caption via the "TEXT" property to appear at the right side of check box, and link each of the above check boxes with appropriate Tags. Let's say P101, P102 and P103.

Then, when P101 is selected by the operator in run time, P101 Tag value will become 1.



If "checked" = false is selected during design time, then Tag value will = 0. If operator presses on check box during Run time, the symbol \checkmark will appear, and **the** Tag value will become 1.

If "checked" = True is selected during design time, the Tag value will = 1, and the \checkmark appears during Run time. If the operator presses the check box during design time, the symbol \checkmark disappears and the Tag value becomes 0.



If Check box is linked with an Analog type Tag, then, it is possible to select an individual bit.

📕 CheckB	ox1 Configu	ration					
General	Common	Events					
Арр	earance -						
	BackColor				Text CheckBox1		
		ForeCo	olor		Checked		
		WriteDes	signTimeVa	lue			
	extFont Nam	e			Size		
	Taho	ma	~		12		
	Style	!					
	Bold		~				
	TagBind	ing			TagBitNo		
	Tag2		~			~	
					0	^	
					1		
					2 3	_	
					4		
					5		
					6	~	

5.3.17.20 Combo box



A combo box is a commonly-used graphical user interface widget. It is a combination of a drop-down list or list box and a single-line textbox, allowing the user to choose from the list of existing options in Run time. Generally it is linked with an Analog tag. Based on selection, the value of the tag will be changed, and it can be used in Logic at PLC.

It saves space in the Recorder screen by allowing the operator to select the option only when it is required by touching the down arrow at right side of Combo box.

Every Combo box is linked with single *Analog* tag from properties.

🔜 ComboBox1 Configuration	
General Items Common Events	
Appearance BackColor ButtonWidth	
TextFont Size	ון
Tahoma 12	
Bold	
TagBinding	
Tag2	

E ComboBox1 Configuration							
General	Items	Common	Events				
Option A Option B Option C Option D Option E Option F Option G							

Note: Do not keep any empty space between different text entries, otherwise, unpredictable results may occur.

Property grid

Ξ	Appearance			1
	BackColor	🔄 White		•
	ButtonWidth	20		Option A
	ForeColor	ControlText		Option B
÷	TextFont	Tahoma,12,Bold		Option C
Ξ	Behavior			Option D
	Visible	True		
	Data		<0 ntions in	Option E
	Items	(Collection) /	Decian time	Option F
	TagBinding	Tag10	Design unie	Option G

	Design						
	(Name)	ComboBox1					
	Locked	False					
	SecurityLevel	0					
Ξ	Events						
	Changed						
Ξ	Layout						
	Dock	None					
Ŧ	Location	128, 96					
Ŧ	Size	224, 24					

Properties

Button Width: Defines the width of a Button. It modifies the width of the down arrow at the right side of the combo button.

Items: Defines all the available options during design time.

For example: There are 7 options available to select a process.

Tag1, an analog tag, is linked to Combo box1

```
Now, If Option A is selected, then during Run time, Tag1 value will = 0, If Option B is selected, then Tag1 value will = 1
```

.....

If Option G is selected, then Tag1 value will = 6

Events

Changed: Defines an action using function editor. When the operator presses on a combo box during Run time, the actions defined here will be executed.

To increase up/down arrow size on combo box, increase the size of text font.

5.3.17.21 List box



A list box is a Graphical User Interface widget that allows the user to select a single item from a list of available items. The available options are entered during Design time and they are available for selection during Run Time. On selection, it writes a value to a Tag based on the order number.

Every List Box should be linked with an *Analog* tag.

GUI Wizard/dialog

🔡 ListBox1	Configuration		
General	Items Common	Events	
ADDE	arance		
	BackColo	r	ForeColor
	ScrollBarWidt	h	
	20		
⊂Tex	tFont		
	Name		Size
	Tahoma	~	12
	Style		
	Bold	~	
	TagBinding		
		~	

•	🔜 ListBox1 Configuration							
	General	Items	Common	Events				
	Select A							
	Select B							
	Select C Select D							
	Select E							
	Select F							
	Select G							

Note: Do not keep any empty space between different text entries, otherwise, unpredictable results may occur.

Property Grid

	Appearance				
	BackColor	White	E	Design	
	ForeColor	ControlText		(Name)	ListBox1
	ScrollBarWidth	20		Locked	False
Ð		Tahoma,12,Bold		SecurityLevel	0
	Behavior		Enter List of	Events	
	Visible	True	Enter List of	Changed	
Ξ	Data		Options in	Layout	
	Items	(Collection) –	Design time	Dock	None
	TagBinding	Tag10 –	💳 Select Analog 🗄	Location	176, 128
			Tag 🗄] Size	160, 112

Properties

Scroll Bar Width: Defines the width of the scroll bar that appears on Right side of List box.

Items: Define all the available options in design time.

For example: There are 6 options available to select a process.

Tag1, an analog tag, is linked to List box1

Now, If "Select A" is selected, then Tag1 value will = 0 If "Select B" is selected, then Tag1 value will = 1

If "Option G" is selected, then Tag1 value will = 5

Events

Changed: Define actions using function editor. When operator presses on list box item in Run time, the actions defined here will be executed.


5.3.17.22 Group Panel

Used to group objects in a screen.

Procedure

Click on "Group Panel" at Basic Objects

On Screen, just draw a rectangle with your mouse over the objects that you would like to group together. It will appear as shown below:



Now, double click on Group Panel object

Select "Group Controls" check box and click "OK"

Now, you will be able to move grouped objects to another location, or rescale them to fit to another screen size etc.

Group Controls: Select the check box to apply the group function. De-select the check box for ungroup

5.3.18 Enhanced Objects

Fine components are available for User interface and display. The components include Dial, Digital LED, Level, Meter, Slider, Switch, Thermometer and Toggle.

5.3.18.1 Common Properties

Appearance

Back Color: Set the background color of the component.

Bevel: Used to set border including inner border, outer border and style of border.

Inner Border: True/False

Outer Border: True/False

Style: 9 styles are available

None, Flat, Single, Double, Raised, Lowered, Double Raised, Double lowered, Frame Raised, Frame Lowered.

Behavior

Visible: True/False. Determines whether control is visible or hidden.

Enable: This is for event control. If linked with a Digital tag, if the tag value =1 during run time, events configured for the object will be executed. If tag value = 0, events will be not executed

Data

Tag Binding: Select the Analog Tag of process value

Write design time value: If selected, the value entered here during design time will be replaced by the default value defined in the tag data base.

Design

Name: Label1, It is the name of the component. Every component will have a **UNIQUE** number in a page. If more than one Label is available in the same page, the number will be incremented automatically. The user can also change name of this component if required.

Component "Name" property is very useful and it can be used in scripts also.

Example: Task: Change Label1 "back" color to blue during Run time when Tag1 is equal to 1.

```
if(Tag1 == 1)
{
    Screen1.Label1.BackColor=Color.Blue;
    }
```

Screen1: It is the location of Label1 Label1: Object name BackColor: Property of Label related to background color Color.Blue: Target Color

If the above script is executed in scheduler once per second, then when Tag1 = 1, the back color for Label1 will change to Blue during Run time.

Properties are case sensitive.

BackColor : OK Backcolor : Not OK

Security Level: Define security level for the component to be used by the operator. If operator security level is less than security level defined for component, it will not allow operator to operate the component.

Locked: True/False: It is to Move or Resize the component.

Layout

Dock: Defines which borders of the control are bound to the container.

Location: The coordinates of the upper-left corner of the component relative to upper-left corner of the container. Set X and Y position in screen in pixels.

Size: Size of the component in pixel. Set height and width of component in pixels.

Position: It is the defined position of Label, Value etc, for some components. Available options include None, Top Left, Bottom Right, Both and Internal.



Position naming convention for components


For example: Level component, Label Position = Bottom Right

If Orientation is Vertical, the Label will be displayed on the *Right* side of the component.

If Orientation is Horizontal, the Label will be displayed on the **Bottom** side of the component.

5.3.18.2 Level

Levels are normally used to display a process parameter value in several steps. Generally it is linked with Analog type tag (Analog input type tag at PLC, which is received as 4-20 mA signal from field transmitters like Ear level transmitters (sound detectors in ball mills, etc).



📰 Level1	Configurat	tion					×
General	Advanced	Values	SectionsColors	ActiveColorSection	Inactive	۲	>
	earance Ba Orientatior Vertical xtFont	ackColor 1	v	LabelsPosition Both Indent 32			
16,	Name Tahoma Style Bold		~	Size 12			
Be	vel InnerBo Style None Decimal	order		OutterBorder			
Taį	gBinding		·				

Properties

Back Color: Defines the background color for the component.

Labels Position: Define label position. Available options are Top Left, Bottom Right and Both. Naming convention depends on orientation. If orientation = Vertical, then, if "Top left" is selected, label position will be shown on "Left" side. If orientation = Horizontal, then if "Top Left" is selected, label position will be shown on "Top" side of component.

Orientation: Vertical/Horizontal. Select direction.

Text Font: Used to set the font of the label. Options include Name of Font, Size of font and Style of font. Supported styles include Regular, Bold, Italic, Underline & Strikeout.

Bevel: Defines inner border and outer border for the component. Please refer to common properties at the beginning of this section for more details.

Decimals: Define number of decimals to be displayed for value to be displayed along with level component in run time.

Tag Binding: Selects the Analog Tag of process value.

🔡 Level1	Configu	ration			×
General	Advanced	Values	SectionsColors	ActiveColorSection	Inactive 🔹 🕨
⊂ Tick:	s				
	TicksPositio	on		TicksLength	
	Both		~	32	
Scale					
- Oca	ScaleDivi	sions		ScaleLabelDivision	าร
	10			5	
	ScaleSub	Divisions		ScaleWidth	
	5			10	
-Bar-					
	BarWidth			Divisions	
	30			50	
	Space				
	1				

Ticks:

Ticks Position: Define Ticks Position. Available options include Top Left, Bottom Right, Both and None.

Ticks length: Define length of Ticks in pixels.

Scale:

Scale divisions: Define the number of Big Ticks in Level graph.

Scale Sub Divisions: Define the number of ticks between two big ticks.

Scale Label Divisions: Define the number of Labels to be displayed. Example: If Scale label division = 5, Scale = 0-100, then, it display labels as 0, 20, 40, 60, 80 & 100.

Scale Width: Define Scale width. If ticks are selected to display on both directions, this is the defined width between two scales on both sides.

Bar

Bar Width: Define width of Bar graph.

Divisions: Define number of divisions (Like bricks) to appear in Bar graph.

Space: Define Space between divisions (bricks) in pixels.

🔜 Level1 (Evel1 Configuration							
General	Advanced	Values	SectionsColors	ActiveColorSection	InactiveColorSectio			
⊂Sca	le							
	Maximu	ım		Minimum				
	100			0				
	📃 Reve	erseScale	e					
Ben	avior Step			Value				
	2			10				
	✓ IsInd	icatorOnl	у	WriteDo	esignTimeValue			
	ValuePos	ition						
	TopLeft							

Maximum: This is the max range of the process value (analog input tag)

Minimum: This is the minimum range of Process Value (analog input tag)

Example: If an Ear Level transmitter range is 0 to 100, set Minimum = 0, Maximum = 100.

Reverse Scale: True/False. If it is selected, then, zero will be on bottom side and 100 will be at top side for vertical orientation.

Step: This is the minimum value to reflect change in Bar graph position. Bar Step and Bar division settings are closely related. If Bar divisions = 50 for a scale value of 0-100, then, if Step=2, when process value changes by value 2, it shows level value change clearly in level graph.

Value: Used to enter a process value during design time and to check the bar graph display on the PC. It requires the operator to enter a value in multiples of the step value. Otherwise, it is automatically rounded to the closest multiple of the step value.



Is Indicator only: If this is selected, the level graph is used for "Read" purposes only. If it is not selected, you can use a level graph for write purposes similar to slider to send a set point from the Recorder to a PLC etc. Just use finger to touch at various places in Level graph to set the level required.

Value Position: Define position of process value to be displayed during Run time along next to the Level graph. Available options include None, Top Left, Bottom Right and Both.

🖶 Level1 Configuration	×
General Advanced Values SectionsC	olors ActiveColorSection Inactive
Section1	MaximumPercent 60
Color	MaximumPercent 80
Color	MaximumPercent 100

Sections colors: It is configure bands for the sections to show different colors for Labels and Ticks in Level graph.

Example: Three bands Section 1, Max % = 60 means, its band is from 0 to 60 %, and it will show labels and ticks in black color.

Section 2, Max % = 80 means its band is from 61 to 80 %.

Section 3, Max % = 100 means its band is from 81 to 100 %.

Note: Band setting is in % for the total Scale defined (Minimum to maximum).

🔜 Level1 Configura	tion		×
Values SectionsColors	ActiveColorSection	InactiveColorSection Common	>
	olor	MaximumPercent	
	olor	MaximumPercent 80	
Section3	olor	MaximumPercent 100	

Active Color Section: Defines the active color for the process value band. For example: If a process value range is 0-100, set different bands in % for the process value, and define colors to appear within the level Bar graph during Run Time.

When the process value is between 0 and 50 % of scale, display bricks in Lime color.

When the process value is between 51 and 80 % of scale, display bricks in Yellow color

When the process value is between 81 and 100 % of scale, display bricks in Red color.

Configuration from Property grid

	ColorSection[] Array
☑ InactiveColorSection	ColorSection[] Array

Click the "ColorSection Array and the following screen will appear. Then, set all the bands and colors.

ColorSection Collection Editor	?	X
Members: O Color [Lime] • 50% 1 Color [Yellow] • 80% 2 Color [Red] • 100% Add Remove	Color [Lime] - 50% properties:	
	OK Cancel] .::


Inactive Color Section: Define Inactive colors for process value bands the same as above. Generally, light colors are selected for Inactive colors and dark colors with more contrast are selected for Active colors. This way, users/operators will be able to differentiate between active and inactive colors easily.

😸 Level1 Configurat	ion		×
Values SectionsColors	ActiveColorSection	InactiveColorSection	Commor 🔹 🔪
Section1	lor	MaximumPercent 50	
Section2	lor	MaximumPercent 80	
Section3	lor	MaximumPercent 100	

Events: It is to trigger functions/jobs to be executed when process value of tag linked with Level bar graph is changed during run time.

5.3.18.3 Meter

A Meter is a component generally used to display process values like pressure, Temperature, Flow etc. Generally, it is linked with an Analog tag (Analog input type tag at PLC, which is received as 4-20 mA signal from field transmitters like Temperature, pressure, etc...)



😸 Meter1 Configuration	X
General Advanced Values S	ectionsColors Common Events
Appearance Bevel	PointerColor
✓ InnerBorder	OutterBorder
Style	
DoubleRaised	✓
TextFont	
Name	Size
Tahoma	• 12
Style	
Bold	✓
TagBinding	_
Tag1	

Properties

Back color: It is to set back ground color for the Meter.

Pointer Color: It is to set Pointer Color.

Bevel: It is to set border including inner border, outer border, and style of border.

Inner Border: True/False

Outer Border: True/False

Style: 9 styles are available

None, Flat, Single, Double, Raised, Lowered, Double Raised, Double lowered, Frame Raised, and Frame Lowered.

Text Font: Used to set font for the label including Name of Font, Size of font and Style of font. Supported styles include Regular, Bold, Italic, Underline & Strikeout.

Tag Binding: Select the Analog Tag of process value.

🔡 Meter 2 C	onfiguration								
General	Advanced	Values	SectionsColors	Common	Events				
Label				I					
Laber	LabelsCo	ount		Label	sRadius				
	10			120					
	☑ LabelsVisible								
Point	er								
	ExternalP	ointerRa	dius	Intern	alPointerRadius				
	80			20					
	PointerSize			Pointe					
	7			Triang	le 🎽				
Ticks									
	TicksCou	int			Length				
	10			32					
	TicksRad	lius			SubDivisionsCount				
	50			5					
	🗹 TicksV	isible							
Cente	er Width			Heigh	ıt				
	0			0					
Circle									
		rCircleC	olor		CircleColor				
	CircleRad	lius							
	150								

Labels:


LabelsCount: Number of labels to be displayed around the Meter.

Example: Pressure transmitter range 0-100 bar Label count =10 Around the Meter, you will see labels marked with 10, 20, 30, 40, 50, 60, 70, 80, 90 and 100.

LabelsRadius: It is to set the radius of Labels to be displayed around the Meter.

LabelsVisible: True/False, it is to set visibility for the label





External Pointer Radius: It is used to set external pointer Radius, define end position.

Internal pointer Radius: It is used to set Internal Pointer Radius, defines start position.

Pointer Size: It is to set Pointer Size in pixels.

Pointer Type: It is set Pointer type. Available types include Triangle, Circle and Line.

Ticks

Ticks Count: Set number of ticks between labels.

Ticks Length: Set Tick length in pixels.

Ticks Radius: Set Tick Radius


Ticks subdivision counts: Set Tick sub division counts

Ticks Visible: True/False, Set Ticks visibility

Center

Width: Adjust width of meter within boundaries.

Height: Adjust height of meter within boundaries. This is useful when a halfcircle meter is required. The meter needs to be adjusted to the center as shown below.



Circles


Border circle Color: Set border color for circle.

Circle Color: Set Color for circle.

Circle Radius: Set Radius for circle.



Note: If Border circle color is the same as the back color, then the circle will not be visible.



🔜 Meter1 Configuration								
General Advanced	Values	SectionsColors	Common	Events				
Angle And Scale								
Minim	um		-	StartAngle				
0				0				
Maxim	um		Ī	EndAngle				
100			270					
🗌 Rev								
Behavior								
Step			•	Value				
0			0					
✓ Isin	dicatorOnly	y] WriteDesignTime∀alue				

Angles & Scale

Maximum: This is the maximum range of the Process Value (an Analog input Type Tag).

Minimum: This is minimum range of Process Value (Analog input Type Tag).

Example: If pressure transmitter range is 0 to 100 bar, set Minimum = 0, Maximum = 100.

Start Angle: It is the start angle for the Range low (Analog input)

End Angle: It is the end angle for the Range high (Analog input)

Reverse Scale: It is to set scale direction in Meter

False: Anti-Clockwise

True: Clockwise




Fig: Standard Reference angle

Reverse Scale = True

For example: If you want 0° (Left) to 180° (Right) Meter for Process value range 0-100, set the following.

Start Angle: 0[°], End Angle: 180[°] and Reverse Scale = True.

Behavior

Step: It is the minimum value to reflect change of pointer position in Meter.

For example: By default, Step = 0, i.e., the pointer moves its position in the Meter in Real time even with a minor change in process value.

For example: Step = 5, i.e., the pointer moves its position on the Meter in Real time in steps of 5.

Value: It is used to enter process value in design time and check pointer position in PC.



Indicator only: By default, it should be selected so that the meter will be used for Read purposes only. If it is not selected, then you can use the Meter for Write purpose similar to a Slider to send a set point from the Recorder to a PLC etc. Just use your finger and move pointer to change set point.

Write design time value: If selected, it writes design time value instead of default value defined at tag data base.

Meter1	's Propert	ies		
General	Advanced	Values	SectionsColors	Common Events
	SectionCou 3	nt	×	
Se	ction1	Color		MaximumPercent
	ction2	Color		MaximumPercent 80
Se	ction3	Color		MaximumPercent 100

Sections colors:

It is to configure bands for the sections to show different colors for Labels and Ticks in Meter.

Example: Three bands

Section 1, Max % = 60. That means its band is from 0 to 60%. It shows labels and ticks in black color.


Section 2, Max% =80 that means, its band is from 61 to 80 %.

Section 3, Max % = 100 that means, its band is from 81 to 100 %.

Note: Band setting is in % for the total Scale defined (Minimum to maximum).

5.3.18.4 Slider

This is normally used to change the set point of a process by the operator from the Recorder during Run time. Generally, it is linked with an analog tag (analog output type tag at PLC, to send 4-20 mA signal out from PLC to external Controllers, Variable speed drives, etc).



In the above figure, Scale divisions = 10 (Big ticks). Scale sub divisions = 5 (Small ticks between big ticks). Scale Label divisions = 10 (0, 10, 20 till 100).

📕 Slider1 (Configuration				
			SectionsColors	Common	Events
	earance Bac Acti	kColor veBarCo erBarCol	lor	" []	LedColor InactiveBarColor LabelsPosition
	Orientat Horizon	ion		[TopLeft Indent 16
Slie	derSize Width 32				Height 48
Te	xtFont Name Tahom	8	v	_	Size
	Style Bold		•	L	
Be	vel V Inner Style	Border			✓ OutterBorder
	Flat Decima	1	*		
	0				
	TagBinding Tag2]	~		

Properties

Back color: Back color for the component.

Active bar color: Define active bar color.

Slider bar color: Define border color for the slider.

LED color: Color of the handle

Inactive bar color: Define inactive bar color.

LabelsPosition: Define Label position. Available options include Top Left, Bottom Right, Both, Internal and None.

Orientation: Horizontal/Vertical. This is the orientation of the slider component. In the above figure, it is in the Horizontal position.

Slide size: Define height and width of the slider.

Text Font: It is to set the font for the label including Name of Font, Size of font and Style of font. Supported styles include Regular, Bold, Italic, Underline & Strikeout.

Bevel: It is to set a border including inner border, outer border and style of border.

Inner Border: True/False

Outer Border: True/False

Style: 9 styles are available

None, Flat, Single, Double, Raised, Lowered, Double Raised, Double lowered, Frame Raised, and Frame Lowered.

Tag Binding: Select the Analog Tag of a process value.

🔜 Slider1 (Configuration				
General	Advanced	Values	SectionsColors	Common	Events
Tick					
	TicksPo	sition			TicksLength
	Both		~		8
				L	
Scal					
	ScaleD	ivisions		:	ScaleLabelDivisions
	10			•	10
	ScaleS	ubDivisio	ons		ScaleWidth
	5				20
	3			L.	20
Bar					
, Dui	BarWid	th			
	15				
	15				

Ticks:

Ticks Position: Define ticks position. Available options include Top Left, Bottom Right, Both, Internal and None.

Ticks Length: Set Tick length in pixels

Scale:

Scale divisions: Define number of Scale divisions (Big ticks).

Scale Sub Divisions: Define number of Sub divisions (Small Ticks between big ticks).

Scale Label Divisions: Define number of Labels to appear. Ex. 0, 10, 20 etc. till 100 for scale 0 to 100.

Define same value for both Scale divisions and Scale label divisions.

Scale Width: Define Scale width.

Note: This is only the width for Scale divisions. Example: If ticks position is selected on both sides, then it is the gap between two scale ticks (Top and Bottom in Horizontal orientation or Left and Right in vertical orientation).

Bar:

Bar Width: Define width of Bar.

🔜 Slider1 Configuration				
General Advanced	Values Secti	onsColors	Common	Events
Scale Maximu 100 Reve	im erseScale]		Minimum O
Behavior				
Step		_		Value
1				20
🗌 Islnd	icatorOnly		۵] WriteDesignTimeValue
ValuePos	ition			
BottomRi	ght 🖌			

Scale:

Maximum: This is maximum range of Set point (Analog Tag, Normally Analog Output).

Minimum: This is minimum range of Set Point (Analog Tag, Normally Analog Output).

Example: If Controller set point is 0 to 100 Deg.C, set Minimum = 0, Maximum = 100.

Reverse Scale: If Selected, Scale labels will be displayed in Reverse.

Behavior:

Step: It is the minimum value change when the slider is moved.

For example: By default, Step = 0, i.e., Slider moves its position in Real time even with minor change in process value.

For example: If Step = 5, Slider moves its position in Real time in steps of 5.

Value: It is used to enter process value in design time and check the Slider position in PC.


Indicator only:



If Indicator only is selected, slider is used for Read only. Operator will be not able to move slider in Run time.

If Indicator only is not selected, the slider is used for Read/Write. Operator will be able to move slider in Run time for example: change set point for variable speed drive.

Value Position: Define position for the value to appear during Run time. Available options include Top left, Bottom Right, Both, Internal and None.



Sections colors: It is configure bands for the sections to show different colors for Labels and Ticks in Slider.

Example: Three bands

Section 1, Max% =60 means its band is from 0 to 60%. It shows labels and ticks in black color.


Section 2, Max% =80 means its band is from 61 to 80%. It shows labels and ticks in brown color.

Section 3, Max% =100 means its band is from 81 to 100%. It shows labels and ticks in Red color.

Note: Band setting is in % for the total Scale defined (Minimum to maximum).

5.3.18.5 Thermometer

This is normally used to view process temperature by operator during Run time. Generally it is linked with an analog tag (Analog input type tag at PLC, which is received as 4-20 mA signal from field transmitters like Temperature etc...)



Scale Label Divisions= 10 (0, 10, 20... 100)

Scale Divisions = 10 (No.of Big Ticks)

Scale Sub Divisions = 10 (No.of Small ticks between Big Ticks)

Thermometer 1's Properties General Advanced Values SectionsColor	s Common Events
Appearance BackColor Orientation Horizontal TextFont Name Tahoma	LiquidColor LabelsPosition TopLeft Indent 16 Size 14
Style Bold Bevel InnerBorder	CoutterBorder
Style DoubleRaised Decimal 0	C Rounding
TagBinding TagBinding <mark>Tag2</mark>	

Properties

Back Color: Define back color for the component.

Liquid color: Shows temperature level (mercury) in Thermometer.

Tank Color: Define background color of thermometer without mercury.

LabelsPosition: Define Label position. Available options include Top Left, Bottom Right, Both, Internal and None. The naming convention is based on the selected orientation of the component.

Orientation: Horizontal/Vertical. This is orientation of component. In the figure above, it is in the Horizontal direction.

Indent: It is the gap between border and start of scale.

Text Font: It is to set font for the label including the Name of Font, Size of font and Style of font. Supported styles include Regular, Bold, Italic, Underline & Strikeout.

Bevel: It is to set the border, including the inner border, outer border and style of border.

Inner Border: True/False

Outer Border: True/False

Style: 9 styles are available

None, Flat, Single, Double, Raised, Lowered, Double Raised, Double lowered, Frame Raised, and Frame Lowered.

Tag Binding: Select the Analog Tag of process value.

💀 Thermometer1 Configuration								
General	dvanced	Values	SectionsColors	Common	Events			
~Ticks-								
	TicksPo	sition		-	FicksLength			
	Both		~	1	10			
Scale								
	ScaleD	ivisions		5	ScaleLabelDivisions			
	10			1	10			
	ScaleS	ubDivisio	ons	e.	ScaleWidth			
	10				30			
Bar								
	BarWid	th						
	12							

Ticks Position: Define ticks position. Available options include Top Left, Bottom Right, Both, Internal and None.

Ticks Length: Set Tick length in pixels

Scale divisions: Define number of scale divisions (Big Ticks) for the component.

Scale Sub Divisions: Define number of Sub divisions between the above scale divisions (Number of Small ticks between any two Big Ticks).

Scale Label Divisions: Define number of Labels to be displayed for component as per Scale Range of process value. For ex: 0, 10, 20, 30...100.

Scale Width: Define Scale width. If you have ticks on both sides of the component, it defines the width between Upper (Left) and Lower (Right) scale divisions based on orientation of component.

Bar Width: Define width of Bar in pixels.

🔜 Therm	ometer1 Config	uration			
Genera	Advanced	Values	SectionsColors	Common	Events
Sc	ale				
	Maximu	ım			Minimum
	100				0
	🗌 Reve	erseScale			
Be	havior				
	Step				Value
	0				60
	🔽 IsInd	icatorOnly	¥	I	UvriteDesignTimeValue
	ValuePos	ition			
	BottomRi	ght	~		

Maximum: This is maximum range of the Set point (Analog Tag, Normally this is an Analog input, 20 mA, 10V DC etc.)

Minimum: This is minimum range of Set Point (Analog Tag, Normally this is an Analog input, 4 mA, 0V DC etc.)

Example: If Temperature transmitter range is 0 to 100 Deg.C, set Minimum = 0, Maximum = 100.

Reverse Scale: True/False. Define Scale direction.

Step: It is the minimum value to reflect change of mercury level.

For example: By default, Step = 0 means the Mercury level moves in Real time even with a minor change in process value.

For example: Step = 5 means the Mercury level moves its position in Real time in steps of 5.

Value: It is used to enter a process value during design time and check mercury level position on the PC.

Indicator only: If selected, this component is used for Read only. If it is not selected, then this component can be used for Write/Read purpose.

Write design time value: If selected, it writes design time values instead of default values defined in the tag database.

Value Position: Define position for the value to appear during Run time. Available options include Top left, Bottom Right, Both, Internal and None. The naming convention is based on the orientation of the component.

📰 Thermor	neter1 Config	uration			
General	Advanced	Values	SectionsColors	Common	Events
	SectionCo 3	unt	\$		
Section1 Color		_	MaximumPercent 60		
Section2			_	MaximumPercent 80	
Sec	tion3	Color		_	MaximumPercent 100

Section Colors: Define bands to display Ticks and Label color accordingly based on the value of the tag during Run time.

5.3.18.6 Bar Box

Bar Box is a Graphical User Interface widget that displays a bar graph for an Analog Tag during Run Time.

Every Bar box should be linked with an *Analog* Tag.

 g	3arBox1's Properties
	General Bands Common Events
	Appearance BackColor BorderStyle None
	Behavior RangeHi RangeLow 100 0 Value 50
	TagBinding TagBinding Tag1 ▼

Properties

Border Style: Define border style. Options include Fixed single, Fixed 3D and None.

Direction: Define direction of Bar graph. Up/Down/Left/Right

Range high: Display scale high.

Range Low: Display scale low.

Value: Default value. It is to check how fore color, back color displays in PC during design time.

BarBox1 Configuration				
General Ba	ands Common			
B	andCount			
3	÷			
⊂Band1				
	BackColor	ForeColor		
Blink	🗌 Blink	BlinkColor		
Band2				
Blink	BackColor	ForeColor		
Dimk	🗌 Blink	BlinkColor		
	Value			
	40			
Band3	BackColor	ForeColor		
Blink				
	🔲 Blink	BlinkColor		
	Value			
	90			

Tag Binding: Select the Analog Tag of process value.

Bands

It is to define various bands for the process value to appear and display animation in Run time.

Band count: Use up/down buttons to increase/decrease number of bands. Maximum 32 bands are supported. In each band, it is possible to configure back color, fore color and blink properties.

Back color: Define back color.

Fore Color: Define fore color.

Blink: Select "True" if blink is required and "False" if blink is not required.

Blink color: If "True" is selected for blink, then this property is visible and you can select required blink color.

Value: It is the band range. For the first band, it is always the Range Low value defined for the bar box. Band 1 high range is the value defined at Band2. Band 2 high range value is the value defined at Band3 and so on.

5.3.18.7 Scale

Screen1	Scale1's Properties	
<u></u>	General Common	
	Appearance BackColor LineWidth 2 Grids 10	ForeColor Direction Right 🗨 Decimal
-4 -3 -2	Minimum 0 Rounding	Maximum 10 II ReverseScale
	TextFont Name Tahoma Style Regular	Size 12

Scale is a Graphical User Interface widget used along with bar box if required.

Properties

Back color: Define back color

Fore Color: Define fore color

Line width: Define width of line

Grids: Define number of grids

Direction: Define direction of Scale. Up/Down/Left/Right

5.3.18.8 Picture box

Picture box permits the user to link different picture files into a Picture box component during design time and then later view them during Run time based on the value of the Tag. Supported formats include

Bitmap file (*.bmp) Windows Metafile (*.wmf) JPEG File (*.jpg) Graphics Interchange format (*.gif) Portable Network Graphic (*.png)

PictureBox1's Properties	
General Animation Bands Common Events	
Appearance BackColor	
BitmapFile	ImageLayout
Transparent	TransparentColor
Flip None	Rotate
TagBinding TagBinding	

Properties

Bitmap file Select the image to be shown in the object

Flip: It is to flip picture file during design time. Available options are Horizontal, Vertical, Both and None.

Rotate: It is to select direction for the picture file during design time to adjust direction. Available directions include 0° , 90° , 180° and 270°

Tag Binding: Select the Analog tag to be linked with Picture box.

🖶 Picture	PictureBox1 Configuration				
General	Animation	Bands Common]		
Mov	ement				
🗆 E	nableMove				
Sta	artPosition -			CEndPosition	
	X			X	
	0				
	0			0	
Tag	Value From			То	
	From 0			100	
	U			100	

Movement: Select "Enable Move" if it is required to move picture during Run time from Location 1 to Location 2 based on a tag Value. Start and End coordinates for X and Y needs to be configured during Design time, and the Picture moves in Run time based on a Tag value.

Tag Value: Define Tag value	
🔜 PictureBox1 Configuration	
General Animation Bands Common	
BandCount	
Band1 BackColor	Visible
Image BitmapFile	ImageLayout None
Transparent	TransparentColor
Flip None	Rotate 0

Band Count: Define number of bands required.

Back Color: Define back color for the selected picture file in specific band.

Visible: Define visibility for the picture in specific band.

Bitmap file: Select picture file for specific band.

Image Layout: Position of image within Picture container. Available options include None/Center/Stretch. When stretch is selected, it attempts to fit the picture file to the size of container.

Transparent: Select if no back color is required for picture file.

Flip: It is to flip picture file during design time. Available options are Horizontal, Vertical, Both and None.

Rotate: It is to select the direction for the picture file during design time to adjust direction. Available directions include 0° , 90° , 180° and 270°

Example: You may take a photo of a section of the factory floor like a tank, then use this on the Recorder screen instead of a default symbol.

A bitmap file by the name sunset.jpg is linked with Picturebox1 in screen1. If you wish to have the same sunset.jpg in screen no2, do not create picture box and link with sunset.jpg again. Since a resource with name sunset already available, if you try to use the same image in other place, it may not allow you to do so, and may give you an error message. If you really need the same image again, copy picture box1 at screen1 and paste it in screen no 2.

5.3.19 Graphics


Graphics are used to place a symbol in a screen like a Tank, Motor etc... Basic symbols are available in Recorder Editing Software and it includes the following symbol categories.

Symbol categories

	Category	Symbols	Colors	Qty
1	Arrows	7	6	42
2	Blowers	5	6	30
3	Boilers	4	6	24
4	Conveyors	6	6	36
5	Instruments- True Color	7	С	7
6	Lamps	4	6	24
7	Material handling	8	С	8
8	Motors	4	6	24
9	Nature-True Color	6	С	6
10	Office-True Color	7	С	7
11	Pipes	10	6	60
12	Power-True Color	7	С	7
13	Pumps	5	6	30
14	Push buttons	8	6	48
15	Tanks	5	6	30
16	Valves	8	6	48
17	Vehicles-True Color	6	С	6

C = True Color

Toolbox	Ę
Basic objects	
Enhanced objects	
SymbolFactory	Motors
Graphics	- Nature
😑 C:\Program Files\Panel Studio\Basic Sy	mbols Office
Arrows	- Pipes
Blower	Power
Boilers	Pumps
- Conveyors	Push buttons
- Instruments	Tanks
Lamps	Valves
Material Handling	- Vehicles



Some symbols are available with 6 different colors. They are Red, Green, Yellow, Blue, Brown and Grey.

All the symbols are vector graphics. They occupy less memory and have high quality.

It is possible to set the transparent property for symbols during design time from the property grid. "Transparent" means the screen color itself will appear as back ground color, making the object appear to be see-through. Also, it is possible to change the symbol background color during design time and Run time.

How to set the "transparent property to a symbol from the property grid

	🔡 Band Editor	
	Members: 0 Band1	Band2's Properties:
		ElimapFile arrow1-b.wmf Flip None
		Rotate 0 Value 100 Visibility 100
Properties 4 ×		Visible True
Behavior		BackColor
Animatio False;0, 0;0, 0;0;10 Bands (Collection)	Add Remove	
Data TagBindii		OK Cancel

Click "Bands", then set "BackColor" to "Transparent"






Fig: Back color=Transparent

Fig: Back Color=Green

Since all symbols are vector symbols, if a symbol is enlarged, it does not lose quality.

When Recorder Editing Software is installed, all basic symbols will be installed in the default folder C:\Program Files\Recorder Editing Software\Recorder Editing Software\Basic Symbols

In addition, if the application developer has any additional symbols, they can be placed in the same folder as the basic symbols for use in the project.

Example: Create a folder named "Custom", and place it in C:\Program Files\Recorder Editing Software\Basic Symbols

It is possible to a set path for graphic symbols in the Recorder software. On the Menu bar, click the "File" dropdown menu, select "Environment", then select "Graphics path". All these will appear in a tree type structure within Recorder editor avoiding the need to import these symbols using a "Picture Box".

Fil	e Edit Format View		
	New >		
6	Open Project Ctrl+O		
	Close Project		
	Save Project Ctrl+S		
	Save Project As		
1	Upload		
	HMI Update >		
	Environment Ctrl+E		
	Recently >		
	Exit		

🔚 Environment		
General Download and Upload	Environment	
Snap and Grid Object default setting	Language	English
	TextFont	Microsoft Sans Serif, 9.75pt, style=Bold
	DateTimeFormat	
	DateFormat	dd-MM-yy 26-12-11
	TimeFormat	h:mmiss tt 2:36:37 PM
	Path	
	Project	
	Graphics	
	Security	
	Password	
	Confirm	

Once a symbol is selected in the Recorder from Graphics, it is possible to change, Flip or rotate basic symbols in 0^0 , 90^0 , 180^0 and 270^0

🔜 MyPicture1 Configuration					
General Animation Bands Common					
TagBinding					
			~		

Properties

Tag Binding: Select an Analog Tag if animation is required for the symbol in Run time.

🖶 MyPicture1 Configuration	
General Animation Bands Common	
Movement	
✓ EnableMove	
StartPosition X 0 Y 0	EndPosition X 100 Y 200
Tag Value From O	То 100

Movement: Select the Enable/Move checkbox, then, enter the X and Y start and end positions (this is in pixels).

Tag Value: Linked with the Start and End Positions.

Ex: Recorder 7" (High Performance), Screen Resolution = 800 X 480, Horizontal installation, Width=800, Height=480. Move symbol from Left to Right of screen during Run time when tag value changes from 0 to 100

🔜 MyPicture1 Configuration 🛛 🗙
General Animation Bands Common
Movement EnableMove StartPosition X 0 Y 0 0 0 0 0 0
Tag Value From To 0 100

To move the symbol from Left to Right, set start and end Positions for X coordinate in pixels, there is no need to set Y coordinates.

Tag value = 0 corresponds to Start Position (X)

Tag value = 1000 corresponds to End Position (X)

Ex: Recorder 7" (High Performance), Screen Resolution = 800 X 480, Horizontal installation, Width=800, Height=480. Move symbol from Top to Bottom in screen at Run time when tag value changes from 0 to 100

General Animation Bands Common Movement EnableMove
EnableMove
StartPosition
Y Y
0 480
Tag Value From To
0 100

Ex: Recorder 7" (High Performance), Screen Resolution = 800 X 480, Horizontal installation, Width=800, Height=480. Move symbol from Left Top to Right Bottom on screen at an angle during Run time when the tag value changes from 0 to 100

🔜 MyPicture1 Configuration	<
General Animation Bands Common	
Movement EnableMove StartPosition X 0 Y 0 480	
Tag Value From To 0 100	

🖶 MyPicture1 Configuration	×
General Animation Bands Common	
BandCount	
Band1 BackColor	Visible
BitmapFile	ImageLayout
arrow1-b.wmf	None
Transparent Transparent	TransparentColor
Flip	Rotate
None	0


Band Count: Used to define bands for run time animation of symbol. Max. 32 bands are supported.

Back Color. Define Back Color of the symbol that should appear in a specific band during Run time.

Visible: Define visibility control for the symbol in a specific band during Run time.

Image: Select different image file to display in a specific band during Run time.


Flip: Define the flip position for the symbol in a specific band during Run time. Available options include None, Horizontal, Vertical and Both.




Rotate: Rotate symbol to any predefined direction in a specific band during Run time. Available options include 0° , 90° , 180° and 270°

Example: There is Liquid level Tank. When the Tag value =0, an arrow should appear pointing in the Down direction indicating that a discharge of the tank is in progress. When the Tag value = 1, the arrow should appear in the Up direction indicating filling of tank is in progress.

B MyPicture1 Configuration	
General Animation Bands Common	
BandCount	
Band1 BackColor	Visible
BitmapFile arrow5-r.wmf	ImageLayout
Flip	TransparentColor Rotate
Band2 BackColor	Visible
Image BitmapFile arrow5-r.wmf	ImageLayout
Transparent Transparent	TransparentColor
Flip None	Rotate 180
Value 1	





5.3.20 Symbol Factory

Symbol Factory $\ensuremath{\textcircled{B}}$ contains more than 4000 symbols in 64 categories.


No.	Category	Symbols	No.	Category	Symbols
1	3-D Pushbuttons	73	35	Machining	90
	Etc.				
2	Air Conditioning	140	36	Maps and Flags	23
3	Architectural	49	37	Material Handling	118
4	Arrows	63	38	Mining	63
5	ASHRAE		39	Misc. Pipes	39
	Controls &	100			
	Equipment				
6	ASHRAE Ducts	86	40	Misc. Symbols 1	57
7	ASHRAE Piping	49	41	Misc. Symbols 2	79
8	Basic Shapes	86	42	Mixers	24
9	Blowers Etc.	34	43	Motors	38
10	Boilers	36	44	Nature	71
11	Buildings	42	45	Operator Interface	28
12	Chemical	50	46	Panels	14
13	Computer	38	47	Pipes	82
	Hardware				
14	Computer Keys	68	48	Plant Facilities	52
15	Containers	56	49	Power	61
16	Controllers	35	50	Process Cooling	20
17	Conveyors, Belt	40	51	Process Heating	61
18	Conveyors, Misc.	26	52	Pulp & Paper	35
19	Conveyors,	56	53	Pumps	99
	Simple				
20	Ducts	51	54	Safety	27
21	Electrical	83	55	Scales	36
22	Finishing	45	56	Segmented Pipes	41
23	Flexible Tubing	24	57	Sensors	55
24	Flow Meters	35	58	Tank Cutaways	23
25	Food	72	59	Tanks	145
26	General Mfg.	68	60	Textures	181

27	Heating	108	61	Valves	73
28	HVAC	74	62	Vehicles	41
29	Icons and	159	63	Water &	112
	Bitmaps			Wastewater	
30	Industrial Misc.	19	64	Wire & Cable	21
31	International	42		Total	4045
	Symbols				
32	ISA Symbols	183			
33	ISA Symbols (3-	123			
	D)				
34	Laboratory	23			

With Recorder Editing Software, only the first symbol from the symbol factory can be selected. If you need all symbols, order our Recorder Editing Software Plus, and we will supply a USB hardware lock to access more than 4000 symbol factory graphics.

It is possible to link a Analog Tag with a Symbol factory graphic and change its colors during Run time. Up to 50 bands are supported.





Screen18	Symbol Factory .	NET Property Page	
Symbol factory Run time 4:20:15	Symbols Style Animations		
< 10 : Yellow Blinking 10 to 19 : Yellow steady	AnimationMode : BandCount :	AnalogColorFill	
20 to 79 : Green Color 80 to 89 : Red Color > 90 : Red Color blinking	Band1	Style BlinkShaded	Breakpoints
First Page Next Page Previous Last Page	Band2	Shaded 💌 💻	90
······	Band3	Shaded 💌 🔳	80
	Band4	Shaded 💌	20
utput	Band5	BlinkShaded	10

Design Time

During design time, the applications engineer is allowed to change the colors of these symbols.

Example: Change tank color from standard grey scale to Green color.

Task: Place symbol on a screen



In Tool box, click "Symbol Factory", then drag and drop a standard control to the screen.




Fig 1	Fig2	Fig3	
	· · · · · · · · · · · · · · · · · · ·		

Fig4

Task: Increase size of symbol

Select the symbol on the screen. It will be as shown as in fig2 above.

Then, move mouse to a square pointer till an arrow appears. Left-click and hold the mouse. Drag the mouse to increase size of symbol as per your requirement and then it will be as shown as in Fig4 above. Alternatively, in the property grid, enter the size in pixels as shown below.

Ξ	Size	120, 100
	Height	100
	Width	120


Task: Changing symbol to another category

· · · · · · · · · ·	./	/	ĊI	ic	k ł	ne	re	·	•		
								asl Pro		ties	
• (🛞)"-	0										•
	0	•	•	•	•	•	•	•	•	•	•

Drag and the drop symbol factory component onto a screen.

Click I, then click on Symbol Factory.NET Properties.

Alternatively, select the symbol factory component using single click (left) with the mouse. Keep the mouse cursor on the symbol, then, double click (left) the mouse to open symbol properties. The following screen will pop up.



Select the required category, select the symbol, then click on button "OK", then new symbol will be placed in screen.

Click on Help in the above screen to open a Chm type help file (English) for the symbol factory.

· • • • • • • • • • • • • • • • • • • •	Standa	rdCon	trol 1	ask	s			
	Symbol F	actory	NET	Prop	pertie:	s	• •	
	1						• •	• •
i i i i i i i i i i i i i i i i i i i				÷		÷		
		· ·	· ·	•	· ·	•	• •	
Symbol F	actory Dot	Not						
S S S S S Symborn	actory Dot	ilet						
No categ	ory (*.CAT2) I	files we	ere fo	und i	n Cat	egor	y_Fil	es.
Perhaps	you should rei	nstáli ti	his pro	oduc	t.			
	-	0.14		1				
	L	OK		J				

If the above error message appears, it is required to reinstall symbol factory.

Style

Used to define the style of symbol in design time.

🗣 Symbol Factory .NET Property Page					
1	Symbols	Style	Animations		


Click on "Style". The following screen will appear.

Symbol Factory .NET Property Page				×
Symbols Style Animations				1
	Fill Color FillColorMode : FillColor :	Original	~	Defaults About
	Background BackStyle : BackColor :	Transparent		
Orientation Flip : None	Blink BlinkMode :	NoBlink	•	
Rotation : 0	BlinkSpeed : BlinkColor :	Medium_800	*	
Stretch				
	(ок) (Cancel (Apply Help

Fig: Default Style settings

Orientation:

Flip: It is possible to flip the symbol during Design time. Available options include Horizontal, Vertical, Both and None.



Flip=None

Flip = Horizontal


Rotation: It is possible to rotate symbol during design time. Available options include 0^0 , 90^0 , 180^0 and 270^0

Padding: Normally it is 0. It is used to decrease size of symbol within selected boundaries.

Stretch: It is used to stretch symbol within selected boundaries.

Fill Color:

Fill color mode: Available options include Original, Shaded, Solid and Hollow.



Fill color: Define color to be filled in Shaded and Solid fill color mode.

Background:

Back Style: Available options include Transparent & Opaque. Transparent means screen background color will appear for symbol. Opaque means, it is possible to set different background colors for a specific selected symbol.

Back color: Define background color when the back style = Opaque.

Blink:

Blink mode: Available options include No Blink, Blink Invisible, Blink shaded and Blink Solid.

NoBlink: Indicates "Blink" is not required for symbol during design time or Run time. Blink Speed and Blink color = Not available when this is selected.

BlinkInvisible: Symbol will appear and disappear cyclically during both design time and Run time per the set Blink speed. Blink color: Not Available for selection.

BlinkShaded: Symbol will flash 2 colors, one color at a time on the same symbol per the set blink speed during both design time and Run time.

Example

Fill Color mode = Shaded, Color = Green

Blink shaded setting: Blink mode=Blink shaded, Blink speed = Medium_800, Blink color = Blue

The green color shaded symbol appears first, then the symbol turns into a blue shade after elapsing the preset time in the blink speed setting.

Blink speed: Define blink speed. Available options include Fast_400, Medium_800, and Slow_1200. Its period is in *ms*.

Blink color: Define background color



Normally, blink is not used during design time. Default settings are as follows.

1. Fill Color Mode = Original. If a different color is required for the symbol, select Fill color mode = Shaded, then define the Fill color.

- 2. By default, Back Style = Transparent in Background
- 3. By Default, Blink mode = NoBlink

Animation

It is to define animation for the symbol to appear at Run time in Recorder.

Animation mode:

Define animation mode. Available options include Analog Color Fill, Discrete color fill, Analog integer color fill.

AnalogColorFill: Select this option if you wish to link an analog ta. Then define the band for the colors. For ex: 0 to 10, Color = Yellow, 10-90, Color = Green, 90-100, Color = Red etc.(See next section "How beak points work" for more details)

DiscreteColorFill: Select this option if you wish to pass discrete values like 1,2,3... during Run time to the Tag linked with symbol for the display of different colors. (See next section "How beak points work for more details)

AnalogIntegerColorFill: This is the same as Analog color fill, but only integer values are passed to the Tag linked with the symbol. (See next section "How beak points work for more details)

Band count: Defines the number of bands required for the selected Animation mode

Styles: Define style of symbols. Available options include Original, Shaded, Solid, Blink Invisible, Blink shaded and Blink solid. All definitions are the same as explained earlier.

5.3.20.1 How break points work

The idea behind Breakpoints is that certain animation will occur when a property of the component changes. If this change falls within the defined parameters (see below), an animation will be triggered.

Please note: The screen shots in the examples below are based upon the Symbol Factory .NET Standard Control, but the same principle applies to the Cutaway control.

Two types of animation can be defined based upon the setting of Animation Mode: Analog Break Points and Discrete Break points

Analog Break points (Animation Mode = Analog integer color fill or Analog color fill)

Analog breakpoints are defined as a value on which an animation will trigger when a property of the component reaches that level. Depending upon your component, different properties will need to be changed depending upon the setting of Animation Mode. These properties are:

Component	Animation Mode Setting	Property that Changes to trigger an Animation
Standard	AnalogColorFill	AnalogValue1
Standard	AnalogIntegerColorFill	AnalogIntValue1
Cutaway	AnalogColorFill	Level
Cutaway	AnalogIntegerColorFill	LevelInt

Number and Ordering of Breakpoints

The number of breakpoints available to you is the number of bands defined minus 1. As a breakpoint is defined as the point to which an animation changes, make sure you arrange the breakpoints from high to low. For example, suppose you had this screen:

Band1	Style Blink Shaded 💌 🚺	Breakpoints
Band2	Shaded	90
Band3	Original	
Band4	Shaded	20
Band5	Blink Shaded	

When the value of your property changes, this is what will happen to the control:

Value of Property	Band that is Active	Appearance of Component
Less than 10	Band5	Blink Shaded Red
10 to < 20	Band4	Display Shaded Yellow
20 to < 80	Band3	Original
80 to < 90	Band2	Display Shaded Yellow
Greater than 90	Band1	Blink Shaded Red

If you do not order your breakpoints in a descending order, your results will be unpredictable.

Discrete break points (Animation mode = Discrete color fill)

Discrete Breakpoints aren't really breakpoints, instead, they enable animation if the "DiscreteValue" of an element in the BandsCollection is set to true.

However, since multiple DiscreteValue properties can be set at the same time, how does the component determine the animation to display? What it does is give priority to the animations based upon their order in the BandsCollection. If the first band in the collection (by default, Band1) has its DiscreteValue set to True, then that animation will be shown no matter which band also has its DiscreteValue set to true. As another example, if Band2 and Band5 each have their DiscreteValue set, the animation that is used will be the one defined in Band2.

Therefore, given the following definition of five bands:

Band1	Style Blink Shaded	•
Band2	Shaded	
Band3	Original	•
Band4	Shaded	
Band5	Blink Shaded	•

Here is what the animations will be shown based upon different values of Discrete Value

Discrete Value for Band1	Discrete Value for Band2	Discrete Value for Band3	Discrete Value for Band4	Discrete Value for Band5	Appearance of Component
True	False	False	False	False	Blink Shaded Red (Band1)
False	True	False	False	False	Shaded Yellow (Band2)
False	False	True	False	False	Original (Band 3)
False	False	False	True	False	Shaded Orange (Band 4)
False	False	False	False	True	Blink Shaded Black (Band 5)
True	True	True	True	True	Blink Shaded Red (Band 1)
False	True	True	True	True	Shaded Yellow (Band 2)
True	False	False	False	True	Blink Shaded Red (Band 1)
False	False	False	False	False	Original (No bands active)

5.3.21 Project Tools

Pr	oject	Help	
	Build	I	F6
	Build	F7	
	Build	F8	
	Online Simulation		
	Stop		
	Build	And Download	
	Dow	nload	
	Proje	ect Status	

5.3.22 Build

Once the project is compiled successfully, it creates a build. This build then needs to be transferred to the Recorder. If there are any errors during the preparation of the build, it will be shown in the output window just below the screen working area. If the Output screen is not visible below the screen working area, select it via Menu, "View", and then click "Output" or apply "Reset window layout" from the Menu-"View"

Output
Screens preparing Screen1 images 0 / 0 objects 0 / 0 UserScripts checking Objects checking Alarms checking Scheduler checking Datalogs checking Recipes checking
Build started
Build succeeded.

After creating a build, if any errors are shown at Output window, do not attempt to download the application from PC to Recorder, or PC to USB flash disk First clear the errors and make sure that compilation errors are not present before transferring the application to the Recorder.

5.3.23 Build & Offline Simulation

First, it creates a build, then runs an Offline simulation.

It is used to test the application on the PC before downloading the application to the Recorder, without connecting a PLC to either PC or Recorder. It is possible to enter some values for the tags via a table to check how the application would appear during run time.

🛃 OffLine Simu		
Tag	CurrentVal	SetVal 🔺
Tag1	12	
Tag2	0	
Tag3	0	
Tag4	0.0788529868553987	
Tag5	58.4416722356357	
Tag6	0	
Tag7	0.39426493427699	
Tag8	0.39426493427699	
Tag9	0	
Tag10	0	•

Enter a value under the "SetVal" column, then press the enter key on your keyboard. It will accept, then show at "CurrentVal". You will now be able to see these values in objects linked with the specific tag.

It is better to run offline simulation frequently say once in couple of hours or after completing specific screen editing by application engineer to verify how it will works on a Recorder so that if there are any compilation errors, it is easier to locate and rectify them.

5.3.24 Stop

It is used to stop a simulation on the PC. When Offline simulation is running, click the lcon to stop the current running simulation. See the picture below. It is located

beneath the "help" dropdown menu.

File	Edit	Format View	Objects	Project	Help	
🗗 • 🚵) 🕑 🖕 🖻 🛍 🕻	× #	🔆 🔛) 🔕 💽	100% 🝷 🔲
[# 4]	â 🖨	\$ 희 파 표 *	0 🛱 🗐 9	김 尊 매 것	· 및 및 목 움	처 하 하 문 🕀

If Offline simulation or online simulation is already running on the PC, and the user attempts to run it again, the build will fail. It prompts an error message similar to the following

Screen1 Build Started.... Could not write to Output file "C:\Program Files\Project\Recorder\Panel.exe" "The process cannot access the file because it is being used by another process" Build Failed

In the case of the above message is prompted, click the Stop icon is a couple of times and make sure that icon is not available in Task bar. Click "Build" once again, then run simulation.

5.3.25 Build & Download

It is to build first and then download application from PC to Recorder.

5.3.26 Download

It is to download application from PC to Recorder

Available options

- i) PC to Recorder via Ethernet
- ii) Removable Disk to Recorder via USB flash disk

PC to Recorder via Ethernet:

After creating an application, create a build on the PC, and make sure there are no compilation errors.

Connect Ethernet cable between PC and Recorder

In editor software, set Environment for Download via Ethernet and enter the IP address of the Recorder. In Environment, Select "Ethernet" at Download, then click the "OK" button.

In editor software, click "Project", then click "Download" or click the 星 icon.

The software will build and transfer the application from the PC to the Recorder. If there are any errors during compilation, they need to be fixed. Once the compilation errors are fixed, please attempt to download again.

🔜 Environment			
General Download and Upload Snap and Grid			
Object default setting	Connectio	on	Ethernet
	Ethernet		
		IP	192.168.0.203

Removable disk to Recorder

After creating an application, create a build in the PC and make sure there are no compilation errors.

Connect USB flash disk in to PC via USB port.

In Recorder editor software, set "Environment" to Download via Removable disk. In Environment, Select "Removable disk" at Download and then, click the "OK" button.

In Recorder editor software, click "Project", then click "Download" or click at 星 icon.

The application will transfer from the PC to the USB flash disk.

Insert USB flash disk in Recorder.

Switch on Power to the Recorder. Press "Load", select Path of project files, then press "Load" button near path selection.

It transfers the application from the USB flash disk to the Recorder.

PC to Recorder via USB to Ethernet Converter

For Low cost Recorder models, Ethernet is an option. You can purchase a USB to Ethernet converter to make it possible to download an application from PC to Recorder via Ethernet. Once USB to Ethernet converter is connected to Recorder, you can see the IP address at the Recorder itself via system information. This is similar to onboard Ethernet port.

Note: The purpose of USB to Ethernet converter is to download application from PC to Recorder only.

5.3.27 Project status

🔜 Project Status			<u>- 🗆 ×</u>
	Total	I	
Tag	0		
Objects	1		
Image	0		
Connection	0		
Alarm	0		
Recipe	0		
DataLog	0		
Scheduler	0		
UserScript	0		
Security	1		
Language	1		
Project designed time			
0 Days	0 Hours	0 Minutes	

It is used for project management purposes and to know limits and usage of objects.

Project used time: It shows how much time a project has been opened for editing purpose.

6. WEBSERVER

It is used to view Paperless Recorder from a Remote location via Internet.



6.1 Requirements

6.1.1 Hardware

Recommended hardware: PC with 3G GHz processor, 512 MB RAM. 5.0GB free space in the hard disk. Ethernet port, RJ 45 female.

6.1.2 Operating system

Windows based Operating systems, Windows XP, Windows 7, Windows 8 etc. 32 bit and 64 bit operating systems are supported.

6.1.3 Browser Requirements

Internet Explorer 10 or higher Google Chrome

6.1.4 IP Address Requirements

A Static IP address is required for the recorder.

Obtain a Static IP address from your Internet service Provider (ISP). This IP address should be unique.

Once the IP address is configured in the Recorder, use a Ping Instruction from the DOS prompt first to verify there is successful communication between the Recorder and the PC via Internet.




Fig: Response from the Recorder for the Ping instruction from PC

6.2 How to configure Web server Settings

For using Web server application in the PR series Recorder, Configuring the Recorder for a static IP address, and enabling the Web server.

Configuration **[**] men 54% 10/22/13 Configuration Channel AI DI Save Math AO Load External Display Timer Clock Default Communication Instrument Password: ******* Demo: Enable Auto-Output System Information

6.2.1 How to Configure Static IP Address

In the Configuration screen, select "Communication", then press the "Enter" soft key.

Communication	
Communication	
Ethernet ▲ IP: User Define IP Address: 192.168.0.111 Subnet Mask: 255.255.255.0 Default Gateway: 192.168.0.1 Default Gateway: 192.168.0.1 DNS Server: 168.95.1.1 Modbus Server Modbus TCP Port: 502 Web Server: Enable Serial -RS232/485 -Protocol: Modbus Slave	
-Address: 1 -Baud Rate: 115200	
Email Test	Back

Select IP type = User Define.

Enter the IP Address, Subnet Mask, Default Gateway, and DNS Server Settings in the Ethernet Settings.

Note: Make sure to enter Global, Unique, static fix IP address received from Internet solution provider.

6.2.2 How to Enable Web Server

Communication SD 77% 1009	15:13:46 6 03/10/14
Communication	
Ethernet IP: User Define IP Address: 192.168.0.111 Subnet Mask: 255.255.0 Default Gateway: 192.168.0.1 DNS Server: 168.95.1.1 Modbus Server Machuse TCD Part: 502	▲ ▼
-Modbus TCP Port: 502 Web Server: Enable -Serial -RS232/485 -Protocol: Modbus Slave -Address: 1	ł
-Baud Rate: 115200 -Data Format: No,8,1	Back
Test	Back

Select Web Server Menu in the Communication screen.

Enable the Web Server for using Web Server application in the Recorder.

Configura	ition mem 78%	SD 14:43:07 100% 03/10/14
	Configuration	
Save	Channel AI DI AO	
Load	DO Display Timer	-
Default	 Clock Communication Instrument Password: ******* Demo: Enable 	-
	- Auto-Output - System Information	*

After completing the above steps, press the "BACK" key, then the "Home" key to return to the main menu. It will save the configuration settings in the Recorder.

Now the Recorder is ready for the Web Server Applications.

Note: The Web Server update time on the browser is 1 second for real time data and statuses and 5 Seconds for Alarms.

6.3 How to View Recorder Data in PC via Webserver:

Connect Paperless Recorder to the Internet

Open the browser (Internet Explorer 10 or Google Chrome) in the PC



Enter the IP address of the Recorder in the address bar of the browser.

Format: http://192.168.1.111

Now you can see the Paperless Recorder screens in browser as shown below

				Realtime						Pagel			
Realtim	10	668.8		418		8	352.3		AI3		163.5		
Mode				•c <mark>·</mark>		1	Sec/Dot		12				
Alarm	1												
Status	5												
0/14 5:14	03/10/14 15:36:54	03/10/14 15:38:34	03/10/14 15:40:14	03/10/14 15:41:54	03/10/14 15:43:34	03/10/14 15:45:14	03/10/14 15:46:54	03/10/14 15:48:34	03/10/14 15:50:14	03/10/14 15:51:54	03/10/14 15:53:34	03/10/14 15:55:14	03/10/1 15:56:5

The display includes Real time values of all channels like AI, Math, Counters, Totalizers, Real time alarms, historical alarms, status of Digital Inputs, Digital Outputs, Analog Outputs, Counters, and Totalizers etc...

•

Menu			Realtime						Pagel			
Realtime	Pagel		10		8	04.6		:AIB:		147.7		
Mode	Page2		°C		11	Sec/Dot		<u></u>				
Alarm	Page3											
Status	Page4											
	Page5											
	Page6											
	Page7											
	Page8											
	Overview											
/14 03/10/14 514 15:36:54	03/10/14 15:38:34	03/10/14 15:40:14	03/10/14 15:41:54	03/10/14 15:43:34	03/10/14 15:45:14	03/10/14 15:46:54	03/10/14 15:48:34	03/10/14 15:50:14	03/10/14 15:51:54	03/10/14 15:53:34	03/10/14 15:55:14	03/10/1 15:56:5

Menu		Realtime		Overview	
All	159.4	A12 257.3	AI3 - 33.5	A14 •C 274.7	AI5 758.0
AI6	810.1	A17 1495.3	AI8 1869.2	A19 426.7	Allo 1051.7
A111	2033.6	AII2 1799.6	All3 16.60	All4 27.70	AII5 38.86
All6	83.40	All7 72.26	A118 61.13	A119 -48.4	A120 65.8
A121	-170.5	A122 362.5	A123 1197.4	A124 1393.4	Counter9 0
Math2	1611.9	Math3 460.2	Math4 777.0	Math3 1275.6	Math6 989.5
Math7	61.1	Math8 72.3	Math9 83.4	Math10 83.4	Math11 72.3

Press Overview to view the summary of all data in single screen

By pressing "Mode", you can view the data in Bar Graphs, Trends and Digital Values.


Menu			Realtime						Pagel			9
Realtime	74.3		세요		15	7.8		AI3		-66.4		
Mode			°C		1 S	ec/Dot						
Alarm	Bar											
Status	Digit											
												1
												1
/10/14 03/10/14	03/10/14	03/10/14 15:41:33	03/10/14 15:43:13	03/10/14	03/10/14 15:46:33	03/10/14 15:48:13	03/10/14 15:49:53	03/10/14 15:51:33	03/10/14 15:53:13	03/10/14 15:54:53	03/10/14 15:56:33	03/10/ 15:58:

By Pressing Trend you can view the data in trends.

Menu		Realtime		Pagel	
Realtime	6.8	als.	78.9	AI3	-92.5
Mode	1370.0	400.0	900.0	1820.0	1767.8
Alarm	- 1213.0	- 335.0	- 800.0	- 1638.0	- 1591.0
Status	- 1056.0	270.0	- 700.0	- 1456.0	- 1414.3
- 664.0	- 899.0	- 205.0	- 600.0	- 1274.0	- 1237.5
- 552.0	- 742.0	- 140.0	- 500.0	- 1092.0	- 1060.7
- 440.0	- 585.0	- 75.0	- 400.0	- 910.0	- 883.9
- 328.0	- 428.0	- 10.0	- 300.0	- 728.0	- 707.1
- 216.0	- 271.0	55.0	- 200.0	- 545.0	- 530.3
- 104.0	- 114.0	120.0	- 100.0	- 364.0	- 353.6
8.0	43.0	185.0	- 0.0	- 182.0	- 176.8
-120.0	-200.0	-250.0	-100.0	0.0	0.0

By pressing "Bar", you can view the data in Bar Graphs

By pressing "Digit", you can view the Data in the digital format



	Menu		Alar			
). A	Active Time	Acked	Туре	Name	Value	
1	3/40/44 16:15:02		ToToAlarm	3713	11.89	

By pressing "Alarm", you can view the List of Alarms along with the details

By pressing "Status", you can view the status of the Analog outputs, Digital Inputs, Digital Outputs, Counters and Totalizers.

→ C 🗋 192.168.0.111/#				
Menu	Status		DI	
DO AO Counter Totalizer				
Name	Value	Description		
DI1	Hi			
DI2	3			
DI3	Hi			
DI4	3			
D15	Hi			
DI6	3			

By pressing "DI", you can view the status of the Digital Inputs

Web Viewer ×	A DESCRIPTION OF THE OWNER.		
→ C 🗋 192.168.0.111/#			<u>ක</u>
Menu	Status	DO	
DO AO Counter Totalizer			
Name	Value	Description	
DO1	Off		
DO2	Off		
DO3	Off		
DO4	Off		
DO5	Off		
DO6	Off		

By pressing "DO", you can view the status of the Digital outputs

By pressing "AO", you can view the status of the Analog Outputs

Web Viewer ×		and the second sec	
→ C 192.168.0.111/#			☆
Menu	Status	AO	
N DO AO Counter Totalizer	1		
o. Name	Value	Description	
AO1	4.106		
AO2	5.421		
AO3	6.737		
AO4	8.051		
A05	9.368		
AO6	10.684		

Menu		Status		Counter	
	AO Counter Totalizer		1		
No. Na	me	Value	Description		
С	ounter9	0			
С	ounter l	0			
С	ounter2	0			
С	ounter3	0			
С	ounter4	0			
i C	ounter5	0			
с	ounter6	0			
С	ounter7	0			
c c	ounter8	0			

By pressing "Counters", you can view the status of the counters

By pressing "Totalizers" you can view the status of the totalizers.

Menu	Status	Totalizer	
Realting Counter Totalizer			
Name	Value	Description	
Totalizer1	0.000		
Totalizer2	5.064e+5		
Totalizer3	1.347e+5		
Totalizer4	2.765e+5		
Totalizer5	5.656e+5		
Totalizer6	5.433e+5		
Totalizer7	5.559e+4		
Totalizer8	5.464e+4		